


# Panasonic®



## User Manual Hybrid IP-PBX

Model No. **KX-TDA100D**




Thank you for purchasing a Panasonic Hybrid IP-PBX.  
Please read this manual carefully before using this product and save this manual for future use.

**KX-TDA100D: PDMPR Software File Version 5.1000 or later**

# Feature Highlights

## IP Communication


This PBX supports IP communication using a variety of IP telephones, such as the KX-NT300 series with Bluetooth® wireless headsets.



Consult your dealer

## Easy Operation


If you are using a certain Panasonic telephone that is equipped with a Navigator Key and a display, it helps you to access the desired feature easily. Also, you will be informed of the arrival of an incoming call or a message waiting by the lamp if it is equipped.



1.1 Before Operating the Telephones (Page 16)

## Wireless System


This PBX optionally supports a Portable Station (PS) system. PSs can be used in the PBX with other wired telephones.



1.8.11 Using Your PS in Parallel with a Wired Telephone (Wireless XDP Parallel Mode) (Page 135)

## Built-in Simplified Voice Message


You can set incoming calls to be redirected to your message box to let callers leave voice messages when you are unable to answer the phone.



1.6.2 Using Voice Messaging (Built-in Simplified Voice Message [SVM]) (Page 100)

## Call Centre

This PBX can establish Incoming Call Distribution Groups (ICD Group) by which a large volume of calls from the external customers could be received. One extension can act as the supervisor, and monitor other group members.



1.9 Utilising the Call Centre (Page 137)

## Voice Mail Integration


You can forward your calls to a voice processing system and let calling parties leave messages in your mailbox when you are unable to receive calls.



1.10.5 If a Voice Processing System is Connected (Page 149)

**PC Phone/PC Console**

This PBX supports the PC Phone/PC Console when your PC is connected to certain Panasonic telephones via USB interface. The PC Phone/PC Console provides advanced control and monitoring of your PBX.



Consult your dealer

**Call Record****(Station Message Detail Recording)**

This PBX can record or print out call information: date, time, extension no., dialled no., duration, etc.

| Date     | Time    | Ext  | ..... |
|----------|---------|------|-------|
| 01/02/02 | 10:03AM | 1230 | ..... |
| 01/02/02 | 11:07AM | 2230 | ..... |

Consult your dealer

**In This Manual,**

- The following abbreviations are used:  
Display PT → Proprietary Telephone with a Display  
DPT → Digital Proprietary Telephone  
IP-PT → IP Proprietary Telephone  
PS → Portable Station  
PT → Proprietary Telephone  
SLT → Single Line Telephone
- The suffix of each model number is omitted.
- The following icons are used frequently.



Hints



Conditions

**Notice**

- Under power failure conditions, the connected telephones may not operate. Please ensure that a separate telephone, not dependent on local power, is available for emergency use.
- Prior to connection of this product, please verify that the intended operating environment is supported. Satisfactory performance cannot be guaranteed for the following:
  - interoperability and compatibility with all devices and systems connected to this product
  - proper operation and compatibility with services provided by telecommunications companies over connected networks

**NOTES**

- Some optional hardware, software, and features are not available in some countries/areas. Please consult your certified Panasonic dealer for more information.
- This manual provides basic information on how you can access commonly used PBX functions with proprietary telephones (PTs), single line telephones (SLTs), portable stations (PSs), and DSS Consoles. For detailed information about each feature or setting, consult your dealer.
- In this manual, several kinds of PTs appear, as follows:
  - IP Proprietary Telephone (IP-PT)
  - Digital Proprietary Telephone (DPT)
  - Proprietary Telephone with a Display (Display PT)

## Feature Highlights

---

"PT" is used as a generic term to represent all of these PTs. If a PBX feature only supports specific PTs, such as IP-PTs, the available telephone types are clearly indicated.

- IP-PTs may become busy and you may not be able to make or receive calls, depending on the network status.
- The contents of this manual apply to PBXs with a certain software version, as indicated on the cover of this manual. To confirm the software version of your PBX, consult your dealer.
- Product specifications are subject to change without notice.

## Safety Notices

Please observe the safety notices in this manual in order to avoid danger to users or other people, and prevent damage to property.

The notices are classified as follows, according to the severity of injury or damage:

|                       |                                                                             |
|-----------------------|-----------------------------------------------------------------------------|
| <b><u>WARNING</u></b> | This notice means that misuse could result in death or serious injury.      |
| <b><u>CAUTION</u></b> | This notice means that misuse could result in injury or damage to property. |

## Trademarks

- The Bluetooth® word mark and logos are owned by the Bluetooth SIG, Inc. and any use of such marks by Panasonic Corporation is under licence.
- All other trademarks identified herein are the property of their respective owners.

## ***Important Safety Instructions***

When using your telephone equipment, basic safety precautions should always be followed to reduce the risk of fire, electric shock and injury to persons, including the following:

- Do not use the product near water, for example, near a bathtub, wash bowl, kitchen sink, or laundry tub, in a wet basement, or near a swimming pool.
- Avoid using wired telephones during an electrical storm. There is a remote risk of electric shock from lightning.
- Do not use a telephone in the vicinity of a gas leak to report the leak.

**SAVE THESE INSTRUCTIONS**

# Important Information

## SAVE THESE INSTRUCTIONS

### **WARNING**

#### **SAFETY REQUIREMENTS**

##### **For All Telephone Equipment**

- The product must only be installed and serviced by qualified service personnel. The product should be used as-is from the time of purchase; it should not be disassembled or modified. Disassembly or modification can cause a fire, electric shock, or damage to the product.
- Do not allow rain to fall on the product or expose the product to moisture. Do not let water, oils, or other liquids to splash onto the product. Such conditions can lead to fire or electric shock, and may impair the performance of the product.
- Follow all warnings and instructions marked on the product.
- Do not place the product on an unstable or uneven surface. If the product were to fall over, it may cause injury or damage to the product.
- Products that require a power source should only be connected to the type of electrical power supply specified on the product label. If you are not sure of the type of power supply to your home, consult your dealer or local power company.
- For safety purposes some products are equipped with an earthed plug. If you do not have an earthed outlet, please have one installed. Do not bypass this safety feature by tampering with the plug.
- Do not allow anything to rest on the power cord. Do not locate the product where the power cord may be stepped on or tripped on.
- Do not supply power to a combination of devices that exceeds the total rated capacity of the wall outlets or extension cables used. If outlets, power strips, extension cords, etc. are used in a manner that exceeds their rated capacity, they emit large amounts of heat, which could cause a fire.
- Regularly clean dust off of all equipment. Excessive amounts of dust can lead to fire or electric shock, and may impair the performance of the product.
- Unplug the product from the wall outlet and contact your dealer in the following cases:
  - a. When the power supply cord or plug is damaged or frayed.
  - b. If liquid has been spilled into the product.
  - c. If the product has been exposed to rain or water.
  - d. If the product does not operate according to the operating instructions. Adjust only the controls that are explained in the operating instructions. Improper adjustment of other controls may result in damage and may require service by a qualified technician to restore the product to normal operation.
  - e. If the product has been dropped or the cabinet has been damaged.
  - f. If product performance deteriorates.

##### **For the PBX**

- If damage to the unit exposes any internal parts, disconnect the power supply cord immediately and return the unit to your dealer.
- Unplug the unit(s) from the AC outlet if the system emits smoke, an abnormal smell or makes unusual noise. These conditions can cause fire or electric shock. Confirm that smoke has stopped and contact an authorised Panasonic Factory Service Centre.
- This unit is equipped with an earthed plug. For safety reasons this plug must only be connected to an earthed outlet that has been installed according to applicable regulations.
- Do not insert objects of any kind into this product, as they may touch dangerous voltage points or short out parts that could result in a fire or electric shock.



- Do not dispose of batteries in a fire, as they may explode. Dispose according to local regulations.

### **CAUTION**

## **SAFETY REQUIREMENTS**

### **For All Telephone Equipment**

- The product should be kept free of dust, moisture, high temperature (more than 40 °C), and vibration, and should not be exposed to direct sunlight.
- Unplug the product from the wall outlet before cleaning. Wipe the product with a soft cloth. Do not clean with abrasive powders or with chemical agents such as benzene or thinner. Do not use liquid cleaners or aerosol cleaners.

### **For the PBX**

- When relocating the equipment, first disconnect the telecom connection before disconnecting the power connection. When the unit is installed in the new location, reconnect the power first, and then reconnect the telecom connection.
- The power supply cord is used as the main disconnect device. Ensure that the AC outlet is located near the equipment and is easily accessible.
- Slots and openings in the front, back and bottom of the cabinet are provided for ventilation; to protect it from overheating, these openings must not be blocked or covered. The openings should never be blocked by placing the product on a bed, sofa, rug, or other similar surface while in use. The product should never be placed near or over a radiator or other heat source. This product should not be placed in a sealed environment unless proper ventilation is provided.
- When this product is no longer in use, make sure to detach it from the wall.
- To protect this unit from static electricity, do not touch any external connectors of the unit.

## **SECURITY REQUIREMENTS**

In order to use the PBX safely and correctly the Security Requirements below must be observed. Failure to do so may result in:

- Loss, leakage, falsification or theft of user information.
- Illegal use of the PBX by a third party.
- Interference or suspension of service caused by a third party.

### **What is User Information?**

User Information is defined as:

1. Information stored on the SD Memory Card:  
Phonebook data, user IDs, system settings data, passwords (User/Administrator/Installer), Personal Identification Numbers (PINs), etc.
2. Information sent from the PBX to a PC or other external device:  
Phone call data (including telephone numbers of outside parties), call charge data, etc.

### **Requirements**

1. The SD Memory Card contains software for all the processes of the PBX and all customer data. It can be easily removed and taken away from the PBX by a third party. Therefore, do not allow unauthorised access to prevent data leakage.
2. Always make backups of data stored on the SD Memory Card. For details, consult your dealer.
3. To prevent illegal access from the Internet, activate a Firewall.
4. To avoid unauthorised access and possible abuse of the PBX, we strongly recommend:
  - a. Keeping the password secret.
  - b. Selecting a complex, random password that cannot be easily guessed.
  - c. Changing your password regularly.



5. Perform the following when sending the PBX for repair or handing it over to a third party.
  - a. Make a backup of data stored on the SD Memory Card.
  - b. Using an SD formatter, format the SD Memory Card so that information cannot be retrieved from it.
6. To prevent data leakage, render the SD Memory Card physically unusable before disposal.
7. When user information is sent from the PBX to a PC or other external device, the confidentiality of that information becomes the responsibility of the customer. Before disposing of the PC or other external device, ensure that data cannot be retrieved from it by formatting the hard disk and/or rendering it physically unusable.

### **Notice**

## **SAFETY REQUIREMENTS**

### **For All Telephone Equipment**

- Read and understand all instructions.

### **For the PBX**

- Keep the unit away from heating appliances and devices that generate electrical noise such as fluorescent lamps, motors, and televisions. These noise sources can interfere with the performance of the PBX.
- If you are having problems making calls to outside destinations, follow this procedure to test the outside lines:
  1. Disconnect the PBX from all outside lines.
  2. Connect known working single line telephones (SLTs) to those outside lines.
  3. Make a call to an external destination using those SLTs.

If a call cannot be carried out correctly, there may be a problem with the outside line that the SLT is connected to. Contact your telephone company.

If all SLTs operate properly, there may be a problem with your PBX. Do not reconnect the PBX to the outside lines until it has been serviced by an authorised Panasonic Factory Service Centre.

### **Notes**

## **SAFETY REQUIREMENTS**

### **For All Telephone Equipment**

- Never attempt to insert wires, pins, etc. into the vents or holes of the product.

## Attention

- When using a Panasonic proprietary telephone (PT), use only the correct Panasonic handset.
- For users of PC Phone (Free Licence Version) shipped with KX-DT301/KX-T7601 USB Module:  
All features of the PC Phone software are available for 90 days from the date of installation.  
After this period expires, the following buttons on the Operation Screen will become unavailable:
  - Recording
  - TAM
  - Voice Memo
  - Text Memo
  - SpeedTo continue using any of the corresponding features after the trial period, please purchase KX-TDA0350 (PC Phone, 5 licences).

### For users in the European Union only

#### Information for Users on Collection and Disposal of Old Equipment and used Batteries



These symbols on the products, packaging, and/or accompanying documents mean that used electrical and electronic products and batteries should not be mixed with general household waste.

For proper treatment, recovery and recycling of old products and used batteries, please take them to applicable collection points, in accordance with your national legislation and the Directives 2002/96/EC and 2006/66/EC.

By disposing of these products and batteries correctly, you will help to save valuable resources and prevent any potential negative effects on human health and the environment which could otherwise arise from inappropriate waste handling.

For more information about collection and recycling of old products and batteries, please contact your local municipality, your waste disposal service or the point of sale where you purchased the items.

Penalties may be applicable for incorrect disposal of this waste, in accordance with national legislation.

#### For business users in the European Union

If you wish to discard electrical and electronic equipment, please contact your dealer or supplier for further information.



#### Information on Disposal in other Countries outside the European Union

These symbols are only valid in the European Union. If you wish to discard these items, please contact your local authorities or dealer and ask for the correct method of disposal.



#### Note for the battery symbol (bottom two symbol examples):

This symbol might be used in combination with a chemical symbol. In this case it complies with the requirement set by the Directive for the chemical involved.

# Table of Contents

|          |                                                                                                                                                    |            |
|----------|----------------------------------------------------------------------------------------------------------------------------------------------------|------------|
| <b>1</b> | <b>Operation .....</b>                                                                                                                             | <b>15</b>  |
| 1.1      | <b>Before Operating the Telephones .....</b>                                                                                                       | <b>16</b>  |
| 1.1.1    | Before Operating the Telephones .....                                                                                                              | 16         |
| 1.2      | <b>Making Calls .....</b>                                                                                                                          | <b>29</b>  |
| 1.2.1    | Basic Calling .....                                                                                                                                | 29         |
| 1.2.2    | Easy Dialling .....                                                                                                                                | 34         |
| 1.2.3    | Redial .....                                                                                                                                       | 37         |
| 1.2.4    | When the Dialed Line is Busy or There is No Answer .....                                                                                           | 38         |
| 1.2.5    | Accessing the ISDN Service (ISDN Service Access) .....                                                                                             | 46         |
| 1.2.6    | Alternating the Calling Method (Alternate Calling—Ring/Voice) .....                                                                                | 47         |
| 1.2.7    | Calling without Restrictions .....                                                                                                                 | 48         |
| 1.2.8    | To Access Another Party Directly from Outside (Direct Inward System Access [DISA]) .....                                                           | 49         |
| 1.2.9    | Setting Your Telephone from Another Extension or through DISA (Remote Setting) .....                                                               | 52         |
| 1.3      | <b>Receiving Calls .....</b>                                                                                                                       | <b>53</b>  |
| 1.3.1    | Answering Calls .....                                                                                                                              | 53         |
| 1.3.2    | Answering Hands-free (Hands-free Answerback) .....                                                                                                 | 54         |
| 1.3.3    | Answering a Call Ringing at Another Telephone (Call Pickup) .....                                                                                  | 55         |
| 1.3.4    | Answering a Call via an External Speaker (Trunk Answer From Any Station [TAFAS]) .....                                                             | 56         |
| 1.3.5    | Using the Answer/Release Button .....                                                                                                              | 57         |
| 1.3.6    | Identifying Malicious Calling Parties (Malicious Call Identification [MCID]) .....                                                                 | 59         |
| 1.4      | <b>During a Conversation .....</b>                                                                                                                 | <b>60</b>  |
| 1.4.1    | Transferring a Call (Call Transfer) .....                                                                                                          | 60         |
| 1.4.2    | Holding a Call .....                                                                                                                               | 64         |
| 1.4.3    | Talking to Two Parties Alternately (Call Splitting) .....                                                                                          | 68         |
| 1.4.4    | Answering Call Waiting .....                                                                                                                       | 70         |
| 1.4.5    | Multiple Party Conversation .....                                                                                                                  | 75         |
| 1.4.6    | Mute .....                                                                                                                                         | 84         |
| 1.4.7    | Letting Other People Listen to the Conversation (Off-hook Monitor) .....                                                                           | 85         |
| 1.4.8    | Using the Headset (Headset Operation) .....                                                                                                        | 86         |
| 1.5      | <b>Using a PDN/SDN Button .....</b>                                                                                                                | <b>88</b>  |
| 1.5.1    | Primary Directory Number (PDN)/Secondary Directory Number (SDN) Extension .....                                                                    | 88         |
| 1.6      | <b>Before Leaving Your Desk .....</b>                                                                                                              | <b>92</b>  |
| 1.6.1    | Forwarding Calls .....                                                                                                                             | 92         |
| 1.6.2    | Using Voice Messaging (Built-in Simplified Voice Message [SVM]) .....                                                                              | 100        |
| 1.6.3    | Showing a Message on the Caller's Telephone Display (Absent Message) .....                                                                         | 111        |
| 1.6.4    | Preventing Other People from Using Your Telephone (Extension Dial Lock) .....                                                                      | 113        |
| 1.7      | <b>Making/Answering an Announcement .....</b>                                                                                                      | <b>115</b> |
| 1.7.1    | Paging .....                                                                                                                                       | 115        |
| 1.7.2    | Answering/Denying a Paging Announcement .....                                                                                                      | 117        |
| 1.7.3    | Making an Announcement and Having a Multiple Party Conversation (Broadcasting) .....                                                               | 118        |
| 1.8      | <b>Setting the Telephone According to Your Needs .....</b>                                                                                         | <b>121</b> |
| 1.8.1    | Setting the Alarm (Timed Reminder) .....                                                                                                           | 121        |
| 1.8.2    | Refusing Incoming Calls (Do Not Disturb [DND]) .....                                                                                               | 123        |
| 1.8.3    | Receiving Call Waiting (Call Waiting/Off-hook Call Announcement [OHCA]/Whisper OHCA) .....                                                         | 127        |
| 1.8.4    | Displaying Your Telephone Number on the Called Party and Caller's Telephone (Calling/Connected Line Identification Presentation [CLIP/COLP]) ..... | 128        |

|             |                                                                                                                                     |            |
|-------------|-------------------------------------------------------------------------------------------------------------------------------------|------------|
| 1.8.5       | Preventing Your Telephone Number Being Displayed on the Caller's Telephone (Connected Line Identification Restriction [COLR]) ..... | 129        |
| 1.8.6       | Preventing Your Number Being Displayed on the Called Party's Telephone (Calling Line Identification Restriction [CLIR]) .....       | 130        |
| 1.8.7       | Preventing Other People from Joining Your Conversation (Executive Busy Override Deny) .....                                         | 131        |
| 1.8.8       | Turning on the Background Music (BGM) .....                                                                                         | 132        |
| 1.8.9       | Protecting Your Line against Notification Tones (Data Line Security) .....                                                          | 133        |
| 1.8.10      | Checking the Time Service Status .....                                                                                              | 134        |
| 1.8.11      | Using Your PS in Parallel with a Wired Telephone (Wireless XDP Parallel Mode) .....                                                 | 135        |
| 1.8.12      | Clearing Features Set at Your Extension (Extension Feature Clear) .....                                                             | 136        |
| <b>1.9</b>  | <b>Utilising the Call Centre .....</b>                                                                                              | <b>137</b> |
| 1.9.1       | Leaving an Incoming Call Distribution Group (Log-in/Log-out, Wrap-up) .....                                                         | 137        |
| 1.9.2       | Monitoring and Controlling the Call Status of an Incoming Call Distribution Group (Incoming Call Distribution Group Monitor) .....  | 140        |
| 1.9.3       | Forwarding a Waiting Call (Manual Queue Redirection) .....                                                                          | 143        |
| <b>1.10</b> | <b>Using User-supplied Equipment .....</b>                                                                                          | <b>144</b> |
| 1.10.1      | If a Doorphone/Door Opener is Connected .....                                                                                       | 144        |
| 1.10.2      | If an External Relay is Connected .....                                                                                             | 146        |
| 1.10.3      | If an External Sensor is Connected .....                                                                                            | 147        |
| 1.10.4      | If a Host PBX is Connected .....                                                                                                    | 148        |
| 1.10.5      | If a Voice Processing System is Connected .....                                                                                     | 149        |
| <b>1.11</b> | <b>Administrative Features .....</b>                                                                                                | <b>154</b> |
| 1.11.1      | Using the Telephones in a Hotel-type Environment (Hospitality Features) .....                                                       | 154        |
| 1.11.2      | Recording Information Using Preprogrammed Messages (Printing Message) .....                                                         | 161        |
| <b>1.12</b> | <b>After Moving to a New Location in the Office .....</b>                                                                           | <b>162</b> |
| 1.12.1      | Using the Same Settings as Your Previous Extension (Walking Extension) .....                                                        | 162        |
| <b>1.13</b> | <b>Using a Display Proprietary Telephone .....</b>                                                                                  | <b>163</b> |
| 1.13.1      | Using the Call Log .....                                                                                                            | 163        |
| 1.13.2      | Using the Directories .....                                                                                                         | 166        |
| 1.13.3      | Accessing System Features (System Feature Access) .....                                                                             | 173        |
| <b>2</b>    | <b>Manager Operation .....</b>                                                                                                      | <b>175</b> |
| <b>2.1</b>  | <b>Control Features .....</b>                                                                                                       | <b>176</b> |
| 2.1.1       | Extension Control .....                                                                                                             | 176        |
| 2.1.2       | Time Service Mode Control .....                                                                                                     | 177        |
| 2.1.3       | Restriction Level Control (Dial Tone Transfer) .....                                                                                | 179        |
| 2.1.4       | Turning on the External Background Music (BGM) .....                                                                                | 180        |
| 2.1.5       | Recording Outgoing Messages (OGM) .....                                                                                             | 181        |
| 2.1.6       | Allowing Users to Seize an Unavailable Outside Line (Trunk Busy Out) .....                                                          | 183        |
| 2.1.7       | Releasing Network Direct Station Selection (NDSS) Monitor .....                                                                     | 184        |
| <b>3</b>    | <b>Customising Your Phone &amp; System .....</b>                                                                                    | <b>185</b> |
| <b>3.1</b>  | <b>Customising Your Phone (Personal Programming) .....</b>                                                                          | <b>186</b> |
| 3.1.1       | Customising Your Phone (Personal Programming) .....                                                                                 | 186        |
| 3.1.2       | Settings on the Programming Mode .....                                                                                              | 188        |
| 3.1.3       | Customising the Buttons .....                                                                                                       | 198        |
| <b>3.2</b>  | <b>Manager Programming .....</b>                                                                                                    | <b>203</b> |
| 3.2.1       | Programming Information .....                                                                                                       | 203        |
| 3.2.2       | Manager Programming .....                                                                                                           | 204        |
| <b>3.3</b>  | <b>Customising Your System (System Programming) .....</b>                                                                           | <b>206</b> |
| 3.3.1       | Programming Information .....                                                                                                       | 206        |
| 3.3.2       | System Programming .....                                                                                                            | 209        |

---

|            |                                   |            |
|------------|-----------------------------------|------------|
| <b>4</b>   | <b>Appendix .....</b>             | <b>213</b> |
| <b>4.1</b> | <b>Troubleshooting .....</b>      | <b>214</b> |
| 4.1.1      | Troubleshooting .....             | 214        |
| <b>4.2</b> | <b>Feature Number Table .....</b> | <b>218</b> |
| 4.2.1      | Feature Number Table .....        | 218        |
| <b>4.3</b> | <b>What is This Tone? .....</b>   | <b>228</b> |
| 4.3.1      | What is This Tone? .....          | 228        |
|            | <b>Index.....</b>                 | <b>233</b> |



---

# **Section 1**

## **Operation**

*This chapter shows you step by step how to use each feature. Read this chapter to become familiar with the many useful features of this PBX.*



# 1.1 Before Operating the Telephones

## 1.1.1 Before Operating the Telephones

### ◆◆ What Kind of Telephone Can Be Used?

You can use a Panasonic IP Proprietary Telephone (IP-PT) (e.g., KX-NT346 or KX-NT366) and a single line telephone (SLT), such as a rotary pulse telephone or a Panasonic proprietary telephone (PT) such as the KX-T7636 or KX-DT346. You can also use a Panasonic Portable Station (PS) such as the KX-TCA255. Use the feature depending on the telephone you are using. If you are using a Panasonic proprietary telephone with a special feature button such as  or a display (Display PT) or both, you can follow the operation with the button or display messages for easy programming.

If you use a large display telephone (e.g., KX-NT346 or KX-T7636), you can follow the displayed messages to use the features. If your telephone does not have feature buttons and/or a display, you may operate the PBX by entering a feature number instead. Follow the operation for your type of telephone. If you use a Console, you can use the buttons on the Console as the buttons on the connected proprietary telephone.



- If you use a Panasonic proprietary telephone which does not have feature buttons, you may change one of the unused flexible buttons to a feature button. Refer to "3.1.3 Customising the Buttons".

### Registration for Your Portable Station (PS)

Your PS must be registered with the PBX and assigned an extension number before initial use, through system programming. To confirm the extension number of your PS, refer to "Your extension information" in Section "3.1.2 Settings on the Programming Mode".

### ◆◆ Feature Numbers

To use certain features, you need to enter specified feature numbers (and an additional parameter, if required). There are two types of feature numbers as follows:

- Flexible feature number
- Fixed feature number

Fixed feature numbers cannot be changed. However, you can change the flexible numbers to other numbers for easier use. In this manual, the default numbers (factory installed) are used for operations.

A flexible number is shown as  (half-shaded key). Use the new programmed number if you have changed the feature number. Write the new number in "4.2.1 Feature Number Table" (Appendix).

#### Notice

The default value of a flexible feature number may vary depending on country/area.



**If you use a single line telephone which does not have the "\*" or "#" keys;**  
it is not possible to access features that have "\*" or "#" in their feature numbers.

## ◆◆ Tone

You will hear various tones, during or after an operation, for confirmation. Refer to "4.3.1 What is This Tone?" (Appendix).

## ◆◆ Display

In this manual, you will see "the display ...". This refers to the display of a Panasonic proprietary telephone. If your telephone is not a Panasonic display proprietary telephone, the message will not be displayed. If you use a Panasonic display proprietary telephone, the display helps you confirm the settings. Some proprietary telephones also give you easy access to features. A message is displayed depending on the feature. By pressing the corresponding button on the side or at the bottom of the display, or pressing the Navigator Key, you can access the desired feature. Furthermore, depending on the display proprietary telephone, you can operate features or make calls using the display message. Refer to "1.13 Using a Display Proprietary Telephone".

### Notice

In this manual, the display messages are described in English.

### Your Extension Number

If you use a Panasonic display proprietary telephone, you can check your own extension number on the display. Press the TRANSFER button or Soft (S1) button while on-hook.

## ◆◆ Using a Navigator Key/Volume Key

The Navigator Key can be used for the display contrast and the volume control or you can search for desired items on the display. Press the Navigator Key/Volume Key in the desired direction. The contrast or the volume level and the items will change as follows:

| Navigator Key                                                                                                                                                                                                     | Volume Key                                                                                                                                                                               |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <p><b>Up</b><br/>(Level <b>increases</b>)</p> <p><b>Left</b>  <b>Right</b></p> <p><b>Down</b><br/>(Level <b>decreases</b>)</p> | <p><b>Up</b><br/>(Level <b>increases</b>)</p> <p></p> <p><b>Down</b><br/>(Level <b>decreases</b>)</p> |







## ◆◆ Restrictions

Some features may be restricted at your extension depending on system programming and the type of telephone being used.

## ◆◆ Icon Descriptions

The following icons show you the feature availability, notes and action to use the features.





### 1.1.1 Before Operating the Telephones

|                                                                                     |                                                                                                                                                                      |                                                                                     |                                                                                                                                                                                                                                                    |
|-------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|    | This feature cannot be used with a single line telephone.                                                                                                            |   | Seize an outside line (One of the following). <ul style="list-style-type: none"> <li>Press the CO button.</li> <li>Dial automatic line access number 0/9.</li> <li>Dial outside line group access number and outside line group number.</li> </ul> |
|    | See "Programming" for Related Programming if necessary.                                                                                                              |                                                                                     |                                                                                                                                                                                                                                                    |
|    | Off-hook (One of the following). <ul style="list-style-type: none"> <li>Lift the handset.</li> <li>Press the SP-PHONE button.</li> <li>Press TALK button.</li> </ul> |    | Press the Call button on the Doorphone.                                                                                                                                                                                                            |
|    | On-hook (One of the following). <ul style="list-style-type: none"> <li>Hang up.</li> <li>Press the SP-PHONE button.</li> <li>Press CANCEL button.</li> </ul>         |    | Press the hookswitch lightly.                                                                                                                                                                                                                      |
|    | Press the corresponding feature button on the proprietary telephone.                                                                                                 |    | Talk.                                                                                                                                                                                                                                              |
|   | Enter the required number.<br><Example><br><br>Enter the account code.            |   | You will hear a busy, confirmation, dial, ring or ringback tone.<br>B. Tone: Busy Tone<br>C. Tone: Confirmation Tone<br>D. Tone: Dial Tone<br>R. Tone: Ring Tone<br>R. B. Tone: Ringback Tone                                                      |
|  | Dial an extension number.                                                                                                                                            |  | Dial outside phone number.                                                                                                                                                                                                                         |
|  | Dial the telephone number.                                                                                                                                           |  | Press any dial key (0–9, *, #).                                                                                                                                                                                                                    |

◆◆ When You Use a Panasonic Proprietary Telephone

If you use a Panasonic proprietary telephone and the Console, they may have some of the useful feature buttons described below. For a PS user, refer to "Operating Instructions" for PS. These buttons make operations simple. The illustrations may differ from the buttons on your telephone.

Buttons on the PT

|                                                                                                                                                                        |                                                                                                                                                                                                   |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |                                                               |
|------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------|
| <br> | <p><b>Flexible Buttons:</b></p> <p>Used to make or receive an outside call (CO button), or as a feature button.<br/>Button assignment is required. Refer to "Customised Buttons" for details.</p> | <br><br><br><br><br> | <p><b>SP-PHONE:</b></p> <p>Used for hands-free operation.</p> |
|------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------|

1.1.1 Before Operating the Telephones

|                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |                                                                                                                               |                                                                                                                                                                                                                                                                                                                                                                                                                |                                                                                                                                                                                                           |
|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <div><div></div><div></div><div><div></div><div></div><div><div></div><div></div></div></div></div> | <div><div><b>AUTO DIAL/STORE:</b></div><div>Used for System/Personal Speed Dialling or storing programme changes.</div></div> | <div><div></div><div></div></div>                                                                                                                                                                                                            | <div><div><b>PAUSE:</b></div><div>Used to insert a pause when storing a telephone number. This button also functions as the PROGRAM button when there is no PROGRAM button on your telephone.</div></div> |
| <div><div></div><div></div><div><div></div><div></div></div></div>                                                                                                                                                                                             | <div><div><b>REDIAL:</b></div><div>Used to redial the last dialled number.</div></div>                                        | <div><div></div><div></div><div><div></div><div></div></div></div> | <div><div><b>MESSAGE:</b></div><div>Used to leave a message waiting indication or call back the party who left the message waiting indication.</div></div>                                                |

|                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |                                                                                                                                                      |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |                                                                                                    |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------|
| <div></div> <div></div> <div></div> <div></div> <div></div> <div></div>            | <p><b>INTERCOM:</b></p> <p>Used to make or receive intercom calls.</p>                                                                               | <div></div>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              | <p><b>Soft Buttons:</b></p> <p>Used to select the item displayed on the bottom of the display.</p> |
| <div></div> <div></div> <div></div> <div></div> <div></div> <div></div> | <p><b>AUTO ANS (Auto Answer)/ MUTE:</b></p> <p>Used to receive an incoming call in hands-free mode or mute the microphone during a conversation.</p> | <div></div> <div></div> <div></div> <div></div> <div></div> <div></div> | <p><b>TRANSFER:</b></p> <p>Used to transfer a call to another party.</p>                           |

1.1.1 Before Operating the Telephones

|                                                                                                                                                         |                                                                                                            |                                                                                                                                                                                     |                                                                                                                                                                                                 |
|---------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <div><div><div>HOLD</div><div></div></div><div><div></div><div></div></div><div><div>HOLD</div><div></div></div><div><div></div><div></div></div></div> | <div><div><b>HOLD:</b></div><div>Used to place a call on hold.</div></div>                                 | <div><div><div>FLASH/<br/>RECALL</div><div></div></div><div><div>R</div><div></div></div><div><div>FLASH/<br/>RECALL</div><div></div></div><div><div>R</div><div></div></div></div> | <div><div><b>FLASH/RECALL:</b></div><div>Used to disconnect the current call and make another call without hanging up. This button also functions as a CANCEL button while on-hook.</div></div> |
| <div><div><div>CONF</div><div></div></div><div><div></div><div></div></div><div><div>CONF</div><div></div></div><div><div></div><div></div></div></div> | <div><div><b>CONF (Conference):</b></div><div>Used to establish a multiple party conversation.</div></div> | <div><div><div>FWD/DND</div><div></div></div><div><div></div><div></div></div><div><div>FWD/DND</div><div></div></div><div><div></div><div></div></div></div>                       | <div><div><b>Call Forwarding (FWD)/Do Not Disturb (DND):</b></div><div>Used to perform Call Forwarding (FWD) or Do Not Disturb (DND).</div></div>                                               |

|                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |                                                                            |                                                                                                                                                                                                                                                                                                                                                                                     |                                                                                                                            |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------|
| <div></div> <div></div> <div></div> <div></div> <div></div> | <p><b>PROGRAM:</b></p> <p>Used to enter and exit the Programming mode.</p> | <div></div> <div></div> <div></div> <div></div> | <p><b>Navigator Key/Volume Key:</b></p> <p>Used to adjust the volume and the display contrast or select desired items.</p> |
| <div></div>                                                                                                                                                                                                                                                                                                                                                                                    | <p><b>ENTER:</b></p> <p>Used to confirm the selected item.</p>             | <div></div>                                                                                                                                                                                                                                                                                       | <p><b>CANCEL:</b></p> <p>Used to cancel the selected item.</p>                                                             |



#### Customised Buttons

If the term is in parentheses like (Account) in this manual, it means a flexible button has been made into an "Account" button. To customise, refer to "3.1.3 Customising the Buttons".

| Button                                                | Feature                                                                                                                                                                                        |
|-------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Loop-CO (L-CO)                                        | Used to access an idle outside line for making outside calls.<br>Incoming outside calls from any outside line arrive at this button.                                                           |
| Group-CO (G-CO)                                       | Used to access an idle outside line in a specified outside line group for making outside calls.<br>Incoming calls from outside lines in the assigned outside line group arrive at this button. |
| Single-CO (S-CO)                                      | Used to access a specified outside line for making or receiving outside calls.                                                                                                                 |
| Direct Station Selection (DSS)                        | Used to access an extension with one touch.<br>It is also possible to be changed to the other feature button.                                                                                  |
| One-touch Dialling                                    | Used to access a desired party or system feature with one touch.                                                                                                                               |
| Incoming Call Distribution Group (ICD Group)          | Used to access a specified incoming call distribution group for making or receiving calls.                                                                                                     |
| Message                                               | Used to leave a message waiting indication or call back the party who left the message waiting indication.                                                                                     |
| Message for Another Extension                         | Used to have a Message button for another extension.                                                                                                                                           |
| Call Forwarding (FWD)/Do Not Disturb (DND)—Both calls | Used to forward all calls to a specified destination or refuse.                                                                                                                                |
| FWD/DND—Outside calls                                 | Used to forward outside calls to a specified destination or refuse.                                                                                                                            |
| FWD/DND—Intercom calls                                | Used to forward intercom calls to a specified destination or refuse.                                                                                                                           |
| Group FWD—Both calls                                  | Used to forward all the calls to your group to a specified destination.                                                                                                                        |
| Group FWD—Outside calls                               | Used to forward the outside calls to your group to a specified destination.                                                                                                                    |
| Group FWD—Intercom calls                              | Used to forward the intercom calls to your group to a specified destination.                                                                                                                   |
| Account                                               | Used to enter an account code.                                                                                                                                                                 |
| Conference                                            | Used to establish a multiple party conversation.                                                                                                                                               |
| Terminate                                             | Used to disconnect the current call and make another call without hanging up.                                                                                                                  |
| External Feature Access (EFA)                         | Used to access special features offered by a host PBX or a telephone company.                                                                                                                  |
| Call Charge Reference                                 | Used to check the total call charge for your own extension.                                                                                                                                    |
| Call Park                                             | Used to park or retrieve a call in a preset parking zone.                                                                                                                                      |
| Call Park (Automatic Park Zone)                       | Used to park a call in an idle parking zone automatically.                                                                                                                                     |
| Call Log                                              | Used to show the incoming call information.                                                                                                                                                    |

| Button                                           | Feature                                                                                                                    |
|--------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------|
| Call Log for ICD Group                           | Used to have a Call Log button for incoming call distribution group.                                                       |
| Log-in/Log-out                                   | Used to switch between the log-in and log-out mode.                                                                        |
| Log-in/Log-out of a specified group              | Used to have a Log-in/Log-out button for another incoming call distribution group.                                         |
| Log-in/Log-out for all groups                    | Used to have a Log-in/Log-out button for all groups.                                                                       |
| Hurry-up                                         | Used to transfer the longest waiting call in the queue of an incoming call distribution group to the overflow destination. |
| Wrap-up                                          | Used to switch the wrap-up status, Ready and Not Ready mode.                                                               |
| System Alarm                                     | Used to confirm a PBX error.                                                                                               |
| Time Service (Day/Night/Lunch/Break)             | Used to switch the time service mode.                                                                                      |
| Answer                                           | Used to answer an incoming call.                                                                                           |
| Release                                          | Used to disconnect the line during or after a conversation or to complete a Call Transfer.                                 |
| Toll Restriction/Call Barring                    | Used to change the toll restriction/call barring level of other extension users temporarily.                               |
| ISDN Service                                     | Used to access an ISDN service.                                                                                            |
| Calling Line Identification Restriction (CLIR)   | Used to switch between the CLIP and CLIR services.                                                                         |
| Connected Line Identification Restriction (COLR) | Used to switch between the COLP and COLR services.                                                                         |
| ISDN-Hold                                        | Used to transfer a call using telephone company.                                                                           |
| Headset                                          | Used to talk using the headset.                                                                                            |
| Time Service Switching Mode (Automatic/Manual)   | Used to switch the time service mode, Automatic or Manual.                                                                 |
| Two-way Record                                   | Used to record a conversation into your own mailbox.                                                                       |
| Two-way Transfer                                 | Used to record a conversation into the mailbox of a specific extension.                                                    |
| One-touch Two-way Transfer                       | Used to record a conversation into the mailbox of a specific extension with one touch.                                     |
| Live Call Screening (LCS)                        | Used to monitor your own voice mailbox while an incoming caller is leaving a message and, if desired, intercept the call.  |
| Voice Mail Transfer                              | Used to transfer a call to the mailbox of a specified extension.                                                           |
| Network Direct Station Selection (NDSS)          | Used to access an extension connected to other PBXs in the network with one touch.                                         |
| CTI                                              | Used to access CTI features.                                                                                               |
| Check-in                                         | Used to switch the room status of extensions from Check-out to Check-in.                                                   |
| Check-out                                        | Used to switch the room status of extensions from Check-in to Check-out.                                                   |

### 1.1.1 Before Operating the Telephones

---

| Button                           | Feature                                                                                                        |
|----------------------------------|----------------------------------------------------------------------------------------------------------------|
| Cleaned-up                       | Used to switch the room status of extensions between Ready and Not Ready.                                      |
| Primary Directory Number (PDN)   | Used to make and receive both outside and intercom calls.                                                      |
| Secondary Directory Number (SDN) | Used to show the current status of another extension, call the extension, and pick up or transfer calls to it. |

◆◆ How to Follow the Steps


An example of system operation is shown below.

◆◆ Calling Another Extension

To call an extension (Intercom Call)

PT/SLT/PS

  
Off-hook.

  
Dial **extension number**  
or press **DSS**.

  
Talk.

**Feature title**

**Operation steps**  
The description of the icons are explained on "Icon Descriptions".



- The DSS button light shows the current status as follows:  
**Off:** The extension is idle.  
**Red on:** Your or another extension is using the line.

**Conditions**



- To call using a directory, refer to "1.13.2 Using the Directories".
- For quick operation**  
If you are an operator or dial some extensions frequently, DSS buttons are useful.
- Hands-free Operation**  
You can make an intercom call and have a conversation in hands-free mode using the SP-PHONE button.

**Hints**



**Customising Your Phone**


- 3.1.2 Settings on the Programming Mode—**Preferred Line Assignment—Outgoing**  
Select the seized line when going off-hook.
- 3.1.3 Customising the Buttons  
Create or edit a Direct Station Selection (DSS) button.

**Programming References:** The related or required programming is noted.

### 1.1.1 Before Operating the Telephones

#### ◆◆ Connection Example

This diagram shows you a connection example.




## 1.2 Making Calls

### 1.2.1 Basic Calling

- ♦♦ Calling Another Extension
- ♦♦ Calling an Outside Party
- ♦♦ Making a Call to a Private Network (TIE Line Access)
- ♦♦ Using an Account Code (Account Code Entry)

#### ♦♦ Calling Another Extension

To call an extension (Intercom Call)



- The DSS button light shows the current status as follows:  
**Off:** The extension is idle.  
**Red on:** Your or another extension is using the line.
- \* You have to press the SDN button once or twice depending on the mode of the SDN button. For details, refer to "1.5.1 Primary Directory Number (PDN)/Secondary Directory Number (SDN) Extension".



- To call using a directory, refer to "1.13.2 Using the Directories".
- **For quick operation**  
 If you are an operator or dial some extensions frequently, DSS buttons are useful.
- **Hands-free Operation**  
 You can make an intercom call and have a conversation in hands-free mode using the SP-PHONE button.




#### Customising Your Phone

- 3.1.2 Settings on the Programming Mode—**Preferred Line Assignment—Outgoing**  
 Select the seized line when going off-hook.
- 3.1.3 Customising the Buttons  
 Create or edit a Direct Station Selection (DSS) button.

**To call an operator (Operator Call)**

You can call an extension or a group assigned as the operator.




- The operator call number (default) varies depending on country/area.

◆◆ **Calling an Outside Party**

You have to seize an outside line before dialling an outside phone number because external calls are made via your PBX.


Select one of the following methods:

**To select an idle outside line automatically (Automatic Line Access)**




- The automatic line access number (default) varies depending on country/area.

**To select an idle outside line in the specified outside line group automatically (Outside Line Group Access)**



### To select the specified outside line



- Each of the S-CO button or G-CO button light shows the current status as follows:  
**Off:** The line is idle.  
**Red on:** The line is in use.
- You may be restricted from making a call to the specified outside party. To make a call, refer to "1.2.7 Calling without Restrictions".



- To confirm number before dialling**, you can enter a phone number and confirm it on the display and then go off-hook. (Predialling)
- Call Charge Reference**  
You can confirm your total call charges by pressing the Call Charge Reference button.
- To make a call to another party without going on-hook**, press the FLASH/RECALL button. It will re-access the outside line and provide external dial tone. Pressing the Terminate button will provide intercom dial tone. You can dial the new phone number without going on/off-hook.
- Hands-free Operation**  
You can make an outside call and have a conversation in hands-free mode using the SP-PHONE button.




### Customising Your Phone

- 3.1.2 Settings on the Programming Mode—**Preferred Line Assignment—Outgoing**  
Select the seized line when going off-hook.
- 3.1.3 Customising the Buttons  
Create or edit a Loop-CO (L-CO) button, a Group-CO (G-CO) button, a Single-CO (S-CO) button, a Terminate button or a Call Charge Reference button.

## ◆◆ Making a Call to a Private Network (TIE Line Access)

You can access extensions connected to other PBXs in a private network.

### To call






1.2.1 Basic Calling



- \* Which type of telephone number must be entered depends on the settings of your PBX.

To call with one touch



- **To start monitoring another PBX extension after customising an NDSS button**, go off-hook, press the NDSS button, and go on-hook.  
The NDSS button light will show the current status as follows:  
**Off:** The extension is idle.  
**Red on:** The extension is busy.




**Customising Your Phone**

- 3.1.3 Customising the Buttons  
Create or edit a Network Direct Station Selection (NDSS) button.

◆◆ Using an Account Code (Account Code Entry)

You may give a specified account code to extension users and check their telephone usage. You can specify an account code for each client and check the call duration.





- **A Panasonic proprietary telephone extension user** can enter an account code during a conversation and when hearing reorder tone after the other party hangs up.
- Account codes may use the digits "0" through "9".
- Depending on the settings of your PBX, you may be required to enter an account code to make an outside call.
- **If you enter the wrong code**, press the "\*" key and re-enter the account code.



- **For your convenience**, you can store the code with the phone number in the memory (e.g., Speed Dialling).



### Customising Your Phone

- 3.1.3 Customising the Buttons  
Create or edit an Account button.


# 1.2.2 Easy Dialling

This is convenient for frequently dialled phone numbers.

- ♦♦ With a One-touch Button (One-touch Dialling)
- ♦♦ Using Numbers Stored at Your Extension (Personal Speed Dialling)
- ♦♦ Using Numbers Stored in the PBX (System Speed Dialling)
- ♦♦ To a Preset Number by Going Off-hook (Hot Line)
- ♦♦ Using a Preprogrammed Number (Quick Dialling)

## ♦♦ With a One-touch Button (One-touch Dialling)

You can store a phone number into the flexible button for one-touch operation.




### Customising Your Phone


- 3.1.3 Customising the Buttons  
Create or edit a One-touch Dialling button, store the desired phone number or feature number.

## ♦♦ Using Numbers Stored at Your Extension (Personal Speed Dialling)

You can store up to 100 numbers at your extension for your personal use.  
This feature is also known as Station Speed Dialling.

### To store a phone number




**To dial**

- To call using a directory, refer to "1.13.2 Using the Directories".

### ◆◆ Using Numbers Stored in the PBX (System Speed Dialling)


You can make calls using speed dialling numbers stored in the PBX.




- To call using a directory, refer to "1.13.2 Using the Directories".

### ◆◆ To a Preset Number by Going Off-hook (Hot Line)


You can make an outside call simply by going off-hook if you have preprogrammed your phone. This feature is also known as Pickup Dialling.

**To store a phone number**

To set/cancel



To dial



- **To call another party**, dial the desired party's phone number before the preprogrammed number is dialled.
- You should assign the intercom line as the seized line when going off-hook. (Preferred Line Assignment—Outgoing)
- It is possible to increase the delay before Hot Line is activated through system programming. This can be useful if you require more time after going off-hook to dial another telephone number or extension number.




**Customising Your Phone**

- 3.1.2 Settings on the Programming Mode—**Preferred Line Assignment—Outgoing**  
Select the seized line when going off-hook.

◆◆ **Using a Preprogrammed Number (Quick Dialling)**

You can make a call simply by pressing the preprogrammed number for quick dialling.




- The length of a quick dialling number can be increased to a maximum of eight digits.
- This is a useful feature for hotels.  
For example, to dial Room Service, dial the digit "3", not the full extension number.

## 1.2.3 Redial

This is convenient when calling the same outside party again.

- ♦♦ Redialling the Last Number You Dialed (Last Number Redial)

### ♦♦ Redialling the Last Number You Dialed (Last Number Redial)



- Up to 32 digits can be stored and redialled.
- After pressing REDIAL, if you hear a busy tone again, press REDIAL to retry.



- **Automatic Redial**  
**To redial automatically**, press the SP-PHONE button and then the REDIAL button, or press the REDIAL button directly. It will keep trying the busy number until the called party answers or until a specified timeout.  
 You can perform other tasks during dialling. To cancel, press the FLASH/RECALL button.  
 Some outside lines may not support this feature.  
 This feature is not available for the KX-T7665 and PS.

### 1.2.4 When the Dialed Line is Busy or There is No Answer

- ♦♦ Reserving a Busy Line (Automatic Callback Busy)
- ♦♦ Setting Callback on an ISDN Line (Completion of Calls to Busy Subscriber [CCBS])
- ♦♦ Sending a Call Waiting Notification (Call Waiting)
- ♦♦ Leaving a Message Waiting Indication/Calling Back the Caller Who Left an Indication (Message Waiting)
- ♦♦ Joining an Existing Call (Executive Busy Override)
- ♦♦ Monitoring Another Extension (Call Monitor)
- ♦♦ To an Extension Refusing the Call (DND Override)

#### ♦♦ Reserving a Busy Line (Automatic Callback Busy)

You can set the telephone to receive callback ringing:

- when a dialed extension becomes idle.
- when your desired outside line that is in use by another extension becomes idle.

You cannot set Automatic Callback Busy for a busy party outside of the PBX.

When you answer the callback ringing:

- For an outside call: The line is seized.
- For an intercom call: The called extension starts ringing automatically.

#### To set (for both extension and outside line)

**PT/SLT/PS**

*While hearing a busy tone*



Enter 6.      C.Tone      On-hook.


#### To answer the callback ringing from an idle extension

**PT/SLT/PS**


*While hearing a callback ringing*



Off-hook.      R.B.Tone      Talk.


**To answer the callback ringing from an idle outside line**

- If you do not answer the callback ringing within 10 seconds, this feature will be cancelled.

**To cancel callback ringing (Automatic Callback Busy Cancel)**

## ◆◆ Setting Callback on an ISDN Line (Completion of Calls to Busy Subscriber [CCBS])

You can set the telephone to receive callback ringing when a busy called party on an ISDN line becomes free. When you answer the callback ringing, the called party's telephone number is automatically dialed.






### To answer while hearing a callback ringing




### To cancel (CCBS Cancel)



- If you do not answer within a specified time period, this feature will be cancelled.
- Availability of this feature depends on the ISDN service of your telephone company.

## ◆◆ Sending a Call Waiting Notification (Call Waiting)

You can inform the called party that your call is waiting.  
This feature is also known as Busy Station Signalling (BSS).



- **Depending on the type of the other party's telephone**, you may be able to talk to the other party using the speaker and the microphone (Off-hook Call Announcement [OHCA]), or you can send a call announcement through the handset (Whisper OHCA), if they are having another conversation using the handset.  
Refer to "1.8.3 Receiving Call Waiting (Call Waiting/Off-hook Call Announcement [OHCA]/Whisper OHCA)".
- Depending on system programming and the called extension's setting, a call waiting tone may be sent automatically without performing the operation above. For details, refer to "**Automatic Call Waiting**" in "3.1.2 Settings on the Programming Mode".


## ◆◆ Leaving a Message Waiting Indication/Calling Back the Caller Who Left an Indication (Message Waiting)

### ◆ For an extension leaving a message waiting indication

When the called extension is busy or does not answer your call, you can leave a notification so that the called party may call you back.


### ◆ For an extension receiving a message waiting indication

As a message receiver, the Message button light or Message/Ringer Lamp lets you know that a call has been received. If you receive notification, you can call the caller back by a simple operation.




### ◆ For an extension leaving a message waiting indication

To leave a message waiting indication




To leave/cancel a message waiting indication




### ◆ For an extension receiving a message waiting indication

To check the left message and call back




## 1.2.4 When the Dialed Line is Busy or There is No Answer

### To call back



### To clear message waiting indications left on your extension



- The Message button light or Message/Ringer Lamp shows the current status as follows:  
**Off:** No message  
**Red on:** You have a message.
- The display shows the messages starting with the most recent call.
- At a called extension, the MESSAGE button allows you to clear message waiting indications if you do not want to call the callers back. To clear, press the MESSAGE button and then press the soft button.
- On your PT, you can establish one or more Message for Another Extension buttons. These buttons can accept the message waiting notification of other extensions or various incoming call distribution groups.  
In other words, you can monitor the message waiting notifications of other telephones.
- A single line telephone extension user will receive a special dial tone as message waiting notification when going off-hook. The message waiting lamp of a single line telephone can also let you know that you have a message in the same way as the Message button.




### Customising Your Phone

- 3.1.3 Customising the Buttons  
Create or edit a Message button or Message for Another Extension button.


## ◆◆ Joining an Existing Call (Executive Busy Override)

The preprogrammed extension can call someone who is busy on the telephone and establish a three-party conversation.

### To join an intercom call



### To join an outside call




- To join another conversation, you must have Executive Busy Override enabled at your extension through COS programming.
- It is possible for an originating extension to leave a three-party conversation with an outside party and let the two other parties talk by simply going on-hook.

### ◆ For the originating extension

## 1.2.4 When the Dialed Line is Busy or There is No Answer

---

### To talk to each party alternately




- You can also deny others the possibility of joining your conversation (Default: Allow). Refer to "1.8.7 Preventing Other People from Joining Your Conversation (Executive Busy Override Deny)".

## ◆◆ Monitoring Another Extension (Call Monitor)


The preprogrammed extension can monitor another extension.

### To monitor



## ◆◆ To an Extension Refusing the Call (DND Override)

The preprogrammed extension can call someone who has set the DND feature.




## 1.2.5 Accessing the ISDN Service (ISDN Service Access)

You can access services provided by the ISDN.



### To access



- Availability of features depends on the ISDN service of your telephone company.



### Customising Your Phone

- 3.1.3 Customising the Buttons  
Create or edit an ISDN Service button.


## 1.2.6 Alternating the Calling Method (Alternate Calling—Ring/Voice)

The caller can alternate the alerting method, either ring or voice, when making an intercom call.

On the other hand, any extension can set the alerting method, either ring or voice, when receiving an intercom call.

**Ringing (Default):** You can call the other party with a ring tone.

**Voice-calling:** You can talk to the other party immediately after confirmation tone.



### To change the method

| PT/SLT/PS                                                                         |                                                                                             |                                                                                   |
|-----------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------|
| <i>After dialling</i>                                                             |                                                                                             |                                                                                   |
|  | <br>C.Tone |  |
| Enter *.                                                                          |                                                                                             | Talk.                                                                             |



- If the called party uses a single line telephone or portable station, Voice-calling is not available.
- This feature is not available when the called party's telephone is in the Voice Call Deny mode.



### Customising Your Phone

- 3.1.2 Settings on the Programming Mode—**Alternate Receiving—Ring/Voice**  
Select the alerting method, either ring or the other party's voice.




## 1.2.7 Calling without Restrictions

- ♦♦ Using Your Calling Privileges at Another Extension (Remote COS Access)


### ♦♦ Using Your Calling Privileges at Another Extension (Remote COS Access)

You can use your calling privileges (Class of Service) at another extension. You may override restrictions which have been set. To use this feature, an original extension number and an extension PIN (Personal Identification Number) are required. You can make a call by entering a verification code and verification code PIN.

#### To call (Walking COS)



#### To call with a verification code (Verification Code Entry)




## 1.2.8 To Access Another Party Directly from Outside (Direct Inward System Access [DISA])


- ♦♦ Calling through DISA

### ♦♦ Calling through DISA


When outside callers access extensions in the PBX, a prerecorded message greets the caller and gives information about how to access an extension. You do not need the operator's assistance. You may be able to access system features or call an outside party with your password depending on the security mode.



#### To call an extension




### To call an outside party



- \* Callers from preprogrammed outside numbers can access the PBX through DISA without a password (extension PIN/verification code PIN) (**DISA Automatic Walking COS**).

### To retry





#### **CAUTION**

There is a risk that fraudulent telephone calls will be made using the Outside-to-Outside Call feature of DISA.

The cost of such calls will be billed to the owner/renter of the PBX.

To protect the PBX from this kind of fraudulent use, we strongly recommend:


- a.** Enabling DISA security (Trunk Security or All Security).
  - b.** Keeping your passwords (verification code PIN/extension PIN) secret.
  - c.** Selecting complex, random PINs that cannot be easily guessed.
  - d.** Changing PINs regularly.
- **Time limit**  
Both parties will hear an alarm tone fifteen seconds before the specified time limit. To extend, press any dial button except \*.
  - **If Built-in Automated Attendant service is set**, you can access the desired extension simply by pressing a single digit (0–9) from the options given the prerecorded message.

# 1.2.9 Setting Your Telephone from Another Extension or through DISA (Remote Setting)


You can set the following features on your telephone from another extension or through DISA.

- Call Forwarding (FWD)/Do Not Disturb (DND)
- Changing the Log-in/Log-out Status of Extensions
- Absent Message
- Extension Dial Lock
- Time Service—Changing the Time Mode (Day/Night/Lunch/Break)

## From another extension



## Through DISA



## 1.3 Receiving Calls

### 1.3.1 Answering Calls

PT/SLT/PS



Off-hook.

▶



Talk.

Select one of the following methods:

- Lift the handset to receive the preferred line.  
(Default: Ringing line is selected.)
- Press the SP-PHONE button.
- Press the flashing CO, INTERCOM, ICD Group, PDN, or SDN button directly.
- Press the Answer button.



- **Hands-free Operation**

You can receive a call and have a conversation in hands-free mode using the SP-PHONE button.



- **Customising Your Phone**

- 3.1.2 Settings on the Programming Mode—

- **Preferred Line Assignment—Incoming**

Select the seized line when going off-hook.

- **Alternate Receiving—Ring/Voice**

Select the alerting method, either ring or the other party's voice.

- 3.1.3 Customising the Buttons


Create or edit an Incoming Call Distribution Group (ICD Group), Primary Directory Number (PDN), or Secondary Directory Number (SDN) button.

### 1.3.2 Answering Hands-free (Hands-free Answerback)

You can answer an incoming call without going off-hook as soon as the line is connected. When an intercom call arrives, you will hear the caller talking without the phone ringing. When an outside call arrives, you will hear the caller talking after a preprogrammed number of rings. Hands-free Answerback for outside calls requires system programming.



**To set/cancel**



- The AUTO ANS button light shows the current status as follows:  
**Off:** Not set  
**Red on:** Set
- PS users: Refer to "Operating Instructions" for PS.

## 1.3.3 Answering a Call Ringing at Another Telephone (Call Pickup)

- ♦♦ Answering a Call from Another Telephone (Call Pickup)
- ♦♦ Denying Other People the Possibility of Picking Up Your Calls (Call Pickup Deny)


### ♦♦ Answering a Call from Another Telephone (Call Pickup)

You can answer an incoming call that is ringing at another extension or group from your phone without leaving your desk.

The following types of pickup are available:

**Group Call Pickup:** Picks up a call within your group.


**Directed Call Pickup:** Picks up a specified extension's call.



- If you receive a call waiting tone, you can ask a third party to pick up your second call with Directed Call Pickup.

### ♦♦ Denying Other People the Possibility of Picking Up Your Calls (Call Pickup Deny)

You can deny or allow other people to pick up your calls.






## 1.3.4 Answering a Call via an External Speaker (Trunk Answer From Any Station [TAFAS])

You can be notified of incoming outside calls through an external speaker. These calls can be answered from any extension.

### Through an external speaker



- You can also receive a paging announcement via a speaker with this operation.

## 1.3.5 Using the Answer/Release Button


The Answer and Release buttons are convenient for operators using headsets. With the Answer button, you can answer all incoming calls. With the Release button, you can disconnect the line during or after a conversation, or complete transferring a call.



### To answer




### To transfer a call



### To talk to a waiting caller



#### To transfer an outside call to an extension with a one-touch operation



#### To end a conversation



#### Customising Your Phone


- 3.1.3 Customising the Buttons  
Create or edit an Answer button or a Release button.

## 1.3.6 Identifying Malicious Calling Parties (Malicious Call Identification [MCID])

You can ask your telephone company to trace a malicious calling party during a conversation or after the calling party hangs up.

You will receive the information on the malicious call later on.

### To request MCID



- Availability of this feature depends on the ISDN service of your telephone company.

## 1.4 During a Conversation

### 1.4.1 Transferring a Call (Call Transfer)



- ♦♦ Transferring to an Extension in the PBX
- ♦♦ Transferring to an Outside Party Using the PBX Service
- ♦♦ Transferring a Call Using the ISDN Service (Call Transfer [CT]—by ISDN)



- You can transfer a held call without talking, and go on-hook even if the transferred party does not answer the call.  
If a transferred call is not answered within a specified time, it will ring at a preprogrammed extension, if set, or at your extension again. If you are off-hook at that time, you will hear an alarm tone. If an outside call is not answered within a specified time, it is automatically disconnected.

#### ♦♦ Transferring to an Extension in the PBX

To transfer




- When you are not at your desk or not in the office and receive a forwarded outside call, for example on your cellular phone, it is possible to transfer the call to an extension in the PBX by pressing # + desired extension number (if enabled through system programming).



- For the transfer operation using an SDN button, refer to "1.5.1 Primary Directory Number (PDN)/Secondary Directory Number (SDN) Extension".


### To transfer with one touch (One-touch Transfer)




- System programming is required to use the One-touch Transfer feature during a conversation with an extension.

## ◆◆ Transferring to an Outside Party Using the PBX Service

Some extensions may be restricted from performing this feature.



1.4.1 Transferring a Call (Call Transfer)





- **Time limit**  
Both the caller and the transferred party will hear an alarm tone fifteen seconds before a specified time period, and the call will be disconnected.
- **To return to the held call before the destination answers**, press the TRANSFER button, corresponding CO, ICD Group or INTERCOM button, or the hookswitch.




**Customising Your Phone**

- 3.1.3 Customising the Buttons  
Create or edit a Direct Station Selection (DSS) button.

◆◆ **Transferring a Call Using the ISDN Service (Call Transfer [CT]—by ISDN)**





- To retrieve the held call, press the TRANSFER button, Recall/hookswitch.
- Even if you go on-hook while transferring a call, it is transferred.
- After the call is transferred, the line becomes idle.



### Customising Your Phone

- 3.1.3 Customising the Buttons  
Create or edit an ISDN-Hold button.



# 1.4.2 Holding a Call

- ♦♦ Holding
- ♦♦ Holding in a System Parking Zone (Call Park)

## ♦♦ Holding

There are two types of hold. The difference between them is that other people can retrieve your held call (Regular Hold) or not (Exclusive Call Hold). As they can be alternated, ask your manager what the current mode is.

### To hold (Call Hold)

PT/PS

During a conversation

TRANSFER

C.Tone

\*

5

0

OR

HOLD

C.Tone

\*

5

0

C.Tone

On-hook.

Press **HOLD**, or press **TRANSFER** and then enter **\*50**.

SLT

During a conversation

Recall/hookswitch


Enter \*50.

C.Tone

On-hook.

Press **Recall/hookswitch**.

## To retrieve a call (Call Hold Retrieve)



- The CO or INTERCOM button light shows the current status as follows:
  - Regular Hold mode
    - Flashing green slowly:** Your held call
    - Flashing red:** Another extension's held call
  - Exclusive Call Hold mode
    - Flashing green moderately:** Your held call
    - Red on:** Another extension's held call
- If a call is not retrieved within a specified time**, you will hear an alarm as a reminder (Hold Recall).  
If an outside call is not answered within a specified time, it is automatically disconnected.
- Hold Mode Change (PT only)**  
After pressing the HOLD button, if you press the HOLD button again, the status switches from the Regular Hold mode to the Exclusive Call Hold mode or from the Exclusive Call Hold mode to the Regular Hold mode.

1.4.2 Holding a Call



- If **Automatic Call Hold** has been preprogrammed, you can put the current call on hold automatically by pressing another CO, ICD Group or INTERCOM button to make or answer another call.
- For the Call Hold Retrieve operation using a PDN/SDN button, refer to "1.5.1 Primary Directory Number (PDN)/Secondary Directory Number (SDN) Extension".

◆◆ **Holding in a System Parking Zone (Call Park)**

You can put a call on hold in a common parking zone of the PBX so that any extension can retrieve the parked call. You can use this feature as a transferring feature.

A call can be put into either a specified parking zone (Specified) or any idle parking zone (Auto). If a Call Park button and Call Park (Automatic Park Zone) button have been established, you can select either way to park by simply pressing the corresponding button.

When a call is parked automatically, or more than one call has been parked at the same time, you need to specify the parking zone number to retrieve the required call.

**To set**

PT/PS

*During a conversation*  
  
(Call Park)  
  
Press **Call Park**.

PT/PS

*During a conversation*  
 ►    ► 

parking zone no.

Specified


OR

Auto





   
Press **TRANSFER**.      Enter **\*52**.  
  
Enter a specified **parking zone number** (2 digits) or press **\*** to park at an idle parking zone automatically.  
  

If you hear a busy tone, enter another parking zone number or press **\*** again.



### To retrieve (Call Park Retrieve)



- If a call is parked automatically, confirm the parking zone number on the display.
- **If a call is not retrieved within a specified time**, you will hear an alarm as a reminder (Call Park Recall).  
If an outside call is not answered within a specified time, it is automatically disconnected.



- **If you hear a reorder tone when retrieving a parked call**, there is no held call. Confirm the stored parking zone number.
- After you park a call, you can perform other operations.





### Customising Your Phone

- 3.1.3 Customising the Buttons  
Create or edit a Call Park button or Call Park (Automatic Park Zone) button.


### 1.4.3 Talking to Two Parties Alternately (Call Splitting)


When talking to one party while the other party is on hold, you can swap the calls back and forth (alternately).

To alternate between the parties leaving one party on hold temporarily



To leave the conversation and then let the two parties talk





# 1.4.4 Answering Call Waiting


- ♦♦ Answering Call Waiting in the PBX
- ♦♦ Answering Call Waiting from the Telephone Company

## ♦♦ Answering Call Waiting in the PBX


During a conversation, a call waiting tone or voice announcement through the speaker or the handset occurs when an outside call has been received or another extension is letting you know a call is waiting. You must activate this feature to use it. (Default: Disable—No call [Intercom calls]/No tone [Outside calls])


**You can answer the second call by disconnecting (1) or holding (2) the current call.**

### 1. To disconnect the current call and then talk to the new party





### 2. To hold the current call and then talk to the new party





After talking to the new party (second call), you can disconnect (2.1) or hold (2.2) it and then retrieve the first call.


**2.1 To disconnect the second call and then talk to the original party**






2.2 To hold the second call and then talk to the original party

After holding it, you can talk to the original party. Then, you can disconnect it and then talk to the new party again.






- Depending on the type of your telephone, you may be able to talk to the other party using the speaker and the microphone (Off-hook Call Announcement [OHCA]), or you can receive an announcement through the handset (Whisper OHCA), if you are having a conversation using the handset.  
Refer to "1.8.3 Receiving Call Waiting (Call Waiting/Off-hook Call Announcement [OHCA]/Whisper OHCA)".
- The caller's name or number is displayed for five seconds in fifteen second intervals while waiting to be answered.




### Customising Your Phone

- 3.1.2 Settings on the Programming Mode—**Call Waiting Tone Type Selection**  
If you select "Tone 1", you will hear the same tone for Call Waiting from an outside party and an extension. If you select "Tone 2", you will hear different tones for Call Waiting from an outside party and an extension.



## ◆◆ Answering Call Waiting from the Telephone Company

This is an optional telephone company service. You can receive a call waiting tone and the caller's information. For details, consult your telephone company.



- **To return to the original party**, repeat the operation.
- In this case, the FLASH/RECALL button on proprietary telephones must be set to External Feature Access (EFA) mode through system programming.



## Customising Your Phone

- 3.1.3 Customising the Buttons  
Create or edit an External Feature Access (EFA) button.



## 1.4.5 Multiple Party Conversation

- ◆◆ Adding Other Parties during a Conversation (Conference)
- ◆◆ Leaving a Conference (Unattended Conference)
- ◆◆ Leaving a Conference (Leaving Three-party Conference)
- ◆◆ Letting a Third Party Join Your Call (Privacy Release)
- ◆◆ Adding a Third Party during a Conversation Using the ISDN Service (Three-party Conference [3PTY] —by ISDN)


### ◆◆ Adding Other Parties during a Conversation (Conference)

You can add one or more parties to your conversation.


To establish a conference call




1.4.5 Multiple Party Conversation




**To establish a conference call when receiving a call from an outside party during a two-party conversation**




### To add four or more parties to a conference




### To add another party on hold to a conference




### To talk to two parties alternately in a three-party conversation



### 1.4.5 Multiple Party Conversation



#### To disconnect one party and then talk to the other in a three-party conversation



- \* In this case, the FLASH/RECALL button on a proprietary telephone must be set to Flash/ Recall mode through system programming.
- During a three-party conversation, pressing the TRANSFER button or Recall/hookswitch alternates between the other parties in the conversation.
- You can have a conference with a maximum of eight parties (comprising intercom or outside lines) simultaneously.
- During a conversation involving four or more parties, you cannot disconnect one party and maintain the conversation with the other parties.




#### Customising Your Phone

- 3.1.3 Customising the Buttons  
Create or edit a Conference button.

### ◆◆ Leaving a Conference (Unattended Conference)

The person who originated a conference can leave the conference, and allow the other parties to continue the conversation.



**To leave a conference****To return while others are talking****To complete a conversation**

- **Time limit**

Both parties will hear an alarm tone before a specified timeout. The originating extension user will hear an alarm tone before timeout. The call is disconnected when the timer runs out unless the originating extension returns to the conference.



- **Customising Your Phone**

- 3.1.3 Customising the Buttons  
Create or edit a Conference button.

## ◆◆ Leaving a Conference (Leaving Three-party Conference)

The person who originated a conference with two other parties can leave the conference, and allow the other parties to continue the conversation.



### To leave a conference involving at least one other extension

#### PT/SLT/PS

*During a three-party conference*



On-hook.

### To leave a conference involving two outside parties

#### PT/PS

*During a three-party conference*



Press **TRANSFER**.



On-hook.

#### SLT

*During a three-party conference*



Press **Recall/hookswitch**.



On-hook.




- To leave a conference call involving two outside parties and have the conversation continue, your extension must be enabled to transfer calls to outside lines through COS programming.

## ◆◆ Letting a Third Party Join Your Call (Privacy Release)

You can let a third party join your current outside call and establish a three-party conversation. You can also leave the conversation and then let the two other parties talk.




To let a third party join your conversation and establish a three-party conversation





- Only an S-CO button can be used for this operation.
- You can leave a three-party conversation and let the two other parties talk by simply going on-hook.

## ◆◆ Adding a Third Party during a Conversation Using the ISDN Service (Three-party Conference [3PTY]—by ISDN)



1.4.5 Multiple Party Conversation



**To complete a conversation****PT/SLT/PS***During a conversation*

On-hook.

**Customising Your Phone**


- 3.1.3 Customising the Buttons  
Create or edit an ISDN-Hold button.

## 1.4.6 Mute

You can disable the microphone or the handset to consult privately with others in the room while listening to the other party on the phone through the speaker or the handset.



### To set/cancel




- The AUTO ANS/MUTE button light shows the current status as follows:  
**Off:** Normal  
**Flashing red:** Mute
- If mute is used during OHCA, it will become Handset Mute.

## 1.4.7 Letting Other People Listen to the Conversation (Off-hook Monitor)

You can let other people in the room listen to the conversation through the speaker while continuing the conversation using the handset.



### To set/cancel



- The SP-PHONE button light shows the current status as follows:  
**Off:** The voice is heard through the handset.  
**On:** The voice is heard through the speaker and the handset.
- This feature is only available with certain proprietary telephones, and requires system programming.



- Hands-free operation**  
 You can have a conversation in hands-free mode using the SP-PHONE button. You can perform other tasks simultaneously
- Helpful hints for hands-free operation:**
  - If it is difficult to hear the other party's voice,**  
 Increase the volume using the Navigator Key or Volume Key
  - If the other party has difficulty hearing you,**  
 Decrease the volume.
  - If the other party reports that your voice echoes,**  
 Use the telephone in a room that has curtains, carpeting or both.
  - If parts of the conversation cannot be heard,**  
 If you and the other party speak at the same time, parts of your conversation may be lost. To avoid this, try to speak alternately.

### 1.4.8 Using the Headset (Headset Operation)


You can have a conversation using a headset.

In this case, you must select "Headset on" in programming mode or set the Headset button on (red) in advance.

This feature is also known as Handset/Headset Selection.



#### To talk using the headset



#### To use the handset during a conversation using the headset



#### To talk in hands-free mode during a conversation using the headset



- The Headset button light shows the current status as follows:  
**Off:** Headset mode off  
**Red on:** Headset mode on
- This feature is not available for the KX-T7665.



- **For KX-NT300 series (except KX-NT321)/KX-DT343/KX-DT346 telephone users:**
  - With the KX-NT300 series (except KX-NT321)/KX-DT343/KX-DT346 telephones, you can use a Bluetooth wireless headset registered on your extension as a headset.
  - **Operating Distance**  
Please keep the telephones with connected Bluetooth Modules, 3 m or more apart from each other. Also, if a Bluetooth headset is in use near a telephone with a connected Bluetooth Module, other than the one it is registered to, noise may be heard. Move away from the telephone and closer to the one it is registered to, to improve the signal.
  - **Noise**  
Signals are transmitted between this module and the Bluetooth headset using radio waves. For maximum distance and noise free operation, it is recommended that the module is situated away from electrical appliances such as faxes, radios, PCs, or microwaves.
    - Systems using the 2.4 GHz ISM (Industrial, Scientific and Medical) band may interfere with this product. Examples of such systems are cordless telephones, wireless LAN, Home RF, microwave ovens and other ISM devices. These systems may cause minor noise.



### Customising Your Phone

- 3.1.2 Settings on the Programming Mode—**Headset Operation**  
Select the equipment to use.
- 3.1.3 Customising the Buttons  
Create or edit a Headset button.



## 1.5 Using a PDN/SDN Button

### 1.5.1 Primary Directory Number (PDN)/Secondary Directory Number (SDN) Extension

Primary Directory Number (PDN) buttons and Secondary Directory Number (SDN) buttons are useful when extension users will handle calls for other extensions. For example, a secretary or multiple secretaries can handle calls and check the call status of a boss or multiple bosses. The functions of PDN and SDN buttons are as follows:



**PDN button:** This button can be used to make and receive all calls (including both outside and intercom calls). Having multiple PDN buttons allows multiple calls to be queued at the extension. Extensions that have a PDN button are called PDN extensions.

**SDN button:** The light of an SDN button displays the current call status of the registered extension, similar to a DSS button. In addition, this button can be used to perform the following operations:

- call the PDN extension (◆◆ SDN Direct Dial)
- answer calls ringing at the PDN extension
- hold calls and retrieve calls held by the PDN extension (◆◆ Call Hold and Call Hold Retrieve)
- transfer calls to the PDN extension (◆◆ Call Transfer Using SDN Button)

Extensions that have an SDN button are called SDN extensions.



- The extension that is registered as the destination of an SDN button must have at least one PDN button.
- One extension can have up to 8 PDN buttons.
- An extension can have only one SDN button for each PDN extension.
- A PDN extension can only receive OHCA or Whisper OHCA from the corresponding SDN extension. When a call is made from another extension, a PDN extension will receive a call waiting tone.
- The button light of each PDN/SDN button shows the current status as follows:

| Light Pattern                    | PDN Button Status                                        | SDN Button Status                                                                                         |
|----------------------------------|----------------------------------------------------------|-----------------------------------------------------------------------------------------------------------|
| <b>Off</b>                       | The PDN extension is idle.                               |                                                                                                           |
| <b>Green on</b>                  | The extension is on a call using the PDN button.         | The extension is on a call using an SDN button.                                                           |
| <b>Flashing green slowly</b>     | A call is on hold at the PDN extension (Regular Hold).   | A call answered with the SDN button is on hold (Regular Hold).                                            |
| <b>Flashing green moderately</b> | A call is on hold temporarily or on Exclusive Call Hold. | A call answered with the SDN button is on hold temporarily or on Exclusive Call Hold.                     |
| <b>Flashing green rapidly</b>    | The PDN extension is receiving an incoming call.         | An SDN extension is receiving a Hold Recall or callback ringing from a call answered with the SDN button. |
| <b>Red on</b>                    | A corresponding SDN extension is using the line.         | The corresponding PDN extension or another corresponding SDN extension is using the line.                 |

| Light Pattern               | PDN Button Status                                                                             | SDN Button Status                                                                    |
|-----------------------------|-----------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------|
| <b>Flashing red slowly</b>  | A corresponding SDN extension is holding a call.                                              | Another corresponding SDN extension, or the PDN extension itself, is holding a call. |
| <b>Flashing red rapidly</b> | The PDN extension is receiving an incoming call to an incoming call distribution (ICD) group. | The corresponding PDN extension is receiving an incoming call.                       |


## ◆◆ SDN Direct Dial

Using an SDN button, you can easily call the corresponding PDN extension. SDN buttons are in one of two modes depending on system programming, and the operation procedure differs as follows:

### Enhanced DSS Key Mode



### Standard SDN Key Mode



- When performing SDN Direct Dial to call the corresponding PDN extension, the SDN button light shows the current status of the destination extension as follows:  
**Green on:** You are using the line.  
**Red on:** The line is being used. (The PDN extension, or another SDN extension when multiple extensions have SDN buttons to a same PDN extension, is using the line.)
- Even if a PDN extension has set Do Not Disturb (DND), you can call the extension as normal by pressing the SDN button.




- When an SDN button is in Standard SDN Key Mode, you can dial a telephone number while hearing a dial tone, instead of pressing the SDN button again. Depending on system programming, your call will be made using either your normal calling privileges (Class of Service) or those of the corresponding PDN extension (**SDN Walking COS**).

◆◆ **Call Hold and Call Hold Retrieve**

You can put calls answered with a PDN or SDN button on hold normally (1.4.2 Holding a Call). You can also retrieve a call held at your extension/another extension with a simple operation, regardless of the call type.

**Call Hold Retrieve**



- **If a call is not retrieved within a specified time**, you will hear an alarm as a reminder (Hold Recall).  
If an outside call is not answered within a specified time, it is automatically disconnected.




- If **Automatic Call Hold** has been preprogrammed, you can put the current call on hold automatically by pressing another PDN button to make or answer another call.

## ◆◆ Call Transfer Using SDN Button

You can transfer a call to a PDN extension with a simple operation using a corresponding SDN button.

### To transfer a call to a PDN extension



- System programming is required to use this feature during a conversation with an extension.
- \* When an SDN button is in Standard SDN Key Mode, you have to press the SDN button twice to transfer the call, unless you used that SDN button to answer an incoming call.



### Customising Your Phone

- 3.1.2 Settings on the Programming Mode—**Preferred Line Assignment—Incoming**  
Select the seized line when going off-hook.
- 3.1.2 Settings on the Programming Mode—**Preferred Line Assignment—Outgoing**  
Select the seized line when going off-hook.
- 3.1.3 Customising the Buttons  
Create or edit a Primary Directory Number (PDN) or Secondary Directory Number (SDN) button.

## 1.6 Before Leaving Your Desk

### 1.6.1 Forwarding Calls

- ◆◆ Forwarding Your Calls (Call Forwarding [FWD])
- ◆◆ FWD/DND Settings Using Fixed FWD/DND Button
- ◆◆ Forwarding Your Calls Using ISDN Service (Call Forwarding [CF]—by ISDN)

#### ◆◆ Forwarding Your Calls (Call Forwarding [FWD])

You can have your incoming calls forwarded to a specified destination.

##### All Calls:

All calls are forwarded. Preset extensions may also forward from their own receiving group.

##### Busy:

All calls are forwarded when your extension is busy.

##### No Answer:


All calls are forwarded when you do not answer the call within a specified time period.

##### Busy/No Answer (BSY/NA):

All calls are forwarded when you do not answer within a specified time period or when your extension is busy.

##### Follow Me (From):

If you fail to set the above-mentioned "All Calls" to forward before you leave your desk, you can set the same feature from the destination extension.




- Incoming calls can be forwarded up to four times.




- You can set the floating extension number of a voice mail group or the SVM card as a forward destination.
- You can set your cellular phone as the forward destination.
- **Boss & Secretary feature**  
The extension which has been set as the destination can call the forwarding extension.


<Example>



### To set/cancel




### To set Follow Me from another extension




- When using a proprietary telephone, you can set or cancel Call Forwarding by pressing the FWD/DND button (fixed button) instead of "✖710".

To set the timer for "No Answer" and "Busy/No Answer"



To set/cancel (Call Forwarding [FWD] for your Incoming Call Distribution Group)





- The FWD/DND button light shows the current status as follows:  
**Off:** Both features are not set.  
**Red on:** FWD mode  
**Flashing red slowly:** DND mode
- The Group FWD button light shows the current status as follows:  
**Off:** No set  
**Red on:** FWD mode
- The system has two modes: (1) FWD/DND Cycle Switch Mode and (2) FWD/DND Setting Mode. Ask your manager what mode your system is in if you are not sure.

#### (1) When in FWD/DND Cycle Switch Mode:

Pressing the FWD/DND button (fixed button) while in idle status will cycle the setting as shown below:



#### (2) When in FWD/DND Setting Mode:

Pressing the FWD/DND button (fixed button) while in idle status allows you to switch the FWD/DND status and set the FWD destination (refer to "◆◆ FWD/DND Settings Using Fixed FWD/DND Button").

#### Note

A FWD/DND button (customised button) is always in FWD/DND Cycle Switch Mode: the mode cannot be changed.

- Transferred outside calls are also forwarded to the destination assigned for outside calls.
- When intercom calls are set to be handled differently from outside calls (forwarding type, forward destination), we recommend establishing buttons for both FWD/DND—Outside calls and FWD/DND—Intercom calls, and/or Group FWD—Outside calls and Group FWD—Intercom calls, because:
  - the light patterns of the FWD/DND—Both calls button (including FWD/DND button [fixed button]) and the Group FWD—Both calls button will indicate the setting for either outside calls or intercom calls, but not both.

#### Note

The FWD icon on PS display reflects the setting for outside calls only.

- pressing the FWD/DND—Both calls button (including FWD/DND button [fixed button]) or the Group FWD—Both calls button will not change the FWD or DND mode for intercom calls and outside calls separately.



### Customising Your Phone

- 3.1.3 Customising the Buttons  
 Create or edit FWD/DND (Both calls, Outside calls, Intercom calls) buttons, or Group FWD (Both calls, Outside calls, Intercom calls) buttons.



### ◆◆ FWD/DND Settings Using Fixed FWD/DND Button


Using a proprietary telephone (PT), you can easily switch the FWD/DND status, and set the forward destination for outside/intercom calls with the FWD/DND button (fixed button). It is also possible to set outside telephone numbers (e.g., your cellular phone) as forward destinations for up to 4 Virtual PSs\* in an Incoming Call Distribution (ICD) Group, to ring together with other ICD Group members for calls to the group. The following settings are available:




- Switching the FWD/DND status and setting FWD destination for outside/intercom calls
- Timer for "No Answer" and "Busy/No Answer"
- Forwarding status (on/off) and outside destinations to ring in parallel for outside calls for up to 4 virtual PSs in an ICD Group

#### \* Virtual PS


A virtual PS is a dedicated extension number assigned to a non-existent portable station (PS) to allow access to outside destinations such as a cellular phone.



#### To switch FWD/DND status for outside calls




#### To switch FWD/DND status for intercom calls






- When you switch the FWD/DND status, any FWD destination that was set previously is not cleared.

### To set and clear FWD/DND for outside/intercom calls



- \* This step can be omitted.

### To set the timer for "No Answer" and "Busy/No Answer"




## 1.6.1 Forwarding Calls



- \* You can enter the time as a 1–3 digit number. For example, 15 seconds can be entered as "15" or "015".

### To set forwarding status and outside destinations to ring in parallel for outside calls to an ICD Group




- Only one extension assigned as member 1 in each ICD group can perform the settings for virtual PSs.
- It is possible to switch the forwarding status (on/off) of a virtual PS by entering the number (4–7) of that extension, then pressing the fixed FWD/DND button, instead of pressing the AUTO DIAL/STORE button.

## ◆◆ Forwarding Your Calls Using ISDN Service (Call Forwarding [CF]—by ISDN)


All calls are forwarded to an outside party using ISDN. The following types of call forwarding are provided by the ISDN service.

- Unconditional (**Call Forwarding Unconditional [CFU]**)
- When your extension is busy (**Call Forwarding Busy [CFB]**)
- When you do not answer (**Call Forwarding No Reply [CFNR]**)


### To set



### To cancel



### To confirm the condition



# 1.6.2 Using Voice Messaging (Built-in Simplified Voice Message [SVM])

Your PBX can provide you with answering machine service if an SVM card is installed. Your extension is assigned a message box, into which callers can leave voice messages for you. After callers reach your message box, they will hear your personal greeting message. You can record two kinds of personal greetings: a normal greeting message and a greeting message for each time mode. You can also play back and clear your greeting messages and the voice messages left by callers.

- ◆◆ Recording a Normal Greeting Message
- ◆◆ Recording a Greeting Message for Each Time Mode
- ◆◆ Redirecting Your Calls to Your Message Box
- ◆◆ Leaving Voice Messages
- ◆◆ Listening to Voice Messages Left by Callers
- ◆◆ Accessing Your Message Box from an Outside Telephone
- ◆◆ Accessing the Message Box of Another Extension from Your Extension



- You may hear a busy tone when trying to access your message box if too many other users are already accessing their message boxes. In that case, wait a few minutes and try again.
- If the used recording space (including greeting messages and voice messages left by callers) for the SVM card reaches a certain limit, the display informs you that the recording space is almost full, and you will hear dial tone 3 when going off-hook.

## Dial Tone 3




- **Operation Reference When Accessing Your Message Box**  
After entering the SVM feature number (\*38), the operations below are available by entering the corresponding numbers.


| Operation No. | Operation                                                   |
|---------------|-------------------------------------------------------------|
| <b>0</b>      | To clear the normal greeting message                        |
| <b>1</b>      | To record a normal greeting message                         |
| <b>2</b>      | To play back the normal greeting message                    |
| <b>3</b>      | To listen to voice messages left by callers                 |
| <b>8</b>      | To set a greeting message for each time mode                |
| <b># 6</b>    | To leave a voice message to another extension's message box |

## ◆◆ Recording a Normal Greeting Message

To record




To play back



- \* This step can be omitted.


To clear




◆◆ Recording a Greeting Message for Each Time Mode

In addition to a normal greeting message, you can record a specific greeting message for each time mode (day/lunch/break/night).

To record




## To play back



- \* This step can be omitted.

## To clear




- If both the greeting message for a certain time mode and the normal greeting message have been recorded, callers will hear the greeting message for that time mode. However, if no greeting message has been recorded for a certain time mode, the normal greeting message will be played instead.



◆◆ Redirecting Your Calls to Your Message Box

You can set incoming calls to be redirected to your own message box so that callers can leave voice messages when you cannot answer the phone.

To set/cancel




- The default floating extension numbers are 591 for SVM card 1, and 592 for SVM card 2.

## ◆◆ Leaving Voice Messages

If the extension user you called is not able to answer your call, and your call is redirected to the message box, you will hear the greeting message. Then, you can leave a voice message for that extension. It is also possible to leave a voice message directly in the message box of a desired extension by following the steps below:

### To leave a voice message directly to another extension's message box



- Voice message recording will stop, you will hear a notification tone, and the call will be disconnected, in the following cases:
  - the recording time for the voice message reaches the preprogrammed limit. (default: 120 seconds)
  - the recording space for the SVM card reaches the limit.



- When you are on the phone, you can transfer the call directly to the message box of a desired extension by placing the call on hold temporarily, then pressing \*38 + #6 + the desired extension number. This allows the caller to leave a voice message in the message box of the desired extension.

◆◆ Listening to Voice Messages Left by Callers

When a caller leaves a voice message, information about that caller is also recorded as the SVM Log. The SVM Log can be viewed using the display of a PT or PS by pressing the Message button.

To listen to voice messages

PT/PS

While on-hook

 → 

Press **MESSAGE** until **desired SVM Log** appears.

Off-hook.

PT/SLT/PS

 →  → 

Off-hook.

Enter \*38.

Enter 3.

PT/SLT/PS

 →  OR 

Off-hook.

Press **MESSAGE** or enter \*702.

To clear the voice message that you are listening to

PT/SLT/PS

While hearing the voice message

 → 

Enter 3.

Press **STORE** or enter 1 to confirm.



- Various operations are available by entering numbers while you are listening to a recorded voice message using any of the methods described above. The available options are as follows:

| Operation No.                | Operations                                                                                                     |
|------------------------------|----------------------------------------------------------------------------------------------------------------|
| <b>1</b> / <b>#</b> <b>*</b> | To play back the voice message from the beginning                                                              |
| <b>2</b>                     | To go to the next voice message                                                                                |
| <b>3</b>                     | To clear the voice message<br>(Press the AUTO DIAL/STORE button or enter 1 to confirm.)                        |
| <b>4</b>                     | To call back the caller who left the voice message                                                             |
| <b>5</b>                     | To go back to the previous voice message                                                                       |
| <b>#</b> <b>6</b>            | To leave a voice message directly in the message box of another extension<br>(Enter desired extension number.) |
| <b>#</b> <b>8</b>            | To play back your greeting message and record a voice message in your own message box                          |
| <b>#</b> <b>9</b>            | To end the call                                                                                                |

- In addition to the caller information that is recorded in the Call Log, the following SVM Log information is recorded with voice messages left by callers:
  - Caller's Name
  - Caller's Telephone Number
  - Time recording started
  - Voice Message Status
    - "New" is displayed for voice messages that have not previously been listened to.
    - "Old" is displayed for voice messages that have previously been listened to.


Please note that the information shown on the display may vary depending on the information that was received and the type of telephone used. Only users of a 6-line display PT can view all of the above information.

- You can lock the SVM Log display by using an extension PIN (Personal Identification Number) to prevent other users from viewing the information and from playing back your voice messages (Display Lock). Refer to "3.1.2 Settings on the Programming Mode".
- If your telephone has a Message for Another Extension button, you can access the message box of another extension and listen to voice messages for that extension.
- If a new voice message has been left in your message box, you will hear dial tone 4 after going off-hook. In addition, if your telephone has a Message button or Message/Ringer Lamp, the corresponding button or lamp will light when a voice message has been left.

#### Dial Tone 4




To listen to voice messages while your display is locked




- When you press the Message button while on-hook to play back voice messages, Display Lock is temporarily deactivated.

To clear voice messages from the SVM Log




## ◆◆ Accessing Your Message Box from an Outside Telephone

You can remotely access your message box and perform any operations of the SVM feature through an outside line as if you were at your own extension.




- If you hear a reorder tone when you try to leave a voice message directly in the message box of another extension, that message box is unavailable. You can enter another extension number by pressing "\*".
- When accessing your message box from an outside telephone, you cannot call back callers who have left voice messages, by pressing 4 while hearing the voice message.

### To listen to voice messages left in the message box of another extension



◆◆ Accessing the Message Box of Another Extension from Your Extension

You can access the message box of another extension (for example, to record a greeting message for that extension) by following the steps below:




## 1.6.3 Showing a Message on the Caller's Telephone Display (Absent Message)


You can show the reason you do not answer, if the caller uses a Panasonic display proprietary telephone. There are eight preprogrammed messages and one for your personal message (16 characters). The selected message is shown on the display of your telephone.

| Message no. | Message (Example)                                                   |
|-------------|---------------------------------------------------------------------|
| 1           | Will Return Soon                                                    |
| 2           | Gone Home                                                           |
| 3           | At Ext %%% (Extension number)                                       |
| 4           | Back at %:%% (Hour:Minute)                                          |
| 5           | Out until %/%% (Month/Day)                                          |
| 6           | In a Meeting                                                        |
| 7           |                                                                     |
| 8           |                                                                     |
| 9           | A message assigned for each extension.<br>(Personal Absent Message) |

To set



To cancel





### 1.6.3 Showing a Message on the Caller's Telephone Display (Absent Message)

---




- Enter the desired value in the "%" positions. You must enter the correct number of characters as represented by the "%" using 0 to 9 or ✕.
- The preprogrammed messages can be changed through system programming.
- To create your personal message (Message no. 9), refer to "3.1.2 Settings on the Programming Mode".


## 1.6.4 Preventing Other People from Using Your Telephone (Extension Dial Lock)

You can lock your extension so that other users cannot make unauthorised outside calls. This feature is also known as Electronic Station Lockout.

### To lock




### To unlock



- **If you forget the extension PIN or cannot unlock your extension**, consult your manager. He can clear your extension PIN. Then, you can set the new PIN and unlock your extension by entering it.
- If your extension is locked by this feature, it cannot perform features as follows:
  - Making outside calls
  - Changing the call forwarding destination
- If you do not set extension PIN, you cannot lock and unlock your extension.

### To make an outside call while your extension is locked



#### 1.6.4 Preventing Other People from Using Your Telephone (Extension Dial Lock)

---



- After you make an outside call, Extension Dial Lock is automatically activated again.

## 1.7 Making/Answering an Announcement


### 1.7.1 Paging

- ◆◆ Group Paging
- ◆◆ Paging and then Transferring a Call

#### ◆◆ Group Paging


You can make a voice announcement to proprietary telephones or external speakers or both in the preset group simultaneously.

To page



- If the group which you paged is already being used for paging, you hear a busy tone.

#### ◆◆ Paging and then Transferring a Call



### 1.7.1 Paging


---




- After you go on-hook, the caller can talk to the person who answers the page.

## 1.7.2 Answering/Denying a Paging Announcement

To answer



To allow/deny a paging announcement (Paging Deny)




- The following are extensions that cannot receive a paging announcement:
  - Portable station
  - Single line telephone
  - Proprietary telephone that is ringing or busy
  - Proprietary telephone in Paging Deny mode
  - Proprietary telephone in DND mode
- Even if the announcement is not paging your extension, you can answer it, if it is paging your group.

### 1.7.3 Making an Announcement and Having a Multiple Party Conversation (Broadcasting)


You can call multiple parties assigned in the group and make a voice announcement. You can also establish a multiple party conversation with called parties. This conversation will be heard by other called parties. Called parties can listen to the announcement simply by going off-hook. They can send a notification tone if they want to join the conversation.

#### To make/answer a broadcasting call




#### ◆ For a caller

#### To make a conversation with a specific party



#### To make a conversation with a party in the group's preassigned order



#### To end a conversation with a specific party

PT

*During a conversation*

- **To end a conversation with a specific party**



(DSS)

Press **DSS**.
- **To end a conversation with the party who joined the conversation last**



TRANSFER

Press **TRANSFER**.
- **To disconnect the party who joined the conversation last from the broadcast**



FLASH/RECALL

Press **FLASH/RECALL**.




- In this case, the FLASH/RECALL button must be set to Flash/Recall mode through system programming.



◆ For a called extension

To send a notification tone to the caller and join a conversation




- A conversation can be established with a maximum of 4 parties (including the caller).

# 1.8 Setting the Telephone According to Your Needs

## 1.8.1 Setting the Alarm (Timed Reminder)


You can receive an alarm at your telephone to remind you of a meeting, appointment or as a wake-up call. The alarm can occur either once or daily (every day until cancelled) at a preset time. When you go off-hook to answer, you will hear a special dial tone or prerecorded message.

### To set




- \* Enter the time in the format assigned to your PBX (12-hour or 24-hour).

### To cancel



### To stop or answer the ringback



### 1.8.1 Setting the Alarm (Timed Reminder)

---

#### To confirm



- You can also confirm the Timed Reminder by using the soft button.
- The alarm keeps ringing for preprogrammed seconds.
- **If you receive an incoming call during ringback**, the ringing starts after the ringback stops.
- **If you are having a conversation exceeding alarm ringing period**, the ringback will start after your conversation.


## 1.8.2 Refusing Incoming Calls (Do Not Disturb [DND])

- ◆◆ Do Not Disturb (DND)
- ◆◆ Switching FWD/DND Status Using Fixed FWD/DND Button

### ◆◆ Do Not Disturb (DND)

You can set this feature to prevent incoming calls from ringing at your extension. This can be useful, for example, when you are in a meeting or busy.

#### To set/cancel



- When using a proprietary telephone, you can set or cancel Do Not Disturb by pressing the FWD/DND button (fixed button) instead of "\*710".



- The FWD/DND button light shows the current status as follows:  
**Off:** Both features are not set.  
**Red on:** FWD mode  
**Flashing red slowly:** DND mode
- The system has two modes: (1) FWD/DND Cycle Switch Mode and (2) FWD/DND Setting Mode. Ask your manager what mode your system is in if you are not sure.

### (1) When in FWD/DND Cycle Switch Mode:

Pressing the FWD/DND button (fixed button) while in idle status will cycle the setting as shown below:



### (2) When in FWD/DND Setting Mode:

Pressing the FWD/DND button (fixed button) while in idle status allows you to switch the FWD/DND status and set the FWD destination (refer to "◆◆ Switching FWD/DND Status Using Fixed FWD/DND Button").

#### Note

A FWD/DND button (customised button) is always in FWD/DND Cycle Switch Mode: the mode cannot be changed.

- If your extension has set this feature, a calling extension will hear DND tone.
- If this feature is set, the Call Forwarding (FWD) feature does not work.
- Specified extensions can override this feature and call DND extensions (DND Override).
- When making a call using an SDN button to a PDN extension with DND set, this feature will temporarily be deactivated.
- When intercom calls are set to be handled differently from outside calls (DND set/cancel), we recommend establishing buttons for both FWD/DND—Outside calls and FWD/DND—Intercom calls, because:
  - a. the light patterns of the FWD/DND—Both calls button (including FWD/DND button [fixed button]) will indicate the setting for either outside calls or intercoms calls, but not both.

#### Note

The DND icon on PS display reflects the setting for outside calls only.

- b. pressing the FWD/DND—Both calls button (including FWD/DND button [fixed button]) will not change the FWD or DND mode for intercom calls and outside calls separately.



## Customising Your Phone


- 3.1.3 Customising the Buttons  
Create or edit FWD/DND (Both calls, Outside calls, Intercom calls) buttons.

## ◆◆ Switching FWD/DND Status Using Fixed FWD/DND Button


Using a proprietary telephone (PT), you can easily switch the FWD/DND status for outside/intercom calls without clearing any FWD destination that was set previously.




### To switch the FWD/DND status for outside calls



### To switch the FWD/DND status for intercom calls



### To set and clear FWD/DND for outside/intercom calls



### 1.8.2 Refusing Incoming Calls (Do Not Disturb [DND])

---



- \* This step can be omitted.

## 1.8.3 Receiving Call Waiting (Call Waiting/Off-hook Call Announcement [OHCA]/Whisper OHCA)

During a conversation, you can be informed of a call waiting with a tone or voice announcement through your built-in speaker or handset. (Default: Disable—No call [Intercom calls]/No tone [Outside calls])

### Call Waiting Tone:

a waiting tone through the built-in speaker of PT/handset of SLT. To change the tone from PT, refer to "3.1.2 Settings on the Programming Mode".


### OHCA:

a voice announcement through the built-in speaker


### Whisper OHCA:

a voice announcement through the handset

### To set/cancel for intercom calls (Manual Call Waiting)



### To set/cancel for outside calls (Automatic Call Waiting)



- OHCA is only available with certain digital proprietary telephones.
- Whisper OHCA is only available with certain digital proprietary telephones and IP proprietary telephones. In addition, both you and the other party must use supported telephones.
- A PDN extension can only receive OHCA or Whisper OHCA from the corresponding SDN extension. When a call is made from another extension, a PDN extension will receive a call waiting tone. (→1.5.1 Primary Directory Number (PDN)/Secondary Directory Number (SDN) Extension)



## 1.8.4 Displaying Your Telephone Number on the Called Party and Caller's Telephone (Calling/Connected Line Identification Presentation [CLIP/COLP])

### CLIP:

When making an outside call, you can present your preprogrammed telephone number to the called party.

### COLP:


When receiving an outside call, you can present your preprogrammed telephone number to the calling party.

You can select the telephone number sent, either the number of the line used or the number assigned to your extension.

If you select "Public", the calling/called party sees the number of the line used (subscriber's number).

If you select "Your extension", they see the telephone number assigned on your extension.

### To show either the number assigned to the outside line or your extension



- Availability of this feature depends on the ISDN service of your telephone company.




- If you use the ICD Group button to make a call to the other party, the telephone number assigned to the ICD Group will be used.

# 1.8.5 Preventing Your Telephone Number Being Displayed on the Caller's Telephone (Connected Line Identification Restriction [COLR])

When receiving an outside call, you can select whether the caller can see your telephone number or not.

To show/prevent



-  You can change the mode by pressing a preset COLR button while on-hook. The COLR button light shows the current status as follows:  
**Off:** shows your telephone number.  
**Red on:** prevents your telephone number being displayed.
- Availability of this feature depends on the ISDN service of your telephone company.


 Customising Your Phone

- 3.1.3 Customising the Buttons  
Create or edit a Connected Line Identification Restriction (COLR) button.

# 1.8.6 Preventing Your Number Being Displayed on the Called Party's Telephone (Calling Line Identification Restriction [CLIR])

When making an outside call, you can select whether the called party can see your telephone number or not.

## To show/prevent




- You can change the mode by pressing a preset CLIR button while on-hook.  
The CLIR button light shows the current status as follows:  
**Off:** shows your telephone number.  
**Red on:** prevents your telephone number being displayed.
- Availability of this feature depends on the ISDN service of your telephone company.



## Customising Your Phone

- 3.1.3 Customising the Buttons  
Create or edit a Calling Line Identification Restriction (CLIR) button.

## 1.8.7 Preventing Other People from Joining Your Conversation (Executive Busy Override Deny)




- Some extensions may be prohibited from performing this feature.

# 1.8.8 Turning on the Background Music (BGM)

You can listen to the background music through your telephone speaker while on-hook. An external music source, such as a radio, can be connected. If your extension becomes busy (off-hook, making or receiving a call etc.), the music stops temporarily. When you go back on-hook, the music starts again.




To select and set/cancel



## 1.8.9 Protecting Your Line against Notification Tones (Data Line Security)


You can protect the line against audible notification tones, such as a call waiting tone during a conversation. Set this feature if your extension has a data communication device, such as a PC or fax machine connected to ensure secure data transmission.

### To set/cancel



### 1.8.10 Checking the Time Service Status

You can check the current status of the Time Service on the display.



- The Time Service (Day/Night/Lunch/Break) button light shows the current status as follows:
  - Off:** Day mode
  - Green on:** Lunch mode
  - Flashing green:** Break mode
  - Red on:** Night mode
  - Flashing red:** Holiday mode
- Any extension user except the managers can check the current status by pressing the Time Service (Day/Night/Lunch/Break) button.



#### Customising Your Phone


- 3.1.3 Customising the Buttons
  - Create or edit a Time Service (Day/Night/Lunch/Break) button.

## 1.8.11 Using Your PS in Parallel with a Wired Telephone (Wireless XDP Parallel Mode)


Your PS can be used in parallel with a PT or SLT.

When in this mode, incoming calls to a wired telephone also ring the paired PS.

### To set



### To cancel



- Some wired telephones are prohibited from using this feature.
- **If you go off-hook while your paralleled telephone is in use**, the call will switch over to you.




## 1.8.12 Clearing Features Set at Your Extension (Extension Feature Clear)

You can reset the settings of the following features on your extension to the default settings with one operation.

This feature is also known as Station Programme Clear.

| Features                                                                                      | Default Setting                        |
|-----------------------------------------------------------------------------------------------|----------------------------------------|
| Hot Line <sup>*1</sup>                                                                        | Off                                    |
| Message Waiting—(All the messages that have been left by other extension users)               | Off                                    |
| Call Pickup Deny                                                                              | Allow                                  |
| Call Forwarding (FWD) <sup>*1</sup>                                                           | Off                                    |
| Absent Message                                                                                | Off                                    |
| Paging Deny                                                                                   | Allow                                  |
| Timed Reminder                                                                                | Cleared                                |
| Do Not Disturb (DND) <sup>*1</sup>                                                            | Off                                    |
| Call Waiting for intercom calls <sup>*1</sup><br>Call Waiting for outside calls <sup>*1</sup> | Disable (No call)<br>Disable (No tone) |
| Executive Busy Override Deny                                                                  | Allow                                  |
| BGM                                                                                           | Off                                    |
| Data Line Security                                                                            | Off                                    |
| Log-in/Log-out                                                                                | Log-in                                 |

<sup>\*1</sup> These features may not be reset depending on the system programming.




## 1.9 Utilising the Call Centre


### 1.9.1 Leaving an Incoming Call Distribution Group (Log-in/Log-out, Wrap-up)

You can control your status in an incoming call distribution group. When in the Log-out mode, incoming calls to the group will not ring at your extension. When you return, calls will again ring at your extension. (Default: Log-in) Even if your extension is logged-in, you can have a specified time period (wrap-up time) when you will not receive calls after completing a previous call. This time can be used for you to write a report and so on.

You can also manually select "Not Ready" mode to temporarily leave a distribution group.



#### To set Log-in/Log-out



1.9.1 Leaving an Incoming Call Distribution Group (Log-in/Log-out, Wrap-up)

PT/PS

ICD Group: Incoming Call Distribution Group

While on-hook

(Log-in/Log-out)

▶

ICD Group extension no.

Specified

OR

\*

All

Press **Log-in/Log-out**. Enter **ICD Group extension number** or **\***.

PT/PS

While on-hook

(Log-in/Log-out of a specified group)

Press **Log-in/Log-out of a specified group**.

To enter/leave Not Ready mode

PT/SLT/PS



▶

\*

7

3

5

▶

1 Not Ready

OR

0 Ready





Off-hook. Enter **\*735**. Enter **1** or **0**. C.Tone On-hook.

To set/cancel Not Ready mode or to leave Wrap-up mode (To enter Ready mode)

PT/PS

While on-hook

(Wrap-up)

Press red or flashing red **Wrap-up**.\*



- \* The status will be as follows:  
Ready → Not Ready  
Not Ready → Ready  
Wrap-up → Not Ready
- The Log-in/Log-out of a specified group button light shows the current status as follows:  
**Off:** Log-in mode  
**Red on:** Log-out mode
- The Wrap-up button alternates the setting of Wrap-up mode, Not Ready mode or Ready mode.  
The Wrap-up button light shows the current status as follows:  
**Off:** Ready mode  
**Red on:** Not Ready mode  
**Flashing red:** Wrap-up mode
- In Wrap-up mode/Not Ready mode, your extension does not receive calls through any group, even if it belongs to multiple groups.
- The last remaining logged-in extension may not be allowed to log out, depending on system programming.
- The Supervisor extension can control the Log-in/Log-out status of other extensions.  
For more information, refer to "1.9.2 Monitoring and Controlling the Call Status of an Incoming Call Distribution Group (Incoming Call Distribution Group Monitor)".




#### Customising Your Phone

- 3.1.3 Customising the Buttons  
Create or edit a Log-in/Log-out button, a Log-in/Log-out of a specified group button or a Wrap-up button.

## 1.9.2 Monitoring and Controlling the Call Status of an Incoming Call Distribution Group (Incoming Call Distribution Group Monitor)

- ♦♦ Monitoring the Status of Waiting Calls
- ♦♦ Monitoring and Changing the Log-in/Log-out Status of Extensions

The extension assigned as a Supervisor extension can monitor and control the status of other extensions in an incoming call distribution group. It should have a PT with 6-line display. The display and DSS buttons show as follows:



### ♦♦ Monitoring the Status of Waiting Calls

The Supervisor extension can monitor the status of calls waiting to be answered in the queue. If an incoming call distribution group has an overflowed call, the display shows the status automatically. The following information is displayed.


#### <Queuing Monitor>

- The current date/time
- The ICD Group extension number/name
- The number of waiting calls
- The longest waiting time

#### <Call Log History>

- The date/time when cleared at last time
- The total number of received calls
- The number of overflowed calls
- The number of unanswered calls
- The average waiting time of queuing calls

### To monitor



### To clear Call Log History




- The accumulated data is cleared.  
"\*\*\*\*\*" shows if the number to be displayed exceeds the maximum displayable digits.


## ◆◆ Monitoring and Changing the Log-in/Log-out Status of Extensions

The Supervisor extension can monitor the Log-in/Log-out status of the incoming call distribution group members by the DSS button light. It can also change their Log-in/Log-out status if needed.

### To monitor



### To change the Log-in /Log-out mode



- The DSS button light shows the current status as follows:  
**Off:** The extension is not in the group.  
**Green on:** Log-in (Ready) mode  
**Flashing green:** Log-in (Not Ready) mode  
**Red on:** Log-out mode

## 1.9.3 Forwarding a Waiting Call (Manual Queue Redirection)


When your incoming call distribution group is busy and other outside calls arrive, the arriving calls are put in a waiting queue.

Extensions can check the status of the queue with the Hurry-up button light, and forward the longest waiting call in the queue to a preset destination manually.

This feature is also known as Hurry-up Transfer.



### To forward the waiting call



- The Hurry-up button light shows the current status as follows:  
**Off:** No waiting call.  
**Red on:** Some calls are waiting.  
**Flashing red:** The number of calls exceeds the manual queue redirection level.



### Customising Your Phone

- 3.1.3 Customising the Buttons  
 Create or edit a Hurry-up button.



# 1.10 Using User-supplied Equipment


## 1.10.1 If a Doorphone/Door Opener is Connected

You can talk to a person at the door through the doorphone. Preprogrammed extensions or an outside party can receive the calls from the doorphone. You can open the door.


- ♦♦ Doorphone Call
- ♦♦ Opening a Door (Door Open)

### ♦♦ Doorphone Call


To call from the doorphone



To answer a call from the doorphone



To call the doorphone




- If no one answers a doorphone call within a specified time period, the call is cancelled.


## ◆◆ Opening a Door (Door Open)

Some extensions may be prohibited from using this feature.

### From a specified extension




### From any extension while talking to the doorphone



- The door open will be triggered for a specified time period.

### To switch on the relay




- 146 | User Manual

## 1.10.3 If an External Sensor is Connected

Preprogrammed extensions can receive an alert call from an external sensor (e.g., security alarm) connected to the PBX.

### To answer a sensor call



- If you do not answer a sensor call within a specified time period, the sensor call will stop.


# 1.10.4 If a Host PBX is Connected

- ♦♦ Accessing External Services (External Feature Access [EFA])

## ♦♦ Accessing External Services (External Feature Access [EFA])

You can access special features (e.g., Call Waiting) offered by a host PBX or telephone company. This feature is only effective for an outside call.

<Example> To hold the current call and then talk to the new party



- In this case, the FLASH/RECALL button on a proprietary telephone must be set to External Feature Access (EFA) mode through system programming.



### Customising Your Phone

- 3.1.3 Customising the Buttons  
Create or edit an External Feature Access (EFA) button.

## 1.10.5 If a Voice Processing System is Connected

You or an outside party can access the Voice Processing System from a telephone.

- ♦♦ Call Forwarding to Voice Mail (Voice Mail Integration)

If your PBX has a Panasonic Voice Processing System connected (e.g., KX-TVM series) using digital integration, the following features are also available:

- ♦♦ Screening Calls (Live Call Screening [LCS])
- ♦♦ Recording a Conversation

### ♦♦ Call Forwarding to Voice Mail (Voice Mail Integration)

- To forward your calls to your mailbox
- To transfer a call to a mailbox
- To listen to messages


If you cannot answer calls, you can forward them to your mailbox. You can select the type of incoming calls (Intercom Calls/Outside Calls/Both Calls) that are forwarded.

If your telephone has a Message button, the Message light turns on when a message is left in your mailbox. You will hear an indication tone\* when going off-hook, regardless of whether or not your telephone has a Message button.


You can also create a Voice Mail Transfer button on your phone to transfer received outside calls to a mailbox of another extension so that calling parties can leave messages (Voice Mail Transfer).

The duration for recording depends on the voice processing system.


#### To forward your calls to your mailbox



To transfer a call to a mailbox



To listen to messages



- \*Indication tone after going off-hook



- You can access a voice mail with one touch.



- The default voice mail floating extension number is 500.



**Customising Your Phone**

- 3.1.3 Customising the Buttons  
Create or edit a Voice Mail Transfer button or a Message button.

## ◆◆ Screening Calls (Live Call Screening [LCS])

While a caller is leaving a message in your mailbox, you can monitor the call without answering. If you so desire, you can answer the call while monitoring. There are two methods available (Default: Hands-free mode).



### Hands-free mode:

You can monitor the message automatically, live through the telephone speaker.

### Private mode:

You will hear an alarm tone while the caller is leaving a message.

### Before operating

- Create a Live Call Screening (LCS) button (Personal Programming).
- Select the mode, either Hands-free or Private (Personal Programming).
- Set the extension PIN (Personal Identification Number).
- Set the Live Call Screening feature.

### To set Live Call Screening

| PT/PS                                                                                                                                                              | PIN: Personal Identification Number                                                                               |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------|
| <div> <div> <div></div> <div>(Live Call Screening)</div> </div> <div>▶</div> <div> <div>extension PIN</div> </div> </div> <p>Press <b>Live Call Screening</b>.</p> | <p>Enter <b>extension PIN</b> (max. 10 digits).</p> <p>This is required only when an extension PIN is stored.</p> |


### To cancel Live Call Screening

| PT/PS                                                                                                               |
|---------------------------------------------------------------------------------------------------------------------|
| <div> <div> <div></div> <div>(Live Call Screening)</div> </div> </div> <p>Press red <b>Live Call Screening</b>.</p> |



## Operation Flowchart

The operations in the shaded areas can be done hands-free.



- The Live Call Screening (LCS) button light shows the feature status as follows:  
**Off:** LCS is off.  
**Flashing green rapidly:** Alerting in the Private mode.  
**Flashing green slowly:** Monitoring.  
**Red on:** LCS is on.
- The manager extension can clear an extension PIN.
- Only the handset monitoring in the Private mode is available for PS users.



### Customising Your Phone

- 3.1.2 Settings on the Programming Mode—**Live Call Screening Mode Set**  
 Select the mode, either monitoring the message through the speaker automatically or receiving, while the caller leaves a message.
- 3.1.3 Customising the Buttons  
 Create or edit a Live Call Screening (LCS) button.

## Recording a Conversation


You can record a conversation into a mailbox while talking on the phone.  
 You can select the mailbox each time you record a conversation.



**To record into your mailbox (Two-way Record)**

**PT/PS**

*During a conversation*




Press **Two-way Record**.

**To record into another mailbox (Two-way Transfer)**

**PT/PS**

*During a conversation*



Press **Two-way Transfer**.

Press **DSS** or enter **another extension number**.

To stop recording, press this button again.

**To record into another mailbox with one touch (One-touch Two-way Transfer)**

**PT/PS**

*During a conversation*



Press **One-touch Two-way Transfer**.



- The Two-way Record button light, Two-way Transfer button light or One-touch Two-way Transfer button light shows the current status as follows:  
**Off:** Not recording.  
**On:** Recording the conversation.



- Note:**  
When you record your Two-way telephone conversations, you should inform the other party that the conversation is being recorded.

**Customising Your Phone**

- 3.1.3 Customising the Buttons  
Create or edit a Two-way Record button, a Two-way Transfer button and a One-touch Two-way Transfer button.

## 1.11 Administrative Features

### 1.11.1 Using the Telephones in a Hotel-type Environment (Hospitality Features)

In a hotel-type environment, an extension assigned as a hotel operator can be used to view and set the check-in/check-out/cleaned-up (Ready or Not Ready) status of each guest room extension. When the hotel operator presses a flexible button assigned as "Check-in", "Check-out" or "Cleaned-up" on his/her extension, the extension will switch to Room Status Control mode, and the light of the DSS button for each room extension will show the current room status. This allows the hotel operator to manage guests and rooms with just a telephone. In addition, the hotel operator can set automatic wake-up calls for guest rooms.



- ◆◆ Check-in
- ◆◆ Check-out
- ◆◆ Setting a Timed Reminder to a Room Extension (Remote Wake-up Call)
- ◆◆ Cleaned-up




- The hotel operator must be using a 6-line display PT to use the Check-in, Check-out, and Cleaned-up features.
- While in Room Status Control mode:
  - a. The hotel operator's extension can only check extensions in/out and ready/not ready. All other operations will be ignored.
  - b. The light of each DSS button shows the room status of the corresponding extension as follows:
    - Off:** Checked-out and Ready
    - Flashing Red:** Checked-out and Not Ready
    - Red on:** Checked-in
  - c. The lights of other buttons may not show their normal display.
  - d. The hotel operator's extension is considered to be busy. Callers to that extension will hear a busy tone.

## ◆◆ Check-in

The hotel operator can change the room status of extensions to check-in by using the Check-in button assigned on his/her extension.

### To check in



- After check-in, Remote Extension Dial Lock is deactivated, and the guest can make outside calls from the room extension. (Refer to "2.1.1 Extension Control".)
  - After check-in, all billing data previously charged to the extension will be cleared automatically.
  - When the room status of extensions is changed, detailed room status information is recorded automatically. This requires system programming.
- <Example>

| Date     | Time    | Ext  | CO | Dial Number |
|----------|---------|------|----|-------------|
| 02/02/00 | 03:07PM | 1234 |    | Check in    |


## ◆◆ Check-out

The hotel operator can change the room status of extensions to check-out by using the Check-out button assigned on his/her extension.


Depending on the setting of the PBX, the hotel operator can do the following:

- Record/edit charges for Minibar/Others
- Print out an invoice containing charge information

### To check out a room with/without printing an invoice



### To record/edit room charges and check out a room with/without printing an invoice





- After check-out, Remote Extension Dial Lock is activated, and outside calls from the room extension are restricted. (Refer to "2.1.1 Extension Control".)
- After check-out, wake-up call, Call Log information, and voice messages for the room extension are cleared automatically. In addition, features set on the room extension are reset to the default settings. For a list of features that are reset, refer to "1.8.12 Clearing Features Set at Your Extension (Extension Feature Clear)".
- When the room status of extensions is changed, detailed room status information is recorded automatically. This requires system programming.

<Example>

| Date     | Time    | Ext  | CO | Dial Number |
|----------|---------|------|----|-------------|
| 02/03/00 | 08:08AM | 1234 |    | Check out   |

- To print out an invoice, a printer should be connected to the PBX. If the room extension is in use, an invoice cannot be printed out.

<Example>

```

*****
*                      Hotel                      *
*****
Check in   : 01.JAN.00 06:31PM
Check out  : 03.JAN.00 07:03AM
Room       : 202 : Mr. Smith

01/01/00 06:52PM 202 01 Call amount:0012 01:24'30 00084.50 001
02/01/00 06:07PM 202 01 123456789          00:10'12 00010.20 1234567890
02/01/00 07:30PM 202 01 012345678901234    00:06'36 00006.60 12345
02/01/00 08:45PM 202 01 0011234567890123   00:03'00 00003.00 12345

Telephone                104.30 (Tax 10.000% = 9.48)
Minibar                   4.00 (Tax 10.000% = 0.36)
Others                    0.00 (Tax 15.000% = 0.00)
-----
Total                     FR 108.30 (Tax Total = 9.84)

Sheet : 002

===== Hotel TDAPBX =====
Tel: +41 3 12 34 56 78 Fax: +41 3 12 34 56 78
E-Mail: 12345678@hoteltdapbx.ch

```

- The PBX can store a limited amount of room information. When this storage becomes almost full, the information of the extension that made the most calls is printed out automatically. In this case, the printout is similar to the example above, but without categorised charge information and the total. The PBX can then store new room information. "Call amount:0012" in the example above indicates that the information of 12 phone calls has previously been printed out automatically.




### Customising Your Phone

- 3.1.3 Customising the Buttons  
Create or edit a Check-in or a Check-out button.

◆◆ **Setting a Timed Reminder to a Room Extension (Remote Wake-up Call)**


The hotel operator can remotely set or cancel a Timed Reminder to a room extension. This allows guests to request wake-up calls without having to program the extension themselves. The hotel operator can also confirm the current Timed Reminder setting for a room extension.

**To set**




- \* Enter the time in the format assigned to your PBX (12-hour or 24-hour).

**To cancel**



### To confirm



- Timed Reminder can also be set from the room extension. (For information about setting Timed Reminder, refer to "1.8.1 Setting the Alarm (Timed Reminder)".) The most recent setting will be valid no matter which extension made the setting.
  - When a Timed Reminder starts, and when it is answered or not answered, detailed Timed Reminder information is recorded automatically. This requires system programming.
- <Example>

| Date     | Time    | Ext  | CO | Dial Number              |
|----------|---------|------|----|--------------------------|
| 02/02/00 | 02:45PM | 1234 |    | Timed Reminder/Start     |
| 02/02/00 | 02:46PM | 1234 |    | Timed Reminder/No Answer |
| 02/02/00 | 02:47PM | 1234 |    | Timed Reminder/Answer    |




- Users of PTs without displays can confirm only whether a Timed Reminder has been set or not by following the steps shown above. If set, a confirmation tone will be heard.

## Cleaned-up

The hotel operator can change the room status of extensions depending on whether the room has been cleaned or not by using the Cleaned-up button assigned on his/her extension. This allows the hotel operator to confirm that the room is clean and ready for the next guest.

### To change the cleaning status of a room







#### **Customising Your Phone**


- 3.1.3 Customising the Buttons  
Create or edit a Cleaned-up button.

## 1.11.2 Recording Information Using Preprogrammed Messages (Printing Message)

You can record a variety of information from your extension using up to 8 preprogrammed messages. Message information from all extensions is recorded with the PBX. For example, it is possible to use this feature as a time card by selecting preprogrammed "sign in" and "sign out" messages.

In a hotel-type environment, this feature can be used to record room information from a room extension. For a list of preprogrammed messages, consult your dealer.

### To record



- \* Depending on the content of the selected message, you may be required to enter a numeric parameter, such as a price or time. Enter the correct number of characters as required for the message. For information about required parameters, consult your dealer.

<Example>

If "Snack %%.%" has been programmed as message number 1 (for recording charges for room snacks consumed), hotel employees would enter data as in the example below using the room extension:

\* 761                      1                      0300                      #  
                                     |                      |  
                                     message no.      parameter  
                                                             (Snack charge)

- When a preprogrammed message is selected, detailed information is recorded automatically, as shown below:

| Date     | Time    | Ext  | CO | Dial Number |
|----------|---------|------|----|-------------|
| 02/02/00 | 10:45AM | 1234 |    | Snack 03.00 |

- Any charges recorded here are not related to charges that the hotel operator records when checking out a room.

## 1.12 After Moving to a New Location in the Office


### 1.12.1 Using the Same Settings as Your Previous Extension (Walking Extension)

You can use the same features assigned on your previous extension even if you move to another extension in the office.

You can retain your settings, such as extension number or One-touch Dialling memory, on the new extension.

This feature is also known as Walking Station.

#### To set



- An extension personal identification number (PIN) is required to use this feature. Refer to "◆◆ Assigning an Extension PIN to Your Extension (Extension PIN [Personal Identification Number])" in "3.1.1 Customising Your Phone (Personal Programming)".
- Your previous extension will receive the old settings of your new extension.
- Extension settings can be exchanged between SLT and SLT, PT and PT, or SLT and PT.
- If you are using a KX-NT300 series (except KX-NT321)/KX-DT343/KX-DT346 telephone with a Bluetooth wireless headset, and exchange the settings with another KX-NT300 series (except KX-NT321)/KX-DT343/KX-DT346 telephone user, you cannot use your Bluetooth wireless headset at the other extension.  
Bluetooth wireless headsets are registered on extensions themselves. Therefore, you have to register a Bluetooth wireless headset on each desired extension. For details about registration, refer to "Bluetooth Registration" in "3.1.2 Settings on the Programming Mode".
- For more information, refer to "3.1.1 Customising Your Phone (Personal Programming)".

## 1.13 Using a Display Proprietary Telephone

### 1.13.1 Using the Call Log

This is available for display proprietary telephones and portable stations.

- ◆◆ Calling with the Incoming Call Log
- ◆◆ Calling with the Outgoing Call Log

#### ◆◆ Calling with the Incoming Call Log

When you receive an outside call or an external sensor call, call information is recorded automatically in the incoming call log. A preprogrammed number of calls can be logged per extension.

When the call log is full and other call arrives, the oldest log is deleted.


You can modify the logged telephone number.

When the Call Log button light turns on, there is a call which you did not answer.

The following information is logged.

- Caller's Name
- Date/Time call received
- Answered or Not Answered
- Confirmed or Not Confirmed
- Caller's Phone Number

**To confirm the log information with the Call Log button**




**To confirm the log information with the Navigator Key**



### To clear the log information

**Display PT**

*While confirming the log information*



▶




Press **Call Log**, or **Up** or **Down** until **desired party** appears.

Press **TRANSFER**.

### To call

**Display PT**

*While confirming the log information*



▶




Press **Call Log**, or **Up** or **Down** until **desired party** appears.

Off-hook.

### To store the caller's information in personal speed dialling

**Display PT**

*While confirming the log information*



▶



Press **Call Log**, or **Up** or **Down** until **desired party** appears.

Press **STORE**.



- The Call Log button light shows the current status as follows:  
**Off:** No incoming call. Or you have already viewed the call log.  
**Red on:** You have missed calls to view.
- If your call is answered by another extension, the caller's information is recorded on the displays of both your extension and the answering extension.
- You can lock your call log display by using an extension PIN (Personal Identification Number), so that you can prohibit access to your logged information (Display Lock). Refer to "3.1.2 Settings on the Programming Mode".
- You can also have a Call Log button for an ICD Group (Incoming Call Distribution Group).
- If a call arrives while you are using the call log, the call log display will be replaced with the caller's information.




### Customising Your Phone

- 3.1.3 Customising the Buttons  
Create or edit a Call Log button or Call Log for ICD Group button.


## ◆◆ Calling with the Outgoing Call Log

You can redial using the outgoing call log.

### To call




### To call with the REDIAL button



- \* System programming is required for this operation.
- This operation is available only for digital proprietary telephones with a display.

### To store the caller's information in personal speed dialling



- You can lock your call log display by using an extension PIN (Personal Identification Number), so that you can prohibit access to your logged information (Display Lock). Refer to "3.1.2 Settings on the Programming Mode".
- If a call arrives while you are using the call log, the call log display will be replaced with the caller's information.

## 1.13.2 Using the Directories

You can call using the directories (*Personal Speed Dialling Directory*, *System Speed Dialling Directory* and *Extension Number Directory*).


Only personal directories can be stored, edited or deleted on your extension.

If a call arrives while you are using a directory, the display will be replaced with the caller's information.

- ◆◆ Calling with the Directory
- ◆◆ Storing Names and Numbers
- ◆◆ Entering Characters

### ◆◆ Calling with the Directory

To select and call




- \* The display order is as follows:  
One time: Personal Speed Dialling Directory  
Two times: System Speed Dialling Directory  
Three times: Extension Number Directory
- To cancel or exit, press the CANCEL or FLASH/RECALL button.
- You can lock your personal speed dialling directory by using an extension PIN (Personal Identification Number), so that you can prohibit access to it (Display Lock). Refer to "3.1.2 Settings on the Programming Mode".



- Directory entries generally should include name and number. If the name is not registered, an entry cannot be displayed.
- The System Speed Dialling Directory can be displayed simply by pressing the AUTO DIAL/STORE button while on-hook.

## ◆◆ Storing Names and Numbers

To store a Personal Speed Dialling Directory item



- Telephone numbers and names displayed are stored using the first spare Personal Speed Dialling memory available.
- PS user: Refer to "Operating Instructions" for PS.



- For more details, refer to "To store the names and numbers in personal speed dialling" in "3.1.2 Settings on the Programming Mode".

## ◆◆ Entering Characters

You can enter the following characters. The tables show you the characters available for each button. Table 1 or Table 2 can be programmed.



Table 1 (Standard mode)

| Times<br>Buttons | 1       | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 |
|------------------|---------|---|---|---|---|---|---|---|---|
| 1                | !       | ? | " | 1 |   |   |   |   |   |
| 2                | A       | B | C | a | b | c | 2 |   |   |
| 3                | D       | E | F | d | e | f | 3 |   |   |
| 4                | G       | H | I | g | h | i | 4 |   |   |
| 5                | J       | K | L | j | k | l | 5 |   |   |
| 6                | M       | N | O | m | n | o | 6 |   |   |
| 7                | P       | Q | R | S | p | q | r | s | 7 |
| 8                | T       | U | V | t | u | v | 8 |   |   |
| 9                | W       | X | Y | Z | w | x | y | z | 9 |
| 0                | (Space) | . | , | ' | : | ; | 0 |   |   |
| *                | /       | + | — | = | < | > | * |   |   |
| #                | \$      | % | & | @ | ( | ) | € | £ | # |

**Table 1 (Standard mode for RU model)**

| Times<br>Buttons | 1       | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 |
|------------------|---------|---|---|---|---|---|---|---|---|
| <b>1</b>         | !       | ? | " | 1 |   |   |   |   |   |
| <b>2</b>         | A       | B | C | a | b | c | 2 |   |   |
| <b>3</b>         | D       | E | F | d | e | f | 3 |   |   |
| <b>4</b>         | G       | H | I | g | h | i | 4 |   |   |
| <b>5</b>         | J       | K | L | j | k | l | 5 |   |   |
| <b>6</b>         | M       | N | O | m | n | o | 6 |   |   |
| <b>7</b>         | P       | Q | R | S | p | q | r | s | 7 |
| <b>8</b>         | T       | U | V | t | u | v | 8 |   |   |
| <b>9</b>         | W       | X | Y | Z | w | x | y | z | 9 |
| <b>0</b>         | (Space) | . | , | ' | : | ; | 0 |   |   |
| <b>*</b>         | /       | + | — | = | < | > | * |   |   |
| <b>#</b>         | \$      | % | & | @ | ( | ) | ■ | ■ | # |

Table 2 (Option mode)

| Times<br>Buttons | 1       | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 |
|------------------|---------|---|---|---|---|---|---|---|---|----|----|----|----|----|----|
| <b>1</b>         | !       | ? | " | ä | ö | ü | 1 |   |   |    |    |    |    |    |    |
| <b>2</b>         | A       | B | C | a | b | c | À | Á | Â | Ã  | Ä  | Å  | Æ  | Ç  | 2  |
| <b>3</b>         | D       | E | F | d | e | f | Ð | È | É | Ê  | Ë  | 3  |    |    |    |
| <b>4</b>         | G       | H | I | g | h | i | Ì | Í | Î | Ï  | 4  |    |    |    |    |
| <b>5</b>         | J       | K | L | j | k | l | 5 |   |   |    |    |    |    |    |    |
| <b>6</b>         | M       | N | O | m | n | o | Ñ | Ò | Ó | Ô  | Õ  | Ö  | Ø  | Œ  | 6  |
| <b>7</b>         | P       | Q | R | S | p | q | r | s | Š | ß  | 7  |    |    |    |    |
| <b>8</b>         | T       | U | V | t | u | v | Û | Ú | Û | Ü  | 8  |    |    |    |    |
| <b>9</b>         | W       | X | Y | Z | w | x | y | z | Ý | Ž  | 9  |    |    |    |    |
| <b>0</b>         | (Space) | . | , | ' | : | ; | 0 |   |   |    |    |    |    |    |    |
| <b>*</b>         | /       | + | — | = | < | > | * |   |   |    |    |    |    |    |    |
| <b>#</b>         | \$      | % | & | @ | ( | ) | € | £ | # |    |    |    |    |    |    |

Table 2 (Option mode for CE model)

| Times<br>Buttons | 1       | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 |
|------------------|---------|---|---|---|---|---|---|---|---|----|----|----|----|----|----|
| <b>1</b>         | !       | ? | " | ä | ö | ü | 1 |   |   |    |    |    |    |    |    |
| <b>2</b>         | A       | B | C | a | b | c | Á | Â | Ă | Ä  | Å  | Ć  | Ç  | Č  | 2  |
| <b>3</b>         | D       | E | F | d | e | f | Ď | Đ | É | Ę  | Ě  | ě  | 3  |    |    |
| <b>4</b>         | G       | H | I | g | h | i | Í | Î | 4 |    |    |    |    |    |    |
| <b>5</b>         | J       | K | L | j | k | l | Ĺ | Í | 5 |    |    |    |    |    |    |
| <b>6</b>         | M       | N | O | m | n | o | Ń | Ň | Ó | Ô  | Õ  | Ö  | 6  |    |    |
| <b>7</b>         | P       | Q | R | S | p | q | r | s | Ř | Ř  | Š  | Ś  | Ş  | ß  | 7  |
| <b>8</b>         | T       | U | V | t | u | v | Ť | Ț | ű | Ú  | Ů  | Ü  | 8  |    |    |
| <b>9</b>         | W       | X | Y | Z | w | x | Y | z | Ž | Ž  | Ž  | Ý  | 9  |    |    |
| <b>0</b>         | (Space) | . | , | ' | : | ; | 0 |   |   |    |    |    |    |    |    |
| <b>*</b>         | /       | + | — | = | < | > | * |   |   |    |    |    |    |    |    |
| <b>#</b>         | §       | % | & | @ | ( | ) | € | £ | # |    |    |    |    |    |    |


Table 2 (Option mode for RU model)

| Times<br>Buttons | 1  | 2 | 3         | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 |
|------------------|----|---|-----------|---|---|---|---|---|---|----|----|
| 1                | А  | Б | В         | ! | ? | " | 1 |   |   |    |    |
| 2                | Г  | Д | Е         | Ё | 2 |   |   |   |   |    |    |
| 3                | Ж  | З | И         | Й | 3 |   |   |   |   |    |    |
| 4                | К  | Л | М         | 4 |   |   |   |   |   |    |    |
| 5                | Н  | О | П         | 5 |   |   |   |   |   |    |    |
| 6                | Р  | С | Т         | 6 |   |   |   |   |   |    |    |
| 7                | У  | Ф | Х         | 7 |   |   |   |   |   |    |    |
| 8                | Ц  | Ч | Ш         | 8 |   |   |   |   |   |    |    |
| 9                | Щ  | Ъ | Ы         | Ь | 9 |   |   |   |   |    |    |
| 0                | Э  | Ю | Я (Space) | . | , | ' | : | ; | 0 |    |    |
| *                | /  | + | —         | = | < | > | Г | € | І | İ  | *  |
| #                | \$ | % | &         | @ | ( | ) | € | І | Ÿ | #  |    |

## 1.13.3 Accessing System Features (System Feature Access)

You can access a feature with the "Feature Access" menu.

To access "Feature Access" menu and select the feature



| Features                       | Refer to                                                          |
|--------------------------------|-------------------------------------------------------------------|
| Automatic Callback Busy Cancel | 1.2.4 When the Dialed Line is Busy or There is No Answer          |
| Group Call Pickup              | 1.3.3 Answering a Call Ringing at Another Telephone (Call Pickup) |
| Directed Call Pickup           | 1.3.3 Answering a Call Ringing at Another Telephone (Call Pickup) |
| Paging                         | 1.7.1 Paging                                                      |
| Doorphone Call                 | 1.10.1 If a Doorphone/Door Opener is Connected                    |
| Door Open                      | 1.10.1 If a Doorphone/Door Opener is Connected                    |
| External Relay                 | 1.10.2 If an External Relay is Connected                          |
| External Background Music      | 2.1.4 Turning on the External Background Music (BGM)              |



- This feature is not available for the KX-NT321 and KX-DT321.



---

## **Section 2**

# ***Manager Operation***

*This chapter shows the manager how to control the other extensions or the PBX.*



## 2.1 Control Features

### 2.1.1 Extension Control


The manager extension can control the settings of other extensions.

- ◆◆ Changing the Settings of Other Extensions

#### ◆◆ Changing the Settings of Other Extensions

##### To lock/unlock other extensions (Remote Extension Dial Lock)

This feature is also known as Remote Station Lock Control.



- The manager can use Remote Extension Dial Lock to unlock any extension, whether that extension was locked remotely (Remote Extension Dial Lock) or from the extension itself (Extension Dial Lock).

## 2.1.2 Time Service Mode Control

The manager extension or the preprogrammed extension can change the time mode (Day, Lunch, Break or Night).

There are two methods (Automatic or Manual) of changing the time modes.

**Automatic:** enables the time mode for each day of the week to change automatically. You may also change it manually.

**Manual:** enables to change a mode in manual as follows.

### To change the time mode (Day/Night/Lunch/Break)


**PT/PS**

*While on-hook*

  
(Time Service  
Day/Night/  
Lunch/Break))

Press **Time Service**  
(Day/Night/Lunch/Break)  
until the desired mode  
appears.

**PT/SLT/PS**

Off-hook.      Enter \*780.      Enter 0 to 3 as you desire.      On-hook.

0 Day  
1 Night  
2 Lunch  
3 Break

### To select the time service switching mode (Automatic/Manual)

**PT/PS**

*While on-hook*

  
(Time Service  
Switching Mode  
Automatic/Manual))

Press **Time Service Switching**  
**Mode (Automatic/Manual).**



- Besides the time mode, there is Holiday mode. It can change mode once on a specified date.
- The Time Service (Day/Night/Lunch/Break) button light shows the current status as follows:  
**Off:** Day mode  
**Green on:** Lunch mode  
**Flashing green:** Break mode  
**Red on:** Night mode  
**Flashing red:** Holiday mode
- The Time Service Switching Mode (Automatic/Manual) button light shows the current status as follows:  
**Off:** Automatic  
**Red on:** Manual




### Customising Your Phone

- 3.1.3 Customising the Buttons  
Create or edit a Time Service (Day/Night/Lunch/Break) button or a Time Service Switching Mode (Automatic/Manual) button.

## 2.1.3 Restriction Level Control (Dial Tone Transfer)

The manager extension can change the restriction level, permitting an extension to make a call.



- The restriction level is changed to the preprogrammed level of Toll Restriction/Call Barring button.




### Customising Your Phone

- 3.1.3 Customising the Buttons  
Create or edit a Toll Restriction/Call Barring button.

## 2.1.4 Turning on the External Background Music (BGM)

The manager extension can select and broadcast background music in the office through external speakers.

To select and start/stop the background music



## 2.1.5 Recording Outgoing Messages (OGM)


The manager extension can record three kinds of greeting messages (OGM) as follows:

1. **DISA message:** Used to greet and guide callers so that they access an extension user group or outside party without operator assistance.
2. **Incoming Call Distribution Group message:** Used to greet and guide callers to an incoming call distribution group.
3. **Timed Reminder message:** Used for a wake-up call message when the extension answers the Timed Reminder.




All messages have their own extension numbers. You can select the desired message. You have two methods for recording a message. One is recorded using the handset, and the other is recorded from an external BGM (MOH) port.


### To record




### To play back



### To record from an external BGM (MOH) port



### To clear the message




- The default of OGM floating extension numbers is 5xx (xx: two-digit number of message).

## 2.1.6 Allowing Users to Seize an Unavailable Outside Line (Trunk Busy Out)

When a problem is found on a certain outside line, the PBX automatically makes it unavailable for use temporarily. The manager can manually enable the outside line and allow users to use it again.

### To re-enable an outside line




- In some countries/areas, the PBX may not be able to automatically make a faulty outside line unavailable for use.



## 2.1.7 Releasing Network Direct Station Selection (NDSS) Monitor

NDSS buttons can be customised on any extension connected to your PBX. An NDSS button allows an extension user to monitor another extension connected to another PBX in a private network. The NDSS button light shows the current status of the monitored extension in the same way as a DSS button. When it becomes unnecessary to monitor an extension connected to another PBX, the manager can stop the PBX from monitoring it. Any NDSS buttons set to monitor that extension will also stop monitoring.



- To restart monitoring of an extension after performing this operation, go off-hook, press the corresponding NDSS button, and go on-hook.



### Customising Your Phone

- 3.1.3 Customising the Buttons  
Create or edit a Network Direct Station Selection (NDSS) button.

---

## **Section 3**

# ***Customising Your Phone & System***

*This chapter shows you how to customise your individual telephone or PBX according to your needs. Find the desired setting and program as necessary.*

## 3.1 Customising Your Phone (Personal Programming)

### 3.1.1 Customising Your Phone (Personal Programming)

You can customise your telephone features. For example, you can change the initial settings or button features according to your needs.

- ♦♦ Assigning an Extension PIN to Your Extension (Extension PIN [Personal Identification Number])




- If you change your desk and extension, refer to "1.12.1 Using the Same Settings as Your Previous Extension (Walking Extension)".


#### ♦♦ Assigning an Extension PIN to Your Extension (Extension PIN [Personal Identification Number])

You can assign a password to each extension.  
The following features require an extension PIN.

1. Screening calls (Live Call Screening [LCS])
2. Prohibiting other people from seeing your personal speed dialling directory, call log, SVM log, and from playing back the voice messages in your message box (Display Lock)
3. Using the same settings as your extension at other extensions (Walking Extension)
4. Remote Control Operation (Walking COS)
5. Extension Dial Lock Clear

To set



**To cancel****CAUTION**

There is a risk that fraudulent telephone calls will be made if a third party discovers your password (extension PIN).

The cost of such calls will be billed to the owner/renter of the PBX.

To protect the PBX from this kind of fraudulent use, we strongly recommend:

- Keeping your PIN secret.
  - Selecting a complex, random PIN that cannot be easily guessed.
  - Changing your PIN regularly.
- Valid numbers for an extension PIN are "0" through "9".
  - If the wrong extension PIN is entered a preprogrammed number of times, the PIN is locked.
  - If you forget your extension PIN or your extension PIN is locked, your manager can clear the extension PIN and extension PIN lock.

## 3.1.2 Settings on the Programming Mode

You can programme features using the programming mode.

- ◆◆ Setting Features
- ◆◆ Clearing Features




- To exit at any time, lift the handset.
- To enter the programming mode when using a PS, refer to "Operating Instructions" for PS.

### ◆◆ Setting Features

The default settings are shown in bold letters. For later reference, place a check mark in the boxes below to indicate your customised setting.

#### Notice

The default value may vary depending on country/area.



| Item                                                                                                          | Programming Input                                             | Selection & Parameter                                                                                                                                                                                                         |                                             |
|---------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------|
| Your extension information                                                                                    | <input type="text" value="0"/> <input type="text" value="0"/> | PT: The display shows the PBX number, slot number and port number.<br><example><br>EXT1050:10308<br>PBX no. <input type="text" value="1"/> <input type="text" value="1"/> <input type="text" value="1"/> Port no.<br>Slot no. |                                             |
| <b>Display Contrast Selection<sup>1</sup></b><br>Preferred display contrast level from the 4 levels available | <input type="text" value="0"/> <input type="text" value="1"/> | <input type="text" value="1"/>                                                                                                                                                                                                | <input type="checkbox"/> Light              |
|                                                                                                               |                                                               | <input type="text" value="2"/>                                                                                                                                                                                                | <input type="checkbox"/> Little Light       |
|                                                                                                               |                                                               | <input type="text" value="3"/>                                                                                                                                                                                                | <input type="checkbox"/> <b>Little Dark</b> |
|                                                                                                               |                                                               | <input type="text" value="4"/>                                                                                                                                                                                                | <input type="checkbox"/> Dark               |

| Item                                                                                                                                                   | Programming Input                                                                                  | Selection & Parameter        |                                                                                                                                                            |
|--------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------|------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Display Language Selection</b><br>Which display language do you prefer?                                                                             | <div>0 2 / </div> | 1                            | <input type="checkbox"/> English                                                                                                                           |
|                                                                                                                                                        |                                                                                                    | 2                            | <input type="checkbox"/> 2nd Language                                                                                                                      |
|                                                                                                                                                        |                                                                                                    | 3                            | <input type="checkbox"/> 3rd Language                                                                                                                      |
|                                                                                                                                                        |                                                                                                    | 4                            | <input type="checkbox"/> 4th Language                                                                                                                      |
|                                                                                                                                                        |                                                                                                    | 5                            | <input type="checkbox"/> 5th Language                                                                                                                      |
| <b>Display Switching Mode</b><br>Would you like the call duration to be shown automatically on the display when answering an outside call?             | <div>0 3</div>                                                                                     | 0                            | <input type="checkbox"/> No—Manual (The display keeps showing all of the outside caller's information unless you change it to the call duration manually.) |
|                                                                                                                                                        |                                                                                                    | 1                            | <input type="checkbox"/> Yes—Automatic (The first line of the display will change to the call duration automatically when you answer an outside call.)     |
| <b>Display Backlight Selection</b> <sup>*1*2</sup><br>Would you like to turn on the display backlight of the telephone?                                | <div>0 4</div>                                                                                     | 0                            | <input type="checkbox"/> Yes—Automatic                                                                                                                     |
|                                                                                                                                                        |                                                                                                    | 1                            | <input type="checkbox"/> Yes—always On                                                                                                                     |
|                                                                                                                                                        |                                                                                                    | 2                            | <input type="checkbox"/> No—always Off                                                                                                                     |
| <b>Hot Line</b><br>Would you like to dial a preset number simply by going off-hook?                                                                    | <div>1 1</div>                                                                                     | desired no. (max. 32 digits) |                                                                                                                                                            |
|                                                                                                                                                        | <div>1 2</div>                                                                                     | 0                            | <input type="checkbox"/> Do not use                                                                                                                        |
|                                                                                                                                                        |                                                                                                    | 1                            | <input type="checkbox"/> Use                                                                                                                               |
| <b>Calling Line Identification Restriction (CLIR)</b><br>Should you prevent your number being displayed on the called party's telephone?               | <div>1 3</div>                                                                                     | 0                            | <input type="checkbox"/> No—Allows your number to be displayed                                                                                             |
|                                                                                                                                                        |                                                                                                    | 1                            | <input type="checkbox"/> Yes—Prevent your number being displayed                                                                                           |
| <b>Calling/Connected Line Identification Presentation (CLIP/COLP)</b><br>Which number should be displayed on the called and calling party's telephone? | <div>1 4</div>                                                                                     | 0                            | <b>Caller ID assigned to your extension</b>                                                                                                                |
|                                                                                                                                                        |                                                                                                    | 1                            | Caller ID assigned on the outside line being used                                                                                                          |


### 3.1.2 Settings on the Programming Mode

| Item                                                                                                                                               | Programming Input         | Selection & Parameter                                                             |                                                                                                                    |
|----------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------|-----------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------|
| <b>Preferred Line Assignment —Outgoing</b><br>Which do you prefer to seize when you go off-hook to make calls?                                     | <div>1</div> <div>9</div> | <div>0</div>                                                                      | <input type="checkbox"/> No line                                                                                   |
|                                                                                                                                                    |                           | <div>1</div>                                                                      | <input type="checkbox"/> An idle outside line                                                                      |
|                                                                                                                                                    |                           | <div>2</div> +<br>CO button no.<br>(01–36) <sup>*3</sup><br>or<br><div>(CO)</div> | <input type="checkbox"/> A CO/ICD Group button                                                                     |
|                                                                                                                                                    |                           | <div>3</div><br>or<br>INTERCOM / <div>(PDN)</div>                                 | <input type="checkbox"/> <b>Intercom</b> (On a PDN extension, an idle PDN button is selected when going off-hook.) |
| <b>Preferred Line Assignment —Incoming</b><br>Which line do you prefer to answer when you go off-hook?                                             | <div>2</div> <div>0</div> | <div>0</div>                                                                      | <input type="checkbox"/> No line                                                                                   |
|                                                                                                                                                    |                           | <div>1</div>                                                                      | <input type="checkbox"/> <b>The longest ringing line (when multiple calls arrive)</b>                              |
|                                                                                                                                                    |                           | <div>2</div> +<br>CO button no.<br>(01–36) <sup>*3</sup><br>or<br><div>(CO)</div> | <input type="checkbox"/> A CO/ICD Group button                                                                     |
|                                                                                                                                                    |                           | <div>3</div> / <div>(PDN)</div>                                                   | <input type="checkbox"/> A PDN button                                                                              |
| <b>Alternate Receiving—Ring/Voice<sup>*1</sup></b><br>How do you prefer to receive an intercom call?                                               | <div>2</div> <div>1</div> | <div>0</div>                                                                      | <input type="checkbox"/> <b>Ringing (Tone Call)</b>                                                                |
|                                                                                                                                                    |                           | <div>1</div>                                                                      | <input type="checkbox"/> Directly—The party's voice is heard without ringing.                                      |
|                                                                                                                                                    |                           | <div>2</div>                                                                      | <input type="checkbox"/> Ring only—Prohibiting the caller switching to the voice mode.                             |
| <b>Forced Answerback Selection<sup>*1</sup></b><br>Do you prefer to answer a call without going off-hook regardless of the AUTO ANS button status? | <div>2</div> <div>3</div> | <div>0</div>                                                                      | <input type="checkbox"/> <b>No—Disable</b>                                                                         |
|                                                                                                                                                    |                           | <div>1</div>                                                                      | <input type="checkbox"/> Yes—Enable                                                                                |

| Item                                                                                                                                                         | Programming Input         | Selection & Parameter        |                                                                                                                |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------|------------------------------|----------------------------------------------------------------------------------------------------------------|
| <b>Live Call Screening Mode Set<sup>*1</sup></b><br>Which service do you prefer when a calling party is recording a message in your mailbox?                 | <div>2</div> <div>5</div> | <div>0</div>                 | <input type="checkbox"/> You can monitor the message through the telephone speaker. ( <b>Hands-free mode</b> ) |
|                                                                                                                                                              |                           | <div>1</div>                 | <input type="checkbox"/> Only an alarm tone is heard. (Private mode)                                           |
| <b>LCS Mode Set (After Answering)</b><br>Would you like to keep recording after answering the call in the LCS mode?                                          | <div>2</div> <div>6</div> | <div>0</div>                 | <input type="checkbox"/> <b>No—Stop recording</b>                                                              |
|                                                                                                                                                              |                           | <div>1</div>                 | <input type="checkbox"/> Yes—Keep recording                                                                    |
| <b>Automatic Call Waiting<sup>*5</sup></b><br>Would you prefer to automatically hear a call waiting tone when you receive a call while already on the phone? | <div>3</div> <div>0</div> | <div>0</div>                 | <input type="checkbox"/> <b>No—Off</b>                                                                         |
|                                                                                                                                                              |                           | <div>1</div>                 | <input type="checkbox"/> Yes—On                                                                                |
| <b>Manual Call Waiting</b><br>How would you prefer to receive call waiting notifications for intercom calls?                                                 | <div>3</div> <div>1</div> | <div>0</div>                 | <input type="checkbox"/> <b>No call (Off)</b>                                                                  |
|                                                                                                                                                              |                           | <div>1</div>                 | <input type="checkbox"/> Tone (BSS)                                                                            |
|                                                                                                                                                              |                           | <div>2</div>                 | <input type="checkbox"/> Voice announcement through the built-in speaker (OHCA) <sup>*6</sup>                  |
|                                                                                                                                                              |                           | <div>3</div>                 | <input type="checkbox"/> Voice announcement through the handset (Whisper OHCA) <sup>*6</sup>                   |
| <b>Call Waiting Tone Type Selection</b><br>Which type of call waiting tone do you prefer?                                                                    | <div>3</div> <div>2</div> | <div>0</div>                 | <input type="checkbox"/> <b>Tone 1</b>                                                                         |
|                                                                                                                                                              |                           | <div>1</div>                 | <input type="checkbox"/> Tone 2                                                                                |
| <b>Absent Message</b><br>Would you like to show a message on the caller's telephone display?                                                                 | <div>4</div> <div>0</div> | <div>0</div>                 | <input type="checkbox"/> <b>No—Off</b>                                                                         |
|                                                                                                                                                              |                           | message no. (1–8)            | <input type="checkbox"/> Yes—Shows the selected message.                                                       |
|                                                                                                                                                              |                           | <div>9</div>                 | <input type="checkbox"/> Yes—Shows your personal message.                                                      |
| <b>Personal Absent Message</b><br>Creating your personal message                                                                                             | <div>4</div> <div>1</div> | message (max. 16 characters) |                                                                                                                |



### 3.1.2 Settings on the Programming Mode

| Item                                                                                                         | Programming Input                                                                                                                                                                  | Selection & Parameter                                         |                                                                                                          |
|--------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------|----------------------------------------------------------------------------------------------------------|
| <b>Call Forwarding (FWD)/Do Not Disturb (DND)</b><br>To forward or refuse some or all of your incoming calls | <br>(for both calls)<br><br>(5) (1)<br>(for outside calls)<br><br>(5) (2)<br>(for intercom calls) | (0)                                                           | <input type="checkbox"/> Off                                                                             |
|                                                                                                              |                                                                                                                                                                                    | (1)                                                           | <input type="checkbox"/> Do Not Disturb (DND)                                                            |
|                                                                                                              |                                                                                                                                                                                    | (2) + desired no.<br>(max. 32 digits)                         | <input type="checkbox"/> All—Forward all calls                                                           |
|                                                                                                              |                                                                                                                                                                                    | (3) + desired no.<br>(max. 32 digits)                         | <input type="checkbox"/> Busy—Forwarded when your extension is busy.                                     |
|                                                                                                              |                                                                                                                                                                                    | (4) + desired no.<br>(max. 32 digits)                         | <input type="checkbox"/> No Answer—Forwarded when you do not answer.                                     |
|                                                                                                              |                                                                                                                                                                                    | (5) + desired no.<br>(max. 32 digits)                         | <input type="checkbox"/> Busy/No Answer—Forwarded when you do not answer or when your extension is busy. |
| <b>FWD N/A Timer</b><br>To set the timer for "No Answer" and "Busy/No Answer"                                | (5) (3)                                                                                                                                                                            | <input type="text"/> (0–120) seconds<br>(Default: 15 seconds) |                                                                                                          |
| <b>Call Pickup Deny</b><br>Should you prohibit other people from picking up your calls?                      | (6) (0)                                                                                                                                                                            | (0)                                                           | <input type="checkbox"/> No—Allow                                                                        |
|                                                                                                              |                                                                                                                                                                                    | (1)                                                           | <input type="checkbox"/> Yes—Deny                                                                        |
| <b>Headset Operation</b> <sup>**4</sup><br>Do you use the headset?                                           | (6) (1)                                                                                                                                                                            | (0)                                                           | <input type="checkbox"/> No—Headset off                                                                  |
|                                                                                                              |                                                                                                                                                                                    | (1)                                                           | <input type="checkbox"/> Yes—Headset on                                                                  |
| <b>Executive Busy Override Deny</b><br>Do you prohibit other people from joining your conversation?          | (6) (2)                                                                                                                                                                            | (0)                                                           | <input type="checkbox"/> No—Allow                                                                        |
|                                                                                                              |                                                                                                                                                                                    | (1)                                                           | <input type="checkbox"/> Yes—Deny                                                                        |
| <b>Paging Deny</b> <sup>*1</sup><br>Would you like to prohibit paging announcements?                         | (6) (3)                                                                                                                                                                            | (0)                                                           | <input type="checkbox"/> No—Allow                                                                        |
|                                                                                                              |                                                                                                                                                                                    | (1)                                                           | <input type="checkbox"/> Yes—Deny                                                                        |
| <b>Key Pad Tone Set</b> <sup>*1</sup><br>Do you prefer to hear the key pad tone?                             | (6) (4)                                                                                                                                                                            | (0)                                                           | <input type="checkbox"/> No—Off                                                                          |
|                                                                                                              |                                                                                                                                                                                    | (1)                                                           | <input type="checkbox"/> Yes—On                                                                          |

| Item                                                                                                                                                                                            | Programming Input         | Selection & Parameter                                                                        |                                    |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------|----------------------------------------------------------------------------------------------|------------------------------------|
| <b>Background Music (BGM)<sup>*1</sup></b><br>Do you want background music through your telephone speaker while on-hook?                                                                        | <div>6</div> <div>5</div> | <div>0</div>                                                                                 | <input type="checkbox"/> No—Off    |
|                                                                                                                                                                                                 |                           | <div>1</div> + BGM no.<br>(1 digit)                                                          | <input type="checkbox"/> Yes—On    |
| <b>Bluetooth Registration<sup>*7</sup></b><br>To register a Bluetooth wireless headset on your extension <sup>*8</sup>                                                                          | <div>6</div> <div>6</div> | Pass key (max. 16 digits)                                                                    |                                    |
| <b>Bluetooth Removal<sup>*7</sup></b><br>To cancel the registration of a Bluetooth wireless headset on your extension <sup>*8</sup>                                                             | <div>6</div> <div>7</div> | Confirm that the ID of your Bluetooth wireless headset is displayed.                         |                                    |
| <b>Extension PIN (Personal Identification Number)</b><br>To set your extension PIN or change the stored extensionPIN                                                                            | <div>9</div> <div>0</div> | extension PIN (max. 10 digits) + ENTER/STORE + same extension PIN                            | To set an extension PIN            |
|                                                                                                                                                                                                 |                           | stored extension PIN + new extension PIN (max. 10 digits) + ENTER/STORE + same extension PIN | To change the stored extension PIN |
| <b>Extension Dial Lock</b><br>To prevent other people from using your telephone                                                                                                                 | <div>9</div> <div>1</div> | <b>extension PIN (max. 10 digits) +</b><br><div>0</div>                                      | <input type="checkbox"/> To unlock |
|                                                                                                                                                                                                 |                           | extension PIN (max. 10 digits) + <div>1</div>                                                | <input type="checkbox"/> To lock   |
| <b>Display Lock<sup>*1</sup></b><br>To prevent other people from seeing your personal speed dialling directory, call log, SVM log, and from playing back the voice messages in your message box | <div>9</div> <div>2</div> | <b>extension PIN (max. 10 digits) +</b><br><div>0</div>                                      | <input type="checkbox"/> To unlock |
|                                                                                                                                                                                                 |                           | extension PIN (max. 10 digits) + <div>1</div>                                                | <input type="checkbox"/> To lock   |

### 3.1.2 Settings on the Programming Mode

| Item                                                                                                     | Programming Input         | Selection & Parameter |                                                                                                                                                                |
|----------------------------------------------------------------------------------------------------------|---------------------------|-----------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>One-touch Dialling Assignment Mode Selection</b><br>Do you prefer to set the One-touch dialling only? | <div>#</div> <div>✱</div> | <div>0</div>          | <input type="checkbox"/> <b>No—Normal (Any Flexible buttons can be modified.)</b>                                                                              |
|                                                                                                          |                           | <div>1</div>          | <input type="checkbox"/> <b>Yes—Only One-touch dialling buttons can be modified. However, to modify them, there is no need to enter "2" before the number.</b> |

\*1 Not available for a PS

\*2 Only available for KX-T7633/KX-T7636/IP-PTs (except KX-NT265/KX-NT321)/KX-DT343/KX-DT346 telephones.

\*3 CO button numbers (25–36) are available only when the Add-on Key Module is set up to your telephone.

\*4 Not available for the KX-T7665

\*5 This setting applies to both outside and intercom calls. For intercom calls, this feature must be enabled through system programming.

\*6 Only available for certain digital proprietary telephones.

\*7 Only available for KX-NT300 series (except KX-NT321)/KX-DT343/KX-DT346 telephones.

\*8 Registering and cancelling a Bluetooth wireless headset may take time. Please avoid any interruption during that time by, for example, going off-hook.



#### **CAUTION**

There is a risk that fraudulent telephone calls will be made if a third party discovers your password (extension PIN).


The cost of such calls will be billed to the owner/renter of the PBX.

To protect the PBX from this kind of fraudulent use, we strongly recommend:

- a. Keeping your PIN secret.
- b. Selecting a complex, random PIN that cannot be easily guessed.
- c. Changing your PIN regularly.
- After the programme number is entered, the programme title is displayed. The programming screen can be changed with the Navigator Key (Up or Down).
- You can select the parameter with the Navigator Key (Up or Down) instead of entering a number.




To store the names and numbers in personal speed dialling



- \* To enter characters, refer to "◆◆ Entering Characters".

#### To edit the names and numbers of personal speed dialling




#### ◆◆ Clearing Features

You can clear or change to features as follows:

| Features                                                       | Default Setting                             |
|----------------------------------------------------------------|---------------------------------------------|
| Display Switching Mode                                         | <b>Automatic</b>                            |
| Hot Line                                                       | <b>Off</b>                                  |
| Calling Line Identification Restriction (CLIR)                 | <b>Allow</b>                                |
| Calling/Connected Line Identification Presentation (CLIP/COLP) | <b>Caller ID assigned on your extension</b> |
| Preferred Line Assignment—Outgoing                             | <b>Intercom</b>                             |
| Preferred Line Assignment—Incoming                             | <b>The longest ringing line</b>             |
| Alternate Receiving—Ring/Voice                                 | <b>Ringing (Tone Call)</b>                  |
| Forced Answerback Selection                                    | <b>Disable</b>                              |
| Live Call Screening Mode Set                                   | <b>Hands-free mode</b>                      |
| LCS Mode Set (After Answering)                                 | <b>Stop recording</b>                       |

| Features                                                          | Default Setting       |
|-------------------------------------------------------------------|-----------------------|
| Automatic Call Waiting                                            | Off                   |
| Manual Call Waiting—Intercom Calls                                | Off (No call/No tone) |
| Call Waiting Tone Type Selection                                  | Tone 1                |
| Absent Message                                                    | Off                   |
| Personal Absent Message                                           | Cleared               |
| Call Forwarding (FWD)/Do Not Disturb (DND)—Intercom/Outside Calls | Off                   |
| FWD N/A Timer                                                     | 15 seconds            |
| Call Pickup Deny                                                  | Allow                 |
| Headset Operation                                                 | Headset off           |
| Executive Busy Override Deny                                      | Allow                 |
| Paging Deny                                                       | Allow                 |
| Key Pad Tone Set                                                  | On                    |
| Background Music (BGM)                                            | Off                   |
| Data Line Security                                                | Off                   |
| Connected Line Identification Restriction (COLR)                  | Allow                 |
| Log-in/Log-out                                                    | Log-in                |
| Message Waiting                                                   | Off                   |
| Timed Reminder                                                    | Cleared               |

### To set




- If you do not desire that the Call Waiting, FWD/DND or Hot Line to be cleared by this feature, please ask your dealer.

### 3.1.3 Customising the Buttons

You can customise the flexible buttons on PTs, Add-on Key Modules, and PSs. They can then be used to make or receive outside calls or as feature buttons.



- To enter the programming mode when using a PS, refer to "Operating Instructions" for PS.
- The buttons in the table below can only be set on certain flexible buttons, as follows:
  - Flexible buttons on PTs/Add-on Key Modules/PSs: all buttons can be set.
  - Flexible buttons on DSS Consoles: all buttons except CTI and Primary Directory Number (PDN) buttons can be set.



| Button                                                | Programming Input                                                                                                               |
|-------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------|
| Loop-CO (L-CO)                                        | <b>[*]</b>                                                                                                                      |
| Group-CO (G-CO)                                       | <b>[#]</b> + Outside line group no. (2 digits)                                                                                  |
| Single-CO (S-CO)                                      | <b>[0]</b> + Outside line no. (3 digits)                                                                                        |
| Direct Station Selection (DSS)                        | <b>[1]</b> + Extension no.                                                                                                      |
| One-touch Dialling <sup>1</sup>                       | <b>[2]</b> + Desired no. (max. 32 digits)                                                                                       |
| Incoming Call Distribution Group (ICD Group)          | <b>[3]</b> <b>[0]</b> + Incoming call distribution group extension no. (+ <b>[#]</b> + delayed ringing time [0–7]) <sup>2</sup> |
| Message                                               | <b>[4]</b> <b>[0]</b>                                                                                                           |
| Message for Another Extension                         | <b>[4]</b> <b>[0]</b> + Extension no./Incoming call distribution group extension no.                                            |
| Call Forwarding (FWD)/Do Not Disturb (DND)—Both calls | <b>[4]</b> <b>[1]</b>                                                                                                           |
| FWD/DND—Outside calls                                 | <b>[4]</b> <b>[2]</b>                                                                                                           |
| FWD/DND—Intercom calls                                | <b>[4]</b> <b>[3]</b>                                                                                                           |
| Group FWD—Both calls                                  | <b>[4]</b> <b>[4]</b> + Incoming call distribution group extension no.                                                          |
| Group FWD—Outside calls                               | <b>[4]</b> <b>[5]</b> + Incoming call distribution group extension no.                                                          |

| Button                                           | Programming Input                                                  |
|--------------------------------------------------|--------------------------------------------------------------------|
| Group FWD—Intercom calls                         | <b>4</b> <b>6</b> + Incoming call distribution group extension no. |
| Account                                          | <b>4</b> <b>8</b>                                                  |
| Conference                                       | <b>4</b> <b>9</b>                                                  |
| Terminate                                        | <b>5</b> <b>0</b>                                                  |
| External Feature Access (EFA)                    | <b>5</b> <b>1</b>                                                  |
| Call Charge Reference                            | <b>5</b> <b>2</b>                                                  |
| Call Park                                        | <b>5</b> <b>3</b> + Parking zone no. (2 digits)                    |
| Call Park (Automatic Park Zone)                  | <b>5</b> <b>3</b> <b>*</b>                                         |
| Call Log <sup>3</sup>                            | <b>5</b> <b>4</b>                                                  |
| Call Log for ICD Group <sup>3</sup>              | <b>5</b> <b>4</b> + Incoming call distribution group extension no. |
| Log-in/Log-out                                   | <b>5</b> <b>5</b>                                                  |
| Log-in/Log-out of a specified group              | <b>5</b> <b>5</b> + Incoming call distribution group extension no  |
| Log-in/Log-out for all groups                    | <b>5</b> <b>5</b> <b>*</b>                                         |
| Hurry-up                                         | <b>5</b> <b>6</b> + Incoming call distribution group extension no. |
| Wrap-up                                          | <b>5</b> <b>7</b>                                                  |
| System Alarm <sup>3</sup>                        | <b>5</b> <b>8</b>                                                  |
| Time Service (Day/Night/Lunch/Break)             | <b>5</b> <b>9</b> + 0/1/2/3 <sup>4</sup> (+ <b>#</b> + Tenant no.) |
| Answer <sup>3</sup>                              | <b>6</b> <b>0</b>                                                  |
| Release <sup>3</sup>                             | <b>6</b> <b>1</b>                                                  |
| Toll Restriction/Call Barring                    | <b>6</b> <b>2</b> + Toll Restriction/Call Barring Level (1–7)      |
| ISDN Service <sup>5</sup>                        | <b>6</b> <b>3</b> + Desired no. (max. 32 digits)                   |
| Calling Line Identification Restriction (CLIR)   | <b>6</b> <b>4</b>                                                  |
| Connected Line Identification Restriction (COLR) | <b>6</b> <b>5</b>                                                  |
| ISDN-Hold                                        | <b>6</b> <b>6</b>                                                  |
| Headset <sup>3,6</sup>                           | <b>6</b> <b>7</b>                                                  |
| Time Service Switching Mode (Automatic/Manual)   | <b>6</b> <b>8</b> (+ Tenant no.)                                   |




### 3.1.3 Customising the Buttons

| Button                                               | Programming Input                                                                                                                             |
|------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------|
| Network Direct Station Selection (NDSS) <sup>7</sup> | <b>6</b> <b>9</b> + Another PBX extension no.                                                                                                 |
| CTI                                                  | <b>7</b> <b>0</b>                                                                                                                             |
| Primary Directory Number (PDN)                       | <b>7</b> <b>1</b>                                                                                                                             |
| Secondary Directory Number (SDN)                     | <b>7</b> <b>2</b> + Extension no. + <b>#</b> + delayed ringing time (0–7) <sup>8</sup>                                                        |
| Check-in <sup>3</sup>                                | <b>8</b> <b>0</b>                                                                                                                             |
| Check-out <sup>3</sup>                               | <b>8</b> <b>1</b>                                                                                                                             |
| Cleaned-up <sup>3</sup>                              | <b>8</b> <b>2</b>                                                                                                                             |
| Two-way Record <sup>9</sup>                          | <b>9</b> <b>0</b> + Voice mail floating extension no. <sup>10</sup>                                                                           |
| Two-way Transfer <sup>9</sup>                        | <b>9</b> <b>1</b> + Voice mail floating extension no. <sup>10</sup>                                                                           |
| One-touch Two-way Transfer <sup>9</sup>              | <b>9</b> <b>1</b> + Voice mail floating extension no. <sup>10</sup> + <b>#</b> + Extension no./Incoming call distribution group extension no. |
| Live Call Screening (LCS) <sup>9</sup>               | <b>9</b> <b>2</b>                                                                                                                             |
| Voice Mail Transfer <sup>9</sup>                     | <b>9</b> <b>4</b> + Voice mail floating extension no. <sup>10</sup>                                                                           |



- \*1 "×", "#", FLASH/RECALL, PAUSE, Secret (INTERCOM) and TRANSFER can also be stored.  
If you do not want to display the stored number when making a call, press the Secret (INTERCOM) button before and after the numbers you wish to conceal.  
If you store an outside party's number, you should first store a line access number.  
If you need to enter an account code, you can enter the specified account code before the line access number.  
<Example>




- \*2 Depending on the settings of your PBX, you may be required to enter delayed ringing time (0: Immediate, 1: 1 ring, 2: 2 rings, 3: 3 rings, 4: 4 rings, 5: 5 rings, 6: 6 rings, 7: No ring). In this case, you can automatically join a new ICD Group by creating a button for that group.
- \*3 This button is not available for a PS.
- \*4 0: Day/Night/Lunch/Break, 1: Day/Night/Break, 2: Day/Night/Lunch, 3: Day/Night
- \*5 Availability of this button depends on the ISDN service of your telephone company. Refer to "1.2.5 Accessing the ISDN Service (ISDN Service Access)".
- \*6 This button is not available for the KX-T7665.
- \*7 The button may not be available depending on the networking method in use or the settings of the PBX.
- \*8 It is possible to set delayed ringing for each SDN button.
- \*9 This button is used for the integrated voice mail features.
- \*10 The default voice mail floating extension number is 500.
- **To exit at any time**, lift the handset.



- You can select the parameter with the Navigator Key (Up or Down) instead of entering a number.


### 3.1.3 Customising the Buttons

To distinguish the ringing tones for each CO, ICD Group, PDN, SDN, or INTERCOM button  
(Digital proprietary telephone only)



- \* Available tone types vary depending on the telephone you are using:
  - KX-NT300 series (except KX-NT321)/KX-NT136/KX-DT300 series (except KX-DT321)/KX-T7600 series (except KX-T7665): Tone types "01" to "30" (01–20: tone, 21–30: melody) are available.
  - KX-NT265/KX-NT321/KX-DT321/KX-T7665: Only tone types "01" to "08" are available. It is possible to enter a tone type number from "09" to "30", but you will hear tone type "01".
  - Other telephones: Only tone types "01" to "08" are available. It is possible to enter a tone type number from "09" to "30", but you will hear tone type "02".
  - Only one ringing tone can be selected for all PDN buttons on your extension.

### To clear the button



## 3.2 Manager Programming

### 3.2.1 Programming Information

The manager can programme the following items.

- Call Charges
- Other Extensions Control

#### **Available Extension**

The extension assigned as a manager

#### **Required Telephone**

A Panasonic Proprietary Telephone with display (over 2 lines)  
(e.g., KX-NT343, KX-DT346, KX-T7636)

#### **Manager Password**

To enter programming mode, the manager password (max. 10 digits) is required. (Default: 1234)

#### **CAUTION**


- The PBX has a default password preset. For security, change the password the first time that you programme the PBX.
- It is strongly recommended that a password of 10 numbers or characters be used for maximum protection against unauthorised access. For a list of numbers and characters that can be used in the password, refer to "◆◆ Entering Characters".
- To avoid unauthorised access to the PBX, keep the password secret. If it becomes known to others, the PBX may be misused.
- Change the password periodically.

#### **Conditions**

The programming extension must be idle, on-hook and holding no calls.

## 3.2.2 Manager Programming

### ◆◆ Changing Call Charges and Extension Control



| Item                                                             | Programming Input                                                                    |
|------------------------------------------------------------------|--------------------------------------------------------------------------------------|
| Changing the manager password.                                   | <b>0</b> <b>0</b> +  + Password (max. 10 digits) +                                   |
| Viewing extension call charges.                                  | <b>0</b> <b>1</b> +  + Extension no.                                                 |
| Clearing extension call charges.                                 | <b>0</b> <b>1</b> +  + Extension no. +  +                                            |
| Setting the budget for extension call charges.                   | <b>0</b> <b>2</b> +  + Extension no. + Charge* +                                     |
| Viewing call charges for each verification code.                 | <b>0</b> <b>3</b> +  + Verification code                                             |
| Clearing call charges for each verification code.                | <b>0</b> <b>3</b> +  + Verification code +  +                                        |
| Setting the budget for each verification code.                   | <b>0</b> <b>4</b> +  + Verification code + Charge* +                                 |
| Viewing call charges for each outside line.                      | <b>0</b> <b>5</b> +  + Outside line no. (3 digits)                                   |
| Assigning a charge rate for each outside line group.             | <b>0</b> <b>6</b> +  + Outside line group no. (2 digits) + Charge rate* +            |
| Clearing all charges.                                            | <b>0</b> <b>7</b> +  +                                                               |
| Printing the total call charge.                                  | <b>0</b> <b>8</b> +  +                                                               |
| Locking/unlocking other extensions. (Remote Extension Dial Lock) | <b>9</b> <b>0</b> +  + Extension no. + <b>1</b> (to lock)/<br><b>0</b> (to unlock) + |
| Clearing the PIN and PIN lock for extensions.                    | <b>9</b> <b>1</b> +  + Extension no. +                                               |
| Clearing the PIN and PIN lock for verification codes.            | <b>9</b> <b>2</b> +  + Verification code +                                           |

| Item                               | Programming Input                                                                                                                                                                                                                                                                                                              |
|------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Setting the verification code PIN. | <div><div>9</div><div>3</div><div>+</div><div></div><div>+</div><div>Verification code + PIN (max. 10 digits)</div></div> <div><div>+</div><div></div></div> |



**CAUTION**

- There is a risk that fraudulent telephone calls will be made if a third party discovers your password (verification code PIN).  
The cost of such calls will be billed to the owner/renter of the PBX.  
To protect the PBX from this kind of fraudulent use, we strongly recommend:
- a.** Keeping your PIN secret.
  - b.** Selecting a complex, random PIN that cannot be easily guessed.
  - c.** Changing your PIN regularly.
- \* To enter a decimal point, press ✕ .

## 3.3 Customising Your System (System Programming)

### 3.3.1 Programming Information

You can customise your system according to your requirements.  
[Your system already has default settings (factory installed).]

**The programming is shown below. (Programme number)**

- The date and time [000]
- System speed dialling numbers and names [001]/[002]
- Extension number and name [003]/[004]

#### **Available Extension**

The extension allowed through COS programming

#### **Required Telephone**

A Panasonic Proprietary Telephone with display (over 2 lines)  
(e.g., KX-NT343, KX-DT346, KX-T7636)

#### **System Password**

To enter programming mode, the system password (max. 10 digits) is required. (Default: 1234)

#### **CAUTION**

- The PBX has a default password preset. For security, change the password the first time that you programme the PBX.
- It is strongly recommended that a password of 10 numbers or characters be used for maximum protection against unauthorised access. For a list of numbers and characters that can be used in the password, refer to "◆◆ Entering Characters".
- To avoid unauthorised access to the PBX, keep the password secret. If it becomes known to others, the PBX may be misused.
- Change the password periodically.

#### **Conditions**

The programming extension must be idle, on-hook and holding no calls.

#### **List**

Before programming, decide the settings and write them down. Your notes will provide a useful record of the programming for future reference. Your dealer also has programming records which contain all of the system programming. You may ask for photocopies of these tables to be aware of the facilities and features available.

## ◆◆ Icon Descriptions

| Fixed Buttons     |                   | Function                          |
|-------------------|-------------------|-----------------------------------|
| KX-NT300/KX-DT300 | KX-NT136/KX-T7600 |                                   |
|                   |                   | PREVIOUS (PREV)                   |
|                   |                   | NEXT                              |
|                   |                   | ➡                                 |
|                   |                   | ➡                                 |
|                   |                   | STORE (ENTER)                     |
|                   |                   | Back to Previous Menu<br>(CANCEL) |
|                   |                   | SHIFT                             |
|                   |                   | PROGRAM                           |
|                   |                   | END                               |
|                   |                   | SELECT                            |
|                   |                   | FLASH                             |
|                   |                   | CLEAR                             |
|                   |                   | SECRET                            |

## ◆◆ Procedure


The basic steps are shown below.



### 3.3.1 Programming Information

---

#### 1. *Entering the programming mode*




#### 2. *Programming*

You can enter each programme number (3 digits).



- To exit the programming mode at any time, lift the handset.

#### 3. *Exiting the mode*




- To exit the programming mode at any time, lift the handset.

### 3.3.2 System Programming


#### ◆◆ Date & Time [000]

The proprietary telephones display the current date and time while on-hook.

[In 12-hour Format]



[In 24-hour Format]






- **After changing the desired values**, you can press the ENTER button. You do not have to perform the rest of the steps.
- The clock starts immediately after the ENTER button is pressed.
- You cannot leave a value empty.
- You can clear the entry by pressing the CLEAR button.
- **To confirm your entry after storing data:**
  - The STORE button light: Lights red
  - Confirmation Tone:  
One beep: Your entry is accepted.  
Three beeps: Your entry is rejected.

## ◆◆ System Speed Dialling Number [001]

You can store the phone numbers of frequently dialled destinations.




- If the desired number is more than 32 digits, divide the number and store it into more than one speed dialling number.
- "\*", "#", FLASH/RECALL, PAUSE, and Secret (INTERCOM) can also be stored.  
If you do not want to display the stored number when making a call, press the Secret (INTERCOM) button before and after the numbers you wish to conceal.  
If you store an outside party's number, you should first store a line access number.  
If you need to enter an account code, you can enter the specified account code before the line access number.  
<Example>

|                          |              |                        |                              |                    |
|--------------------------|--------------|------------------------|------------------------------|--------------------|
| *49                      | 1234         | #                      | 0/9                          | SECRET<br>123 4567 |
| Account code feature no. | Account code | Account code delimiter | Automatic line access number | Phone number       |


### ◆◆ System Speed Dialling Name [002]

You can store the name associated with the speed dialling number. These names are displayed when making calls using the display operation. To enter characters, refer to "◆◆ Entering Characters".



### ◆◆ Extension Number [003]

You can assign an extension number to each extension.




- The leading number(s) should be the same as the number(s) assigned for Flexible Numbering.
- A duplicate entry is invalid.

### ◆◆ Extension Name [004]

You can store the name of an extension user. This is useful if you want to know who is calling, or who you are calling when making an intercom call using the directory.

To enter characters, refer to "◆◆ Entering Characters".



---

## **Section 4**

# **Appendix**

*This chapter provides the Troubleshooting, the Feature Number Table and Tone List. Check the Troubleshooting section before consulting your dealer.*

## 4.1 Troubleshooting

### 4.1.1 Troubleshooting

#### ◆◆ Troubleshooting

| Problem                                                                                                                            | Remedy                                                                                                                                                                                                                                                                                                                                                                                                       |
|------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| The telephone does not work properly.                                                                                              | <ul style="list-style-type: none"> <li>➡ Confirm with your manager that your settings are correct.</li> <li>➡ If the problem persists, consult your dealer.</li> </ul>                                                                                                                                                                                                                                       |
| The telephone does not respond when buttons are pressed.                                                                           | <ul style="list-style-type: none"> <li>• <b>The telephone is locked.</b><br/>➡ Unlock your telephone. (👉 1.6.4 Preventing Other People from Using Your Telephone (Extension Dial Lock), 2.1.1 Extension Control)</li> </ul>                                                                                                                                                                                  |
| Some features do not work.                                                                                                         | <ul style="list-style-type: none"> <li>• <b>System management may restrict certain features.</b><br/>➡ Consult your manager.</li> <li>• <b>The feature numbers have changed.</b><br/>➡ Confirm the revised number and try again.</li> </ul>                                                                                                                                                                  |
| Even though following the manual instructions, none of the operations work when using a proprietary telephone.                     | <ul style="list-style-type: none"> <li>• <b>The Intercom line was not seized.</b> The seized line, when going off-hook, was changed by personal setting. (👉 3.1.2 Settings on the Programming Mode)<br/>➡ In the manual, going off-hook means an Intercom line is seized.<br/>If the setting has been changed, press the INTERCOM or PDN button after going off-hook and follow the instructions.</li> </ul> |
| The telephone does not work using the personal settings or with other settings. (One-touch dialling, forwarding destination, etc.) | <ul style="list-style-type: none"> <li>• <b>The extension line has been changed.</b> The previous telephone's settings have not been cleared.<br/>➡ Clear the settings and then programme your desired settings again. (👉 1.8.12 Clearing Features Set at Your Extension (Extension Feature Clear), 3.1.1 Customising Your Phone (Personal Programming), 3.1.3 Customising the Buttons)</li> </ul>           |
| My proprietary telephone does not have a feature button.                                                                           | <ul style="list-style-type: none"> <li>• <b>Some models do not have the feature button.</b><br/>➡ Change a flexible button to the desired button. (👉 3.1.3 Customising the Buttons)<br/>➡ Enter the specified feature number instead of the feature button. (👉 1.1.1 Before Operating the Telephones)</li> </ul>                                                                                             |

| Problem                                                                              | Remedy                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
|--------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| A reorder tone is audible or "Restricted" is displayed.                              | <ul style="list-style-type: none"> <li>• <b>The telephone is locked.</b><br/>➡ Unlock your telephone. (👉 1.6.4 Preventing Other People from Using Your Telephone (Extension Dial Lock), 2.1.1 Extension Control)</li> <li>• <b>Toll restriction is activated.</b><br/>➡ Consult your manager or dealer.</li> <li>• <b>An account code is required.</b> (👉 1.2.7 Calling without Restrictions, ♦♦ Using an Account Code (Account Code Entry) in 1.2.1 Basic Calling)</li> </ul> |
| I cannot make an outside call using the One-touch Dialling button or speed dialling. | <ul style="list-style-type: none"> <li>• <b>A line access number was not stored.</b><br/>➡ A line access number is required for outside calls. (👉 1.2.1 Basic Calling, 3.1.3 Customising the Buttons)</li> </ul>                                                                                                                                                                                                                                                               |
| I cannot remember the feature numbers.                                               | <ul style="list-style-type: none"> <li>• ➡ If the feature numbers have been changed from the default values, write the new feature numbers in the table in "4.2.1 Feature Number Table".</li> <li>• ➡ Ask your dealer to change the feature numbers for easier use.</li> </ul>                                                                                                                                                                                                 |
| While talking to an outside party, the line is disconnected.                         | <ul style="list-style-type: none"> <li>• <b>The time limit has run out.</b> (👉 1.4.1 Transferring a Call (Call Transfer), 1.4.5 Multiple Party Conversation)<br/>➡ Consult your dealer to extend the time limit, if necessary.</li> </ul>                                                                                                                                                                                                                                      |
| Redialling does not function.                                                        | <ul style="list-style-type: none"> <li>• <b>The stored number was more than 32 digits or an extension number.</b> (👉 1.2.3 Redial)</li> </ul>                                                                                                                                                                                                                                                                                                                                  |
| I cannot have a conversation using the Bluetooth headset.                            | <ul style="list-style-type: none"> <li>• ➡ Make sure that the headset is properly registered to the module.</li> <li>• ➡ Make sure that the headset is properly charged according to the manual of the headset.</li> <li>• ➡ Remove the wired headset from the headset jack. Priority is given to the wired headset when both are connected.</li> </ul>                                                                                                                        |
| I cannot register, de-register, or confirm the ID of the Bluetooth headset.          | <ul style="list-style-type: none"> <li>• ➡ Make sure that the module is properly installed in the IP-PT/DPT.</li> </ul>                                                                                                                                                                                                                                                                                                                                                        |
| The PC and fax machine communication failed.                                         | <ul style="list-style-type: none"> <li>• <b>An indication tone may have interrupted communication.</b> (👉 1.8.9 Protecting Your Line against Notification Tones (Data Line Security))</li> </ul>                                                                                                                                                                                                                                                                               |



| Problem                                                                               | Remedy                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
|---------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| I do not want to show my telephone number to the calling or called party's telephone. | <ul style="list-style-type: none"> <li>( 1.8.5 Preventing Your Telephone Number Being Displayed on the Caller's Telephone (Connected Line Identification Restriction [COLR]), 1.8.6 Preventing Your Number Being Displayed on the Called Party's Telephone (Calling Line Identification Restriction [CLIR]))</li> </ul>                                                                                                                                                                                                                                                                                                  |
| I want to show my telephone number to the calling or called party's telephone.        | <ul style="list-style-type: none"> <li>( 1.8.4 Displaying Your Telephone Number on the Called Party and Caller's Telephone (Calling/Connected Line Identification Presentation [CLIP/COLP]))</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                  |
| I cannot send a call waiting tone to the dialled extension.                           | <ul style="list-style-type: none"> <li>• <b>The other party has not set the Call Waiting feature.</b><br/>(  Sending a Call Waiting Notification (Call Waiting), 1.4.4 Answering Call Waiting, 1.8.3 Receiving Call Waiting (Call Waiting/Off-hook Call Announcement [OHCA]/Whisper OHCA))</li> <li>• <b>The other party has set Data Line Security.</b><br/>( 1.8.9 Protecting Your Line against Notification Tones (Data Line Security))</li> </ul> |
| I forgot the password.                                                                | <ul style="list-style-type: none"> <li>• Ask the manager to assist you.<br/>( 2.1.1 Extension Control)</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| The background music started suddenly.                                                | <ul style="list-style-type: none"> <li>• ➡ Turn off the music.<br/>( 1.8.8 Turning on the Background Music (BGM), 2.1.4 Turning on the External Background Music (BGM))</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| I do not want to display a number which is stored in memory.                          | <ul style="list-style-type: none"> <li>• ➡ Conceal the number.<br/>(  Storing Names and Numbers, 3.1.3 Customising the Buttons)</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                          |
| I want to confirm my extension number.                                                | <ul style="list-style-type: none"> <li>• ( Your Extension Number in 1.1.1 Before Operating the Telephones)</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| The date and time are not correct.                                                    | <ul style="list-style-type: none"> <li>• <b>Set the date and time by system programming.</b><br/>(  Date &amp; Time [000] in 3.3.2 System Programming)</li> </ul>                                                                                                                                                                                                                                                                                                                                                                   |
| The display is not shown well.                                                        | <ul style="list-style-type: none"> <li>• ➡ Change the Display contrast level.<br/>( 3.1.2 Settings on the Programming Mode)</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| I want to distinguish the tones.                                                      | <ul style="list-style-type: none"> <li>• ( To distinguish the ringing tones for each CO, ICD Group, PDN, SDN, or INTERCOM button (Digital proprietary telephone only), 3.1.3 Customising the Buttons)</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                       |

| Problem                                      | Remedy                                                                                                                                                                                                                                                             |
|----------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| The MESSAGE button light lit.                | <ul style="list-style-type: none"><li>• Another extension left you a message waiting indication while you were on the phone or away from your desk.</li></ul>                                                                                                      |
| An SDN button on my extension does not work. | <ul style="list-style-type: none"><li>• A PDN button is not assigned on the extension corresponding to your SDN button.<ul style="list-style-type: none"><li>➡ Create a PDN button on the desired extension. (👉 3.1.3 Customising the Buttons)</li></ul></li></ul> |

## 4.2 Feature Number Table

### 4.2.1 Feature Number Table

Numbers listed below are the default settings. There are flexible feature numbers and fixed feature numbers. If you change the flexible feature numbers, fill in your assigned numbers (new) in the list for future reference.

| Feature (While dial tone is heard)                                                                                                                                                                                                                                                                                                                                    | Default (New)                                                                                | Additional digits/buttons                                                                                                                                                   |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>1.2.1 Basic Calling</b><br>To call an operator (Operator Call)<br>To select an idle outside line automatically (Automatic Line Access)<br>To select an idle outside line in the specified outside line group automatically (Outside Line Group Access)<br>◆◆ Making a Call to a Private Network (TIE Line Access)<br>◆◆ Using an Account Code (Account Code Entry) | 9/0<br>(       )<br>0/9<br>(       )<br>8<br>(       )<br>7<br>(       )<br>*49<br>(       ) | outside phone no.<br>outside line group no. (2 digits) + outside phone no.<br>private phone no.<br>account code + # + outside phone no.                                     |
| <b>1.2.2 Easy Dialling</b><br>◆◆ Using Numbers Stored at Your Extension (Personal Speed Dialling)<br>– To store<br>– To dial<br>◆◆ Using Numbers Stored in the PBX (System Speed Dialling)<br>– To dial<br>◆◆ To a Preset Number by Going Off-hook (Hot Line)<br>– To store<br>– To set<br>– To cancel                                                                | *30<br>(       )<br>**<br>(       )<br>**<br>(       )<br>*740<br>(       )                  | personal speed dialling no. (2 digits) + phone no. + #<br>* + personal speed dialling no. (2 digits)<br>system speed dialling no. (3 digits)<br>2 + phone no. + #<br>1<br>0 |
| <b>1.2.3 Redial</b><br>◆◆ Redialling the Last Number You Dialed (Last Number Redial)                                                                                                                                                                                                                                                                                  | #<br>(       )                                                                               |                                                                                                                                                                             |

| Feature (While dial tone is heard)                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              | Default (New)                                     | Additional digits/buttons                                                                                                                                                                                           |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <p>1.2.4 When the Dialed Line is Busy or There is No Answer</p> <p>To cancel callback ringing (Automatic Callback Busy Cancel)/To cancel (CCBS Cancel)</p> <p>◆◆ Leaving a Message Waiting Indication/Calling Back the Caller Who Left an Indication (Message Waiting)</p> <p>For an extension leaving a message waiting indication</p> <ul style="list-style-type: none"> <li>– To leave/cancel</li> </ul> <p>For an extension receiving a message waiting indication</p> <ul style="list-style-type: none"> <li>– To call back</li> <li>– To clear</li> </ul> | <p>✖46<br/>(       )</p> <p>✖70<br/>(       )</p> | <p>1/0 + extension no.</p> <p>2</p> <p>0 + your extension no.</p>                                                                                                                                                   |
| <p>1.2.7 Calling without Restrictions</p> <p>◆◆ Using Your Calling Privileges at Another Extension (Remote COS Access)</p> <p>To call with a verification code (Verification Code Entry)</p>                                                                                                                                                                                                                                                                                                                                                                    | <p>✖47<br/>(       )</p>                          | <p>extension no. + extension PIN + phone no.</p> <p>✖ + verification code + verification code PIN + phone no.</p>                                                                                                   |
| <p>1.2.8 To Access Another Party Directly from Outside (Direct Inward System Access [DISA])</p> <p>◆◆ Calling through DISA</p> <ul style="list-style-type: none"> <li>– To an extension (In All Security Mode only)</li> <li>– To an outside party (In Trunk Security Mode/All Security Mode only)</li> </ul>                                                                                                                                                                                                                                                   |                                                   | <p>your extension no./(✖ + verification code) + extension PIN/verification code PIN + extension no.</p> <p>your extension no./(✖ + verification code) + extension PIN/verification code PIN + outside phone no.</p> |
| <p>1.2.9 Setting Your Telephone from Another Extension or through DISA (Remote Setting)</p> <ul style="list-style-type: none"> <li>– From another extension</li> <li>– Through DISA</li> </ul>                                                                                                                                                                                                                                                                                                                                                                  |                                                   | <p>your extension no. + extension PIN + feature no.</p>                                                                                                                                                             |
| <p>1.3.3 Answering a Call Ringing at Another Telephone (Call Pickup)</p> <p>◆◆ Answering a Call from Another Telephone (Call Pickup)</p>                                                                                                                                                                                                                                                                                                                                                                                                                        |                                                   |                                                                                                                                                                                                                     |

#### 4.2.1 Feature Number Table

| Feature (While dial tone is heard)                                                                                                                                                                                                                                                                                                                                                                                                      | Default (New)                                                                | Additional digits/buttons                                                                                                                                           |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <ul style="list-style-type: none"> <li>Group</li> <li>Directed</li> </ul>                                                                                                                                                                                                                                                                                                                                                               | *40<br>(       )<br>*41<br>(       )<br>*720<br>(       )                    | group no. (2 digits)<br><br>extension no.<br><br><br>1<br>0                                                                                                         |
| ◆◆ Denying Other People the Possibility of Picking Up Your Calls (Call Pickup Deny) <ul style="list-style-type: none"> <li>To deny</li> <li>To allow</li> </ul>                                                                                                                                                                                                                                                                         |                                                                              |                                                                                                                                                                     |
| 1.3.4 Answering a Call via an External Speaker (Trunk Answer From Any Station [TAFAS]) <ul style="list-style-type: none"> <li>Calls through an external speaker</li> </ul>                                                                                                                                                                                                                                                              | *42<br>(       )                                                             | speaker no. (1 digit)                                                                                                                                               |
| 1.3.6 Identifying Malicious Calling Parties (Malicious Call Identification [MCID])                                                                                                                                                                                                                                                                                                                                                      | *7*3<br>(       )                                                            |                                                                                                                                                                     |
| 1.4.1 Transferring a Call (Call Transfer) <ul style="list-style-type: none"> <li>◆◆ Transferring a Call Using the ISDN Service (Call Transfer [CT]—by ISDN)</li> </ul>                                                                                                                                                                                                                                                                  | *62<br>(       )                                                             | phone no.                                                                                                                                                           |
| 1.4.2 Holding a Call <ul style="list-style-type: none"> <li>To hold (Call Hold)/To retrieve a call (Call Hold Retrieve)</li> <li>To retrieve a call (Call Hold Retrieve)</li> <li>Specified with a held line number</li> <li>Specified with a holding extension number</li> <li>◆◆ Holding in a System Parking Zone (Call Park)               <ul style="list-style-type: none"> <li>To set</li> <li>To retrieve</li> </ul> </li> </ul> | *50<br>(       )<br>*53<br>(       )<br>*51<br>(       )<br>*52<br>(       ) | outside line no. which is held (3 digits)<br><br>extension no. which has a held call<br><br><br>parking zone no. (2 digits)/*<br>stored parking zone no. (2 digits) |
| 1.4.4 Answering Call Waiting <ul style="list-style-type: none"> <li>◆◆ Answering Call Waiting in the PBX</li> <li>◆◆ Answering Call Waiting from the Telephone Company</li> </ul>                                                                                                                                                                                                                                                       | *50<br>(       )<br>*60<br>(       )                                         |                                                                                                                                                                     |
| 1.4.5 Multiple Party Conversation                                                                                                                                                                                                                                                                                                                                                                                                       |                                                                              |                                                                                                                                                                     |

| Feature (While dial tone is heard)                                                                                              | Default (New)     | Additional digits/buttons                                                                                                                                                                                                |
|---------------------------------------------------------------------------------------------------------------------------------|-------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| ◆◆ Adding a Third Party during a Conversation Using the ISDN Service (Three-party Conference [3PTY]—by ISDN)                    | *62<br>(       )  | phone no. + TRANSFER button + 3                                                                                                                                                                                          |
| 1.6.1 Forwarding Calls<br>◆◆ Forwarding Your Calls (Call Forwarding [FWD])/1.8.2 Refusing Incoming Calls (Do Not Disturb [DND]) |                   |                                                                                                                                                                                                                          |
| – Both Calls                                                                                                                    | *710<br>(       ) | 0 (Cancel)/                                                                                                                                                                                                              |
| – Outside Calls                                                                                                                 | *711<br>(       ) | 1 (Do Not Disturb [DND])/                                                                                                                                                                                                |
| – Intercom Calls                                                                                                                | *712<br>(       ) | 2 (All calls) + phone no. + #/<br>3 (Busy) + phone no. + #/<br>4 (No Answer) + phone no. + #/<br>5 (Busy/No Answer) + phone no. + #/<br>7 (Follow Me) + your extension no./<br>8 (Follow Me Cancel) + your extension no. |
| – To set the timer for "No Answer" and "Busy/No Answer"                                                                         | *713<br>(       ) | 00–99 (second)                                                                                                                                                                                                           |
| To set/cancel (Call Forwarding [FWD] for your Incoming Call Distribution Group)                                                 |                   |                                                                                                                                                                                                                          |
| – Both Calls                                                                                                                    | *714<br>(       ) | 1 (Set) + ICD Group extension no. + phone no. + #/0 (Cancel) + ICD Group extension no.                                                                                                                                   |
| – Outside Calls                                                                                                                 | *715<br>(       ) |                                                                                                                                                                                                                          |
| – Intercom Calls                                                                                                                | *716<br>(       ) |                                                                                                                                                                                                                          |
| ◆◆ Forwarding Your Calls Using ISDN Service (Call Forwarding [CF]—by ISDN)                                                      | *7*5<br>(       ) |                                                                                                                                                                                                                          |
| – To set                                                                                                                        |                   | outside line no. + # + multiple subscriber no. + # + 2 (Unconditional)/3 (Busy)/4 (No Reply) + phone no. + #                                                                                                             |
| – To cancel                                                                                                                     |                   | outside line no. + # + multiple subscriber no. + # + 0                                                                                                                                                                   |
| – To confirm                                                                                                                    |                   | outside line no. + # + multiple subscriber no. + # + 1                                                                                                                                                                   |

#### 4.2.1 Feature Number Table

| Feature (While dial tone is heard)                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                | Default (New)                                                                                          | Additional digits/buttons                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <p>1.6.2 Using Voice Messaging (Built-in Simplified Voice Message [SVM])</p> <p>◆◆ Recording a Normal Greeting Message</p> <ul style="list-style-type: none"> <li>– To record</li> <li>– To play back</li> <li>– To clear</li> </ul> <p>◆◆ Recording a Greeting Message for Each Time Mode</p> <ul style="list-style-type: none"> <li>– To record</li> <li>– To play back</li> <li>– To clear</li> </ul> <p>To leave a voice message directly to another extension's message box</p> <p>◆◆ Listening to Voice Messages Left by Callers</p> <p>◆◆ Redirecting Your Calls to Your Message Box</p> <ul style="list-style-type: none"> <li>– Both Calls</li> <li>– Outside Calls</li> <li>– Intercom Calls</li> </ul> | <p>✱38<br/>(       )</p> <p>✱710<br/>(       )</p> <p>✱711<br/>(       )</p> <p>✱712<br/>(       )</p> | <p>1</p> <p>2</p> <p>0</p> <p>8 + 0 (Day)/1 (Night)/2 (Lunch)/3 (Break) + 1</p> <p>8 + 0 (Day)/1 (Night)/2 (Lunch)/3 (Break) + 2</p> <p>8 + 0 (Day)/1 (Night)/2 (Lunch)/3 (Break) + 0</p> <p># + 6 + extension no.</p> <p>3</p> <p>0 (Cancel)/</p> <p>2 (All Calls) + floating extension no. for SVM card<sup>5</sup> + #/</p> <p>3 (Busy) + floating extension no. for SVM card<sup>5</sup> + #/</p> <p>4 (No Answer) + floating extension no. for SVM card<sup>5</sup> + #/</p> <p>5 (Busy/No Answer) + floating extension no. for SVM card<sup>5</sup> + #</p> |
| <p>1.6.3 Showing a Message on the Caller's Telephone Display (Absent Message)</p> <ul style="list-style-type: none"> <li>– To set</li> <li>– To cancel</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 | <p>✱750<br/>(       )</p>                                                                              | <p>1–9 (+ parameter) + #</p> <p>0</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
| <p>1.6.4 Preventing Other People from Using Your Telephone (Extension Dial Lock)</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              | <p>✱77<br/>(       )</p>                                                                               |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |

| Feature (While dial tone is heard)                                                                                                                                                                                                                | Default (New)                          | Additional digits/buttons                                                                                   |
|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------|-------------------------------------------------------------------------------------------------------------|
| <ul style="list-style-type: none"> <li>– To lock</li> <li>– To unlock</li> <li>– To make an outside call while your extension is locked</li> </ul>                                                                                                | *47<br>(       )                       | 1<br>0 + extension PIN<br>your extension no. + extension PIN + phone no.                                    |
| 1.7.1 Paging<br>◆◆ Group Paging                                                                                                                                                                                                                   | *33<br>(       )                       | paging group no. (2 digits)                                                                                 |
| 1.7.2 Answering/Denying a Paging Announcement<br><ul style="list-style-type: none"> <li>– To answer</li> <li>– To deny</li> <li>– To allow</li> </ul>                                                                                             | *43<br>(       )<br>*721<br>(       )  | 1<br>0                                                                                                      |
| 1.7.3 Making an Announcement and Having a Multiple Party Conversation (Broadcasting)<br><ul style="list-style-type: none"> <li>– To call and make an announcement</li> </ul>                                                                      | *32<br>(       )                       | broadcasting group no. (1 digit)                                                                            |
| 1.8.1 Setting the Alarm (Timed Reminder)<br><ul style="list-style-type: none"> <li>– To set</li> <li>– To cancel</li> </ul>                                                                                                                       | *760<br>(       )                      | 12H: 1 + hour/minute + 0 (AM)/1 (PM) + 0 (once)/1 (daily)<br>24H: 1 + hour/minute + 0 (once)/1 (daily)<br>0 |
| 1.8.3 Receiving Call Waiting (Call Waiting/Off-hook Call Announcement [OHCA]/Whisper OHCA)<br><ul style="list-style-type: none"> <li>– For intercom calls (No call/Tone/OHCA/Whisper OHCA)</li> <li>– For outside calls (No tone/Tone)</li> </ul> | *731<br>(       )<br>*732<br>(       ) | 0 (No call)/1 (Tone)/2 (OHCA)/3 (Whisper OHCA)<br>0 (No tone)/1 (Tone)                                      |
| 1.8.4 Displaying Your Telephone Number on the Called Party and Caller's Telephone (Calling/Connected Line Identification Presentation [CLIP/ COLP])<br><ul style="list-style-type: none"> <li>– Public</li> <li>– Your extension</li> </ul>       | *7*2<br>(       )                      | 1<br>2                                                                                                      |



#### 4.2.1 Feature Number Table

| Feature (While dial tone is heard)                                                                                                                                      | Default (New)                                | Additional digits/buttons                                                                 |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------|-------------------------------------------------------------------------------------------|
| <b>1.8.5 Preventing Your Telephone Number Being Displayed on the Caller's Telephone (Connected Line Identification Restriction [COLR])</b><br>– To show<br>– To prevent | *7*0<br>(        )                           | 0<br>1                                                                                    |
| <b>1.8.6 Preventing Your Number Being Displayed on the Called Party's Telephone (Calling Line Identification Restriction [CLIR])</b><br>– To show<br>– To prevent       | *7*1<br>(        )                           | 0<br>1                                                                                    |
| <b>1.8.7 Preventing Other People from Joining Your Conversation (Executive Busy Override Deny)</b><br>– To prevent<br>– To allow                                        | *733<br>(        )                           | 1<br>0                                                                                    |
| <b>1.8.8 Turning on the Background Music (BGM)</b><br>– To set<br>– To cancel                                                                                           | *751<br>(        )                           | BGM no. (1 digit)<br>0                                                                    |
| <b>1.8.9 Protecting Your Line against Notification Tones (Data Line Security)</b><br>– To set<br>– To cancel                                                            | *730<br>(        )                           | 1<br>0                                                                                    |
| <b>1.8.11 Using Your PS in Parallel with a Wired Telephone (Wireless XDP Parallel Mode)</b><br>– To set<br>– To cancel                                                  | *48<br>(        )                            | 1 + paired wired extension no.<br>0                                                       |
| <b>1.8.12 Clearing Features Set at Your Extension (Extension Feature Clear)</b>                                                                                         | *790<br>(        )                           |                                                                                           |
| <b>1.9.1 Leaving an Incoming Call Distribution Group (Log-in/Log-out, Wrap-up)</b><br>Log-in<br>Log-out<br>To enter/leave Not Ready mode                                | *736<br>(        )<br><br>*735<br>(        ) | 1 + ICD Group extension no./*<br>0 + ICD Group extension no./*<br>1 (Not Ready)/0 (Ready) |

| Feature (While dial tone is heard)                                                                                                                                                                                               | Default (New)                                                       | Additional digits/buttons                                                                                                                                                                |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <sup>*3</sup> 1.9.2 Monitoring and Controlling the Call Status of an Incoming Call Distribution Group (Incoming Call Distribution Group Monitor)                                                                                 | *739<br>(       )                                                   | ICD Group extension no.                                                                                                                                                                  |
| 1.10.1 If a Doorphone/Door Opener is Connected<br>◆◆ Doorphone Call<br><br>◆◆ Opening a Door (Door Open)                                                                                                                         | *31<br>(       )<br><br>*55<br>(       )                            | doorphone no. (2 digits)<br><br>doorphone no. (2 digits)                                                                                                                                 |
| 1.10.2 If an External Relay is Connected                                                                                                                                                                                         | *56<br>(       )                                                    | relay no. (2 digits)                                                                                                                                                                     |
| 1.10.4 If a Host PBX is Connected<br>◆◆ Accessing External Services (External Feature Access [EFA])                                                                                                                              | *60<br>(       )                                                    | service code                                                                                                                                                                             |
| 1.10.5 If a Voice Processing System is Connected<br>◆◆ Call Forwarding to Voice Mail (Voice Mail Integration)<br>– Both Calls<br><br>– Outside Calls<br><br>– Intercom Calls                                                     | *710<br>(       )<br><br>*711<br>(       )<br><br>*712<br>(       ) | 0 (Cancel)/<br><br>2 (All Calls)/<br><br>3 (Busy)/<br>4 (No Answer)/<br>5 (Busy/No Answer)<br>+ voice mail floating extension no. <sup>*6</sup> + #                                      |
| 1.11.1 Using the Telephones in a Hotel-type Environment (Hospitality Features)<br><sup>*4</sup> ◆◆ Setting a Timed Reminder to a Room Extension (Remote Wake-up Call)<br>– To set<br><br><br><br>– To cancel<br><br>– To confirm | *76*<br>(       )                                                   | 12H: 1 + extension no. + hour/minute + 0 (AM)/1 (PM) + 0 (once)/1 (daily)<br>24H: 1 + extension no. + hour/minute + 0 (once)/1 (daily)<br><br>0 + extension no.<br><br>2 + extension no. |
| 1.11.2 Recording Information Using Preprogrammed Messages (Printing Message)                                                                                                                                                     | *761<br>(       )                                                   | message no. (+ parameter) + #                                                                                                                                                            |

#### 4.2.1 Feature Number Table

| Feature (While dial tone is heard)                                                                                                       | Default (New)                            | Additional digits/buttons                                                                                                                                             |
|------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1.12.1 Using the Same Settings as Your Previous Extension (Walking Extension)                                                            | *727<br>(        )                       | your previous extension no. + extension PIN                                                                                                                           |
| 2.1.1 Extension Control<br>*1 To lock/unlock other extensions (Remote Extension Dial Lock)<br>– To unlock<br>– To lock                   | *782<br>(        )<br>*783<br>(        ) | extension no.<br>extension no.                                                                                                                                        |
| *2 2.1.2 Time Service Mode Control<br>– Day/Night/Lunch/Break                                                                            | *780<br>(        )                       | 0/1/2/3                                                                                                                                                               |
| *1 2.1.4 Turning on the External Background Music (BGM)<br>– To start<br>– To stop                                                       | *35<br>(        )                        | external pager no. (1 digit)/* + BGM no. (1 digit)<br>external pager no. (1 digit)/* + 0                                                                              |
| *1 2.1.5 Recording Outgoing Messages (OGM)<br>– To record<br>– To play back<br>– To record from an external BGM (MOH) port<br>– To clear | *36<br>(        )                        | 1 + OGM floating extension no.*7<br>2 + OGM floating extension no.*7<br>3 + BGM port no. (1 digit) + OGM floating extension no.*7<br>0 + OGM floating extension no.*7 |
| *1 2.1.6 Allowing Users to Seize an Unavailable Outside Line (Trunk Busy Out)                                                            | *785<br>(        )                       | outside line no. (3 digits)                                                                                                                                           |
| *1 2.1.7 Releasing Network Direct Station Selection (NDSS) Monitor                                                                       | *784<br>(        )                       | another PBX extension no. + #                                                                                                                                         |

| Feature (While dial tone is heard)                                                                                                                                                        | Default (New)      | Additional digits/buttons                                                  |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------|----------------------------------------------------------------------------|
| <b>3.1.1 Customising Your Phone (Personal Programming)</b><br>◆◆ Assigning an Extension PIN to Your Extension (Extension PIN [Personal Identification Number])<br>– To set<br>– To cancel | ✕799<br>(        ) | 1 + extension PIN + # + same extension PIN + #<br>0 + stored extension PIN |

\*1 Manager only

\*2 Manager and preprogrammed extension user only

\*3 Supervisor only

\*4 Hotel operator only

\*5 The default floating extension numbers are 591 for SVM card 1, and 592 for SVM card 2.

\*6 The default voice mail floating extension number is 500.

\*7 The default of OGM floating extension numbers is 5xx (xx: two-digit number of message).

| Feature (While busy, DND or call tone is heard)                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  | Default                       |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------|
| <b>1.2.4 When the Dialed Line is Busy or There is No Answer</b><br>◆◆ Sending a Call Waiting Notification (Call Waiting)<br>◆◆ To an Extension Refusing the Call (DND Override)<br>◆◆ Joining an Existing Call (Executive Busy Override)<br>◆◆ Leaving a Message Waiting Indication/Calling Back the Caller Who Left an Indication (Message Waiting)<br>◆◆ Monitoring Another Extension (Call Monitor)<br>◆◆ Reserving a Busy Line (Automatic Callback Busy)/◆◆ Setting Callback on an ISDN Line (Completion of Calls to Busy Subscriber [CCBS]) | 1<br><br><br>3<br>4<br>5<br>6 |
| <b>1.2.6 Alternating the Calling Method (Alternate Calling—Ring/Voice)</b>                                                                                                                                                                                                                                                                                                                                                                                                                                                                       | ✕                             |

| Feature (While dialling or talking)                                                                        | Fixed Number |
|------------------------------------------------------------------------------------------------------------|--------------|
| <b>1.4.5 Multiple Party Conversation</b><br>◆◆ Adding Other Parties during a Conversation (Conference)     | 3            |
| <b>1.10.1 If a Doorphone/Door Opener is Connected</b><br>From any extension while talking to the doorphone | 5            |

# 4.3 What is This Tone?


## 4.3.1 What is This Tone?

### While on-hook

#### Ring Tones

The following tones are programmable allowing recognition of call type (Outside, Intercom or Doorphone).

##### Tone 1




##### Tone 2



##### Tone 3



##### Tone 4




### When going off-hook

#### Dial Tones


##### Tone 1

Normal



**Tone 2**


- When there are messages that have previously been listened to and no new messages on the SVM card
- When any of the following features are set:
  - Absent Message
  - Background Music
  - Call Forwarding
  - Call Pickup Deny
  - Call Waiting
  - Do Not Disturb
  - Extension Dial Lock
  - Executive Busy Override Deny
  - Hot Line
  - Timed Reminder

**Tone 3**


- After pressing TRANSFER or Recall/hookswitch to hold a call temporarily (e.g., Call Splitting)
- When the recording space of the Built-in Simplified Voice Message feature becomes almost full
- While a called PS is being searched
- When Account Code Entry is performed
- When answering a Timed Reminder call with no message
- When answering an external sensor call

**Tone 4**

Message waiting indication was received.




## When you make calls

**Busy Tone**

### 4.3.1 What is This Tone?


#### Reorder Tone

The outside line you tried to seize is not assigned or denied.




#### Ringback Tones

##### Tone 1




##### Tone 2



#### Do Not Disturb (DND) Tone

The dialled extension is refusing incoming calls.




## While off-hook

#### Indication Tones


##### Tone 1

Call waiting tone



##### Tone 2


A call is on hold longer than the specified time



## When talking to an outside party

#### Warning Tone

This tone is sent 15, 10 and 5 seconds before the specified time for disconnection.




## When setting the features or programming


#### Confirmation Tones

**Tone 1**

- The feature setting was set successfully.
- A call is received in Voice-calling mode.

**Tone 2**

- Before receiving a page through an external speaker
- A call is received in Hands-free mode.

**Tone 3**


- Before the following features activate:
  - Retrieving a held call
  - Picking up another call
  - Paging/Answering a paging announcement
  - Answering the call through a speaker
- When a conversation is established with the extension in the following modes:
  - Hands-free Answerback mode
  - Voice-calling mode
- When making a call to or from a doorphone.

**Tone 4**

Establishing or leaving a conference

**Tone 5**

A call has been put on hold.





#### 4.3.1 What is This Tone?

---

---

## ***Index***

- A**
- Absent Message 111, 191, 222
  - Accessing System Features (System Feature Access) 173
  - Accessing the ISDN Service (ISDN Service Access) 46
  - Account Button 24, 199
  - Account Code Entry 32, 218
  - Adding Other Parties during a Conversation (Conference) 75
  - Alarm Setting 121
  - Alarm Setting, Remote 158
  - Alternate Calling—Ring/Voice 47, 227
  - Alternate Receiving—Ring/Voice 190
  - Announcement, Making 118
  - Announcement, Making/Answering 115
  - Answer Button 25, 57, 199
  - Answering Calls 53
  - Answering Calls, Hands-free 54
  - Answering Calls, Malicious 59
  - Answering Calls, Ringing at Other Telephones 55
  - Answering Calls, Via External Speaker 56
  - AUTO ANS (Auto Answer)/MUTE Button 21
  - AUTO DIAL/STORE Button 20
  - Automatic Call Hold 66, 90
  - Automatic Call Waiting 191
  - Automatic Callback Busy 38, 227
  - Automatic Callback Busy Cancel 39, 219
  - Automatic Line Access 30, 218
  - Automatic Redial 37
  - Call Park Retrieve 67
  - Call Pickup 55
  - Call Pickup Deny 55, 220
  - Call Splitting 68
  - Call Transfer 60, 220
  - Call Transfer (CT)—by ISDN 62, 220
  - Call Waiting 40
  - Call Waiting Tone 127
  - Call Waiting Tone Type Selection 191
  - Call Waiting, Answering 70, 220
  - Call Waiting, Automatic 191
  - Call Waiting, From PBX 70, 220
  - Call Waiting, From Telephone Company 74, 220
  - Call Waiting, Manual 191
  - Call Waiting, Receiving 127, 223
  - Call Waiting, Sending 40
  - Call, To PDN Extension 89
  - Callback Setting 38
  - Callback Setting, ISDN Line 39
  - Calling Line Identification Presentation (CLIP) 128, 189, 223
  - Calling Line Identification Restriction (CLIR) 130, 189, 224
  - Calling Line Identification Restriction (CLIR) Button 25, 199
  - Calling, Account Code 32
  - Calling, Adding Another Party 81
  - Calling, Automatically 35
  - Calling, Directory 166
  - Calling, Extension in DND Mode 45
  - Calling, From Other Extension 48
  - Calling, From Outside Directly 49, 219
  - Calling, Incoming Call Log 163
  - Calling, Joining a Call 42
  - Calling, Last Dialed Number 37
  - Calling, One-touch Button 34
  - Calling, Operator 30
  - Calling, Other Extension 29
  - Calling, Outgoing Call Log 165
  - Calling, Outside Party 30
  - Calling, Personal Preprogrammed Numbers 34
  - Calling, Preprogrammed Numbers 36
  - Calling, Private Network 31
  - Calling, Privately 131
  - Calling, System Preprogrammed Numbers 35
  - Calling, Through DISA 49
  - Calling, Using the Headset 86
  - Calling/Connected Line Identification Presentation (CLIP/CLIP) 128, 189, 223
  - CANCEL Button 23
  - CCBS → Completion of Calls to Busy Subscriber 39
  - CCBS Cancel 40, 219
  - Changing the Settings of Other Extensions 176
  - Characters, Entering 167
  - Charges, Changing 204
  - Check-in 155
  - Check-in Button 25, 200
  - Check-out 155
  - Check-out Button 25, 200
  - Cleaned-up 159
  - Cleaned-up Button 26, 200
  - Clearing Settings 136, 196
  - CLIP → Calling Line Identification Presentation 128
  - CLIR → Calling Line Identification Restriction 130
- B**
- Background Music (BGM) 132, 193, 224
  - Background Music, External Speaker Settings 180
  - Backlight, Display 189
  - Before Operating the Telephones 16
  - BGM → Background Music 132
  - Bluetooth Wireless Headset Registration 193
  - Bluetooth Wireless Headset Removal 193
  - Boss & Secretary feature 92
  - Broadcasting 118, 223
  - Built-in Simplified Voice Message 100, 222
  - Busy Tone 229
  - Buttons, Customising 24, 198
  - Buttons, Proprietary Telephone 19
- C**
- Call Charge Reference 31
  - Call Charge Reference Button 24, 199
  - Call Forwarding (CF)—by ISDN 99, 221
  - Call Forwarding (FWD) 92
  - Call Forwarding (FWD) Button 22
  - Call Forwarding (FWD)/Do Not Disturb (DND)—Both calls Button 24, 198
  - Call Hold 64, 220
  - Call Hold Retrieve 65, 220
  - Call Hold Retrieve, PDN/SDN Button 90
  - Call Log Button 24, 199
  - Call Log for ICD Group Button 25, 199
  - Call Monitor 45, 227
  - Call Park 66, 220
  - Call Park (Automatic Park Zone) Button 24, 199
  - Call Park Button 24, 199

COLP → Connected Line Identification Presentation 128  
 COLR → Connected Line Identification Restriction 129  
 Completion of Calls to Busy Subscriber (CCBS) 39, 227  
 CONF (Conference) Button 22  
 Conference 75  
 Conference (ISDN Service), Adding Parties 81  
 Conference (Multiple Party), Leaving 78  
 Conference (Three-Party), Leaving 79  
 Conference Button 24, 199  
 Conference, Adding Parties 75  
 Confirmation Tones 230  
 Connected Line Identification Presentation (COLP) 128, 189, 223  
 Connected Line Identification Restriction (COLR) 129, 224  
 Connected Line Identification Restriction (COLR) Button 25, 199  
 Connection Example 28  
 Contrast Selection, Display 188  
 CTI Button 25, 200  
 Customised Buttons 24  
 Customising Your Phone (Personal Programming) 186  
 Customising Your System (System Programming) 206

## D

Data Line Security 133, 224  
 Date & Time [000] 209  
 Denying Call Pickup 55  
 Denying Other People the Possibility of Picking Up Your Calls (Call Pickup Deny) 55  
 Dial Tone Transfer 179  
 Dial Tones 228  
 Direct Inward System Access (DISA) 49, 219  
 Direct Station Selection (DSS) Button 24, 198  
 DISA → Direct Inward System Access 49  
 Display 17  
 Display Backlight Selection 189  
 Display Contrast Selection 188  
 Display Language Selection 189  
 Display Lock 193  
 Display Switching Mode 189  
 DND → Do Not Disturb 123  
 DND Override 45, 227  
 Do Not Disturb (DND) 123  
 Do Not Disturb (DND) Button 22  
 Do Not Disturb (DND) Tone 230  
 Door Open 145, 225  
 Doorphone Call 144, 225  
 DSS → Direct Station Selection 24

## E

EFA → External Feature Access 148  
 Electronic Station Lockout → Extension Dial Lock 113, 193, 222  
 Enhanced DSS Key Mode 89  
 ENTER Button 23  
 Entering Characters 167  
 Exclusive Call Hold 64  
 Executive Busy Override 42, 227  
 Executive Busy Override Deny 131, 192, 224  
 Extension Control 176, 204  
 Extension Dial Lock 113, 193, 222

Extension Feature Clear 136, 224  
 Extension Name [004] 211  
 Extension Number [003] 211  
 Extension number, Confirming Your Own 17  
 Extension PIN (Personal Identification Number) 186, 193, 227  
 External Background Music (BGM) 180, 226  
 External Feature Access (EFA) 148, 199, 225  
 External Feature Access (EFA) Button 24, 199  
 External Relay 146  
 External Sensor 147

## F

Feature Highlights 2  
 Feature Number Table 218  
 Feature Numbers 16  
 FLASH/RECALL Button 22  
 Forced Answerback Selection 190  
 Forwarding Calls 92  
 Forwarding Calls, ISDN Service 99  
 Forwarding Calls, To Incoming Call Distribution Group 94, 221  
 FWD N/A Timer 192  
 FWD/DND Cycle Switch Mode 95, 124  
 FWD/DND Setting Mode 95, 124  
 FWD/DND settings, FWD/DND fixed button 96  
 FWD/DND status, switching with FWD/DND fixed button 96, 125  
 FWD/DND—Intercom calls Button 24, 198  
 FWD/DND—Outside calls Button 24, 198

## G

G-CO → Group-CO 24  
 Greeting Message, Recording 101, 102  
 Group FWD—Both calls Button 24, 198  
 Group FWD—Intercom calls Button 24, 199  
 Group FWD—Outside calls Button 24, 198  
 Group Paging 223  
 Group-CO (G-CO) Button 24, 198

## H

Handset/Headset Selection → Headset Operation 86, 192  
 Hands-free Answerback 54  
 Hands-free operation 85  
 Headset Button 25, 199  
 Headset Operation 86, 192  
 HOLD Button 22  
 Holding Calls 64  
 Holding in a System Parking Zone (Call Park) 66  
 Hospitality Features 154  
 Host PBX 148  
 Hot Line 35, 189, 218  
 Hotel Use 154  
 Hurry-up Button 25, 199  
 Hurry-up Transfer → Manual Queue Redirection 143

## I

ICD Group → Incoming Call Distribution Group 24  
 Icon Descriptions 17, 207  
 Incoming Call Distribution Group (ICD Group) 24, 198

Incoming Call Distribution Group Monitor 140, 225  
Incoming Call Distribution Group, Extension Status 141  
Incoming Call Distribution Group, Forwarding Calls 143  
Incoming Call Distribution Group, Leaving 137  
Incoming Call Distribution Group, Monitoring and Controlling 140  
Incoming Call Distribution Group, Waiting Call Status 140  
Incoming Call Log 163  
Indication Tones 230  
INTERCOM Button 21  
Intercom Call 29  
ISDN Service Access 46  
ISDN Service Button 25, 199  
ISDN-Hold Button 25, 199

## J

Joining an Existing Call (Executive Busy Override) 42

## K

Key Pad Tone Set 192

## L

Language, Display 189  
Last Number Redial 37, 218  
L-CO → Loop-CO 24  
LCS (Live Call Screening) 151  
LCS Mode Set (After Answering) 191  
Leaving a Message Waiting Indication/Calling Back the Caller Who Left an Indication (Message Waiting) 41  
Leaving Three-party Conference 79  
Live Call Screening (LCS) 151  
Live Call Screening Button 25, 200  
Live Call Screening Mode Set 191  
Locking Your Telephone 113  
Log-in/Log-out 137, 224  
Log-in/Log-out Button 25, 199  
Log-in/Log-out for all groups Button 25, 199  
Log-in/Log-out of a specified group Button 25, 199  
Loop-CO (L-CO) Button 24, 198

## M

Malicious Call Identification (MCID) 59, 220  
Manager Operation 176  
Manager Password 203  
Manager Programming Information 203  
Manual Call Waiting 191  
Manual Queue Redirection 143  
Message Box, Accessing from Outside 109  
Message Box, Accessing Other Extension's 110  
Message Box, Redirecting to 104  
Message Button 20, 24, 198  
Message Display (Absent Message) 111  
Message for Another Extension Button 24, 198  
Message Waiting 41, 219, 227  
Messages (Preprogrammed), Recording 161  
Monitoring Another Extension (Call Monitor) 45  
Multiple Party Conversation 75, 118  
Mute 84

## N

Names and Numbers, Storing 167  
Navigator Key 17, 23  
NDSS → Network Direct Station Selection 184  
Network Direct Station Selection (NDSS) Button 25, 200  
Network Direct Station Selection, Releasing 184

## O

Off-hook Call Announcement (OHCA) 127, 223  
Off-hook Monitor 85  
OGM → Outgoing Messages 181  
OHCA → Off-hook Call Announcement 127  
One-touch Dialling 34  
One-touch Dialling Assignment Mode Selection 194  
One-touch Dialling Button 24, 198  
One-touch Transfer 61  
One-touch Two-way Transfer 153  
One-touch Two-way Transfer Button 25, 200  
Operating Telephones, Preparations 16  
Operator Call 30, 218  
Outgoing Call Log 165  
Outgoing Messages (OGM) 181, 226  
Outgoing Messages (OGM), Recording 181  
Outside Line Group Access 30, 218  
Outside Line, Re-enabling Unavailable 183

## P

Paging 115  
Paging Announcement, Answering/Denying 117  
Paging Deny 117, 192  
Paging, and Transferring 115  
Paging, Group 115  
PAUSE Button 20  
PDN → Primary Directory Number 88  
PDN Extension 88  
Personal Absent Message 191  
Personal Programming 186  
Personal Speed Dialling 34, 218  
PIN → Personal Identification Number 186  
Portable Station, Registration 16  
Portable Station, Using in Parallel with Wired Telephone 135  
Predialling 31  
Preferred Line Assignment—Incoming 190  
Preferred Line Assignment—Outgoing 190  
Preventing Other People from Using Your Telephone (Extension Dial Lock) 113  
Primary Directory Number (PDN) Button 26, 200  
Printing Message 161  
Privacy Release 81  
PROGRAM Button 23

## Q

Quick Dialling 36

## R

Redial 37  
Redial Button 20  
Refusing Incoming Calls (Do Not Disturb [DND]) 123

Relay → External Relay 146  
 Release Button 25, 57, 199  
 Remote COS Access 48, 219  
 Remote Extension Dial Lock 176, 226  
 Remote Setting 52, 219  
 Remote Wake-up Call 158  
 Reorder Tone 230  
 Restriction Level Control (Dial Tone Transfer) 179  
 Ring Tones 228  
 Ringback Tones 230  
 Ringing Method (Ring/Voice) 47

## S

S-CO → Single-CO 24  
 Screening Calls (Live Call Screening [LCS]) 151  
 SDN → Secondary Directory Number 88  
 SDN Direct Dial 89  
 SDN Extension 88  
 SDN Walking COS 89  
 Secondary Directory Number (SDN) Button 26, 200  
 Sensor → External Sensor 147  
 Setting Your Telephone, Personal 186  
 Setting Your Telephone, Remotely 52  
 Settings, Changing Other Extension's 176  
 Settings, Feature 188  
 Settings, Keeping when Changing Extensions 162  
 Settings, Personal 186  
 Settings, Programming Mode 188  
 Settings, System 206  
 Single-CO (S-CO) Button 24, 198  
 Soft Buttons 21  
 SP-PHONE Button 19  
 Standard SDN Key Mode 89  
 Station Programme Clear → Extension Feature Clear 136, 224  
 Storing Names and Numbers 167  
 System Alarm Button 25, 199  
 System Feature Access 173  
 System Password 206  
 System Programming 206, 209  
 System Programming Information 206  
 System Programming, Icon Descriptions 207  
 System Speed Dialling 35, 218  
 System Speed Dialling Name [002] 211  
 System Speed Dialling Number [001] 210

## T

TAFAS (Trunk Answer From Any Station) 56  
 Talking to Two Parties Alternately (Call Splitting) 68  
 Telephone Number, Hiding 129, 130  
 Telephone Number, Sending 128  
 Telephone Numbers, Storing 167  
 Telephone Types 16  
 Terminate Button 24, 199  
 Three-party Conference [3PTY]—by ISDN 81, 221  
 TIE Line Access 31, 218  
 Time Service (Day/Night/Lunch/Break)  
 Button 25, 134, 177, 199, 226  
 Time Service Mode, Control 177  
 Time Service Mode, Status 134

Time Service Switching Mode (Automatic/Manual)  
 Button 25, 177, 199  
 Time Service Switching Mode (Automatic/Manual),  
 Select 177  
 Timed Reminder 121, 223  
 Toll Restriction/Call Barring Button 25, 199  
 Tone Types 228  
 TRANSFER Button 21  
 Transfer, SDN Button 91  
 Transfer, To PDN Extension 91  
 Transferring Calls, After Paging 115  
 Transferring Calls, ISDN Service 62  
 Transferring Calls, To Other Extension 60  
 Transferring Calls, To Outside Party 61  
 Troubleshooting 214  
 Trunk Answer From Any Station (TAFAS) 56, 220  
 Trunk Busy Out 183, 226  
 Two-way Record 153  
 Two-way Record Button 25, 200  
 Two-way Transfer 153  
 Two-way Transfer Button 25, 200

## U

Unattended Conference 78

## V

Verification Code Entry 48, 219  
 Virtual PS 96  
 Voice Mail Integration 149, 225  
 Voice Mail Transfer 149  
 Voice Mail Transfer Button 25, 149, 200  
 Voice Mail, Call Forwarding 149  
 Voice Mail, Monitoring → Live Call Screening (LCS) 151  
 Voice Mail, Recording Conversation 152  
 Voice Messages 100  
 Voice Messages, Leaving 105  
 Voice Messages, Listening to 106  
 Voice Processing System 149  
 Volume Key 17, 23

## W

Walking COS 48  
 Walking Extension 162, 226  
 Warning Tone 230  
 When the Dialed Line is Busy or There is No Answer 38  
 Whisper OHCA 127, 223  
 Wireless XDP Parallel Mode 135, 224  
 Wrap-up 137  
 Wrap-up Button 25, 199

## Y

Your Extension Number 17



The KX-TDA100DCE is designed to interwork with the:

- Analogue Public Switched Telephone Network (PSTN) of European countries
- Pan-European Integrated Services Digital Network (ISDN) using ISDN basic rate access
- Pan-European Integrated Services Digital Network (ISDN) using ISDN primary rate access
- ONP 2048 kbit/s digital structured leased lines (D2048S)

Panasonic System Networks Co., Ltd. declares that this equipment is in compliance with the essential requirements and other relevant provisions of Radio & Telecommunications Terminal Equipment (R&TTE) Directive 1999/5/EC.

Declarations of Conformity for the relevant Panasonic products described in this manual are available for download by visiting:

**<http://www.doc.panasonic.de>**

Contact to Authorised Representative:  
Panasonic Testing Centre  
Panasonic Marketing Europe GmbH  
Winsbergring 15, 22525 Hamburg, Germany





**For Future Reference**

Please print, record, and retain the following information for future reference.

**Note**

The serial number of this product can be found on the label affixed to the unit. You should record the model number and the serial number of this unit as a permanent record of your purchase to aid in identification in the event of theft.

|                   |                                  |
|-------------------|----------------------------------|
| MODEL NO.         | _____                            |
| SERIAL NO.        | _____                            |
| DATE OF PURCHASE  | _____                            |
| NAME OF DEALER    | _____                            |
| DEALER'S ADDRESS  | _____<br>_____<br>_____<br>_____ |
| DEALER'S TEL. NO. | _____                            |

**Panasonic System Networks Co., Ltd.**

1-62, 4-chome, Minoshima, Hakata-ku, Fukuoka 812-8531, Japan

**Copyright:**

This material is copyrighted by Panasonic System Networks Co., Ltd., and may be reproduced for internal use only. All other reproduction, in whole or in part, is prohibited without the written consent of Panasonic System Networks Co., Ltd.

© Panasonic System Networks Co., Ltd. 2010